

# 2014 JUKE OWNER'S MANUAL

For your safety, read carefully and keep in this vehicle.

DEALER E-PROCESS

## **Foreword**

Welcome to the growing family of new NISSAN owners. This vehicle is delivered to you with confidence. It was produced using the latest techniques and strict quality control.

This manual was prepared to help you understand the operation and maintenance of your vehicle so that you may enjoy many miles of driving pleasure. Please read through this manual before operating your vehicle.

A separate Warranty Information Booklet explains details about the warranties covering your vehicle. The NISSAN Service and Maintenance Guide explains details about maintaining and servicing your vehicle. Additionally, a separate Customer Care/Lemon Law Booklet (U.S. only) will explain how to resolve any concerns you may have with your vehicle, as well as clarify your rights under your state's lemon law.

In addition to factory installed options, your vehicle may also be equipped with additional accessories installed by NISSAN or by your NISSAN dealer prior to delivery. It is important that you familiarize yourself with all disclosures, warnings, cautions and instructions concerning proper use of such accessories prior to operating the vehicle and/or accessory. See a NISSAN dealer for details concerning the particular

accessories with which your vehicle is equipped.

Your NISSAN dealer knows your vehicle best. When you require any service or have any questions, we will be glad to assist you with the extensive resources available to us.

#### READ FIRST — THEN DRIVE SAFELY

Before driving your vehicle, read your Owner's Manual carefully. This will ensure familiarity with controls and maintenance requirements, assisting you in the safe operation of your vehicle.



#### WARNING

## IMPORTANT SAFETY INFORMATION REMINDERS FOR SAFETY!

Follow these important driving rules to help ensure a safe and comfortable trip for you and your passengers!

- NEVER drive under the influence of alcohol or drugs.
- ALWAYS observe posted speed limits and never drive too fast for conditions.
- ALWAYS give your full attention to driving and avoid using vehicle features or taking other actions that

- could distract you.
- ALWAYS use your seat belts and appropriate child restraint systems.
   Pre-teen children should be seated in the rear seat.
- ALWAYS provide information about the proper use of vehicle safety features to all occupants of the vehicle.
- ALWAYS review this Owner's Manual for important safety information.

## On-pavement and off-road driving

This vehicle will handle and maneuver differently from an ordinary passenger car because it has a higher center of gravity. As with other vehicles with features of this type, failure to operate this vehicle correctly may result in loss of control or an accident. Be sure to read "Avoiding collision and rollover" and "Driving safety precautions" in the "5. Starting and driving" section of this manual.





#### MODIFICATION OF YOUR VEHI-CLE

This vehicle should not be modified. Modification could affect its performance. safety or durability, and may even violate governmental regulations. In addition. damage or performance problems resulting from modification may not be covered under NISSAN warranties.

#### WHEN READING THE MANUAL

This manual includes information for all features and equipment available on this model. Features and equipment in your vehicle may vary depending on model, trim level, options selected, order, date of production, region or availability. Therefore, you may find information about features or equipment that are not included or installed on your vehicle.

All information, specifications and illustrations in this manual are those in effect at the time of printing, NISSAN reserves the right to change specifications, performance, design or component suppliers without notice and without obligation. From time to time, NISSAN may update or revise this manual to provide Owners with the most accurate information currently available. Please carefully read and retain with this manual all revision updates sent to you by NISSAN to ensure you have access to accurate and up-to-date information regarding your vehicle. Current versions of vehicle Owner's Manuals and any updates can also be found in the Owner section of the NISSAN website at https://owners.nissanusa.com/nowners/navigation/manualsGuide. If you have questions concerning any information in your Owner's Manual, contact NISSAN Consumer Affairs. See the NISSAN CUSTOMER CARE PROGRAM page in this Owner's Manual for contact information.

#### IMPORTANT INFORMATION ABOUT THIS MANUAL

You will see various symbols in this manual. They are used in the following ways:



### **WARNING**


This is used to indicate the presence of a hazard that could cause death or serious personal injury. To avoid or reduce the risk, the procedures must be followed precisely.



#### A CAUTION

This is used to indicate the presence of a hazard that could cause minor or moderate personal injury or damage to vour vehicle. To avoid or reduce the risk. the procedures must be followed carefully.





If you see the symbol above, it means "Do not do this" or "Do not let this happen".





If you see a symbol similar to those above in an illustration, it means the arrow points to the front of the vehicle.









Arrows in an illustration that are similar to those above indicate movement or action.









Arrows in an illustration that are similar to those

above call attention to an item in the illustration.
CALIFORNIA PROPOSITION 65
WARNING



Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

#### CALIFORNIA PERCHLORATE ADVI-SORY

Some vehicle parts, such as lithium batteries, may contain perchlorate material. The following advisory is provided: "Perchlorate Material - special handling may a pply, see www.dtsc.ca.gov/hazardouswaste/perchlorate."



Bluetooth

Bluetooth<sup>®</sup> is a trademark owned by Bluetooth SIG, Inc., and licensed to Visteon Corporation and Bosch.

(((Sirius XIIII))

SiriusXM Satellite Radio requires subscription, sold separately. Not available in Alaska, Hawaii or Guam. For more information, visit www.siriusxm.com.

© 2014 NISSAN MOTOR CO., LTD.

All rights reserved. No part of this Owner's Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Nissan Motor Co., Ltd.

## NISSAN CUSTOMER CARE PROGRAM

#### **NISSAN CARES ...**

Both NISSAN and your NISSAN dealer are dedicated to serving all your automotive needs. Your satisfaction with your vehicle and your NISSAN dealer are our primary concerns. Your NISSAN dealer is always available to assist you with all your automobile sales and service needs.

However, if there is something that your NISSAN dealer cannot assist you with or you would like to provide NISSAN directly with comments or questions, please contact the NISSAN Consumer Affairs Department using our toll-free number:

For U.S. customers 1-800-NISSAN-1 (1-800-647-7261) For Canadian customers 1-800-387-0122

The Consumer Affairs Department will ask for the following information:

- Your name, address, and telephone number
- Vehicle identification number (attached to the top of the instrument panel on the driver's side)
- Date of purchase
- Current odometer reading
- Your NISSAN dealer's name
- Your comments or questions

OR

You can write to NISSAN with the information at:

For U.S. customers
Nissan North America, Inc.
Consumer Affairs Department
P.O. Box 685003
Franklin, TN 37068-5003
or via e-mail at:
nnaconsumeraffairs@nissan-usa.com

For Canadian customers
Nissan Canada Inc.
5290 Orbitor Drive
Mississauga, Ontario L4W 4Z5
or via e-mail at:
information.centre@nissancanada.
com

If you prefer, visit us at:

**www.nissan.ca** (for Canadian customers)
We appreciate your interest in NISSAN and thank you for buying a quality NISSAN vehicle.

www.nissanusa.com (for U.S. customers) or





# Table of Contents

| Illustrated table of contents                                | 0  |
|--|----|
| Safety — Seats, seat belts and supplemental restraint system | 1  |
| Instruments and controls                                     | 2  |
| Pre-driving checks and adjustments                           | 3  |
| Heater, air conditioner, audio and phone systems             | 4  |
| Starting and driving   | 5  |
| In case of emergency   | 6  |
| Appearance and care  | 7  |
| Maintenance and do-it-yourself                               | 8  |
| Technical and consumer information                           | 9  |
| Index  | 10 |

DEALER E-PROCESS




## 0 Illustrated table of contents

| Seats, seat belts and Supplemental Restraint |     |
|--|-----|
| System (SRS)                                 | 0-2 |
| Exterior front                               | 0-3 |
| Exterior rear                                | 0-4 |
| Exterior (NISMO models)                      | 0-8 |
| Passenger compartment                        | 0-6 |

| Cockpit                      | . 0- |
|------------------------------|------|
| Instrument panel             | 0-   |
| Meters and gauges            | 0-   |
| Engine compartment           |      |
| MR16DDT engine               | 0-1  |
| Warning and indicator lights | 0-1  |



#### **SEATS, SEAT BELTS AND** SUPPLEMENTAL RESTRAINT SYSTEM (SRS)



- Rear head restraints (Page 1-5)
- Child restraint anchor points (for top tether strap child restraint) (P.1-30, P.1-34)
- Front head restraints (P.1-5)
  - Front-seat Active Head Restraints (P.1-9)
- Roof-mounted curtain side-impact supplemental air bags (P.1-38)


- Seat belts (P.1-10)
- Front seats (P.1-3)
- Supplemental front-impact air bags (P.1-38)
  - LATCH (Lower Anchors and Tethers for CHildren) system (P.1-20)
- Rear seats (P.1-4)
  - Child restraints (P.1-18)



- 10. Front seat-mounted side-impact supplemental air bags (P.1-38)
- 11. Seat belt with pretensioners (P.1-50)
- 12. Occupant classification sensors (weight sensors)
  - Advanced Air Bag System (P.1-44)
- 13. Front passenger air bag status light (P.1-46)

#### Illustrated table of contents

#### **EXTERIOR FRONT**




- Hood (P.3-19)
- Windshield wiper and washer
  - Switch operation (P.2-32)
  - Blade replacement (P.8-17)
  - Window washer fluid (P.8-12)
- Parking lights, turn signal lights and front side marker lights

- Switch operation (P.2-35)
- Bulb replacement (P.8-27)
- Moonroof\* (P.2-48)
- Side turn signal lights
  - Switch operation (P.2-38)
  - Bulb replacement (P.8-28)
- Power windows (P.2-45)

- Outside mirrors (P.3-25)
- License plate installation (P.9-13)
- Recovery hook (P.6-14)
- Fog lights\*
  - Switch operation (P.2-39)
  - Bulb replacement (P.8-28)
- 11. Headlights
  - Switch operation (P.2-35)
  - Bulb replacement (P.8-28)
- 12. Tires
  - Wheels and tires (P.8-30, P.9-8)
  - Flat tire (P.6-3)
  - Tire Pressure Monitoring System (TPMS) (P.2-15, P.5-4)
- 13. Doors
  - Keys (P.3-2)
  - Door locks (P.3-4)
  - Remote keyless entry system\* (P.3-7)
  - Intelligent Key system\* (P.3-10)
  - Security system (P.2-29)
- if so equipped

#### **EXTERIOR REAR**



- 1. Lift gate (P.3-20)
  - Intelligent Key system\* (P.3-10)
- 2. Rear window wiper and washer
  - Switch operation (P.2-34)
  - Window washer fluid (P.8-12)


Illustrated table of contents

- 3. Rear spoiler\* (P.7-3)
- 4. High-mounted stop light (P.8-26)

- 5. Antenna (P.4-70)
  - Satellite radio antenna\* (P.4-28)
- 6. Rear window defroster (P.2-35)
- 7. Fuel-filler door
  - Operation (P.3-21)
  - Fuel information (P.9-4)
- 8. RearView camera\* (P.4-15)

- 9. Rear combination lights
  - Bulb replacement (P.8-28)
- 10. Child safety rear door lock (P.3-6)
- : if so equipped

#### **EXTERIOR (NISMO models)**




For NISMO models, the vehicle parts listed below require special care or caution for cleaning. Refer to the additional information in each section.

- Front bumper (P.3-20, P.6-14)
- Daytime running light (P.2-37, P.3-20, P.8-26, P.8-28)
- Side sill extensions (P.3-20)
- Rear spoiler (P.3-20, P.7-3)



#### PASSENGER COMPARTMENT




- 1. Cargo area
  - Cargo cover\* (P.2-44)
  - Cargo light (P.2-51, P.8-26)
- 2. Coat hook (P.2-44)
- 3. Sun visors (P.3-24)
- 4. Microphone (P.4-72, P.4-85)
- 5. Moonroof switch\* (P.2-48)
- 0-6 Illustrated table of contents

- 6. Room light and map lights (P.2-50)
- 7. Inside rearview mirror (P.3-25)
- 8. Door armrest
  - Power window switch (P.2-45)
  - Power door lock switch (P.3-5)
- ': if so equipped



#### COCKPIT




- Outside mirror remote control switch (P.3-25)
- Headlight, fog light and turn signal switch
  - Headlight (P.2-35)
  - Turn signal light (P.2-38)
  - Fog light\* (P.2-39)
- Paddle shifter\* (P.5-20)
- Steering wheel

- Electric power steering system (P.5-38)
- Horn (P.2-39)
- Driver's supplemental air bag (P.1-38)
- Wiper and washer switch (P.2-32)
- Shift lever
  - Continuously Variable Transmission (CVT) (P.5-17)

- Manual Transmission (MT) (P.5-23)
- Fuse box cover (P.8-21) 7.
- Vehicle Dynamic Control (VDC) OFF switch (P.5-41)
- All-Wheel Drive (AWD) switch\* (P.5-33)
- 10. Tilting steering wheel lever (P.3-23)
- Steering-wheel-mounted controls (left side)
  - Audio control (P.4-69)
  - Bluetooth® Hands-Free Phone System control (P.4-72, P.4-85)
- Ignition switch (models without Intelligent Key system) (P.5-10)
- 13. Steering-wheel-mounted controls (right side)
  - Cruise control switches (P.5-30)
- 14. Heated seat switch\* (P.2-40)
- if so equipped


#### **INSTRUMENT PANEL**




- 1. Meters and gauges (P.2-5)
- 2. Center ventilator (P.4-19)
- Audio system\* or Navigation system\*\* (P.4-28)
   Clock\* (P.2-41)
- 4. Hazard warning flasher switch (P.6-2)
- 5. Integrated Control System\* (P.2-21)
  - Drive mode (P.5-25)

- Heater and air conditioner control (P.4-20)
- Defroster switch (P.2-35)
- Heater and air conditioner control (models without Integrated Control System) (P.4-20)
  - Defroster switch (P.2-35)
- 6. Front passenger supplemental air bag (P.1-38)
- 7. Side ventilator (P.4-19)

- 8. Fuel-filler door release handle (P.3-21)
- 9. Hood release handle (P.3-19)
- Push-button ignition switch (models with Intelligent Key system) (P.5-12)
- 11. AUX/USB connector\* (P.4-31)
- 12. Parking brake (P.5-29)
- 13. Cup holder (P.2-42)
- 14. Power outlet (P.2-42)
- 15. Glove box (P.2-44)
- \*: if so equipped
- \*\*: Refer to the separate Navigation System Owner's Manual.



#### **METERS AND GAUGES**




- Tachometer (P.2-8)
- Engine coolant temperature gauge (P.2-8)
- Vehicle information display (P.2-9)
  - Odometer/twin trip odometer (P.2-6)
  - Trip computer (P.2-10)
  - Torque vectoring AWD (AWD model) (P.2-11)

- Outside air temperature (P.2-10)
- Fuel gauge (P.2-9)
- Speedometer (P.2-6)
- Warning/indicator lights (P.2-12)
- Instrument brightness control knob (P.2-38)
- Continuously Variable Transmission (CVT) position indicator\* (P.2-10)

- RESET switch for trip odometer (P.2-6)/Trip computer mode switch (P.2-10)
- if so equipped

#### **ENGINE COMPARTMENT**



#### MR16DDT ENGINE

- 1. Engine oil filler cap (P.8-8)
- 2. Radiator filler cap (P.8-8)
  - Vehicle overheat (P.6-10)
- 3. Brake and clutch\* fluid reservoir (P.8-11)
- 4. Air cleaner (P.8-16)
- 5. Window washer fluid reservoir (P.8-12)
- 0-10 Illustrated table of contents

- 6. Engine drive belt location (P.8-15)
- 7. Engine oil dipstick (P.8-8)
- 8. Engine coolant reservoir (P.8-8)
- 9. Fuse/fusible link holder (P.8-19)
- 10. Battery (P.8-13)
  - Jump starting (P.6-8)
- \*: for Manual Transmission (MT) models



#### WARNING AND INDICATOR LIGHTS

|                  |  | _    |
|------------------|--|------|
| Warning<br>light | Name   | Page |
| AWD              | All-Wheel Drive (AWD) warning light (yellow) (AWD model) | 2-13 |
| ABS              | Anti-lock Braking System (ABS) warning light             | 2-13 |
| BRAKE            |  |      |
| <b>(D)</b>       | Brake warning light                                      | 2-13 |
| +                | Charge warning light                                     | 2-14 |
|                  | Door open warning light                                  | 2-14 |
| PS               | Electric power steering warning light                    | 2-14 |
| þ                | Engine oil pressure warning light                        | 2-14 |
| (E)              | Intelligent Key system warning light*                    | 2-14 |
|                  | Low fuel warning light                                   | 2-15 |
| :                | Low tire pressure warning light                          | 2-15 |
| (3               | Low washer fluid warning light*                          | 2-16 |
| P#<br>SHIF1      | P position selecting warning light*                      | 2-16 |
| Ž.               | Seat belt warning light                                  | 2-16 |
| *                | Supplemental air bag warning light                       | 2-17 |

| Warning<br>light | Name  | Page |
|------------------|---|------|
| ΦĄ               | Vehicle Dynamic Control (VDC) warning light | 2-17 |

| Indicator<br>light        | Name   | Page |
|---------------------------|--|------|
| AWD                       | All-Wheel Drive (AWD) indicator light (green) (AWD model)      | 2-17 |
| <b>₹</b> ₹ <b>I</b>       | All-Wheel Drive (AWD)-V indicator light (green) (AWD model)    | 2-17 |
| CVT                       | Continuously Variable Trans-<br>mission (CVT) indicator light* | 2-17 |
| CRUISE                    | Cruise indicator light   | 2-18 |
| ŗ                         | Engine start operation indicator light*                        | 2-18 |
| ŭ,                        | Exterior light indicator                                       | 2-18 |
| 0+ 20 2                   | Front passenger air bag status light                           | 2-18 |
|                           | High beam indicator light                                      | 2-18 |
| SERVICE<br>ENGINE<br>SOON | Malfunction Indicator Light (MIL)                              | 2-18 |
| Ŷ                         | Security indicator light                                       | 2-19 |
| 4                         | Turn signal/hazard indicator lights                            | 2-19 |
| F<br>OFF                  | Vehicle Dynamic Control (VDC) off indicator light              | 2-19 |

if so equipped



#### **MEMO**




## 1 Safety — Seats, seat belts and supplemental restraint system

| Seats   | 1-2      |
|---|----------|
| Front seats                                   | 1-3      |
| Rear seats                                    | 1-4      |
| Head restraints/headrests                     | 1-5      |
| Adjustable head restraint/headrest components | 1-6      |
| Non-adjustable head                           |          |
| restraint/headrest components                 | 1-7      |
| Remove  | 1-7      |
| Install                                       | 1-7      |
| Adjust  | 1-8      |
| Front-seat Active Head Restraints (if         |          |
| so equipped)                                  | 1-9      |
| Seat belts                                    | 1-10     |
| Precautions on seat belt usage                | 1-10     |
| Pregnant women                                | 1-12     |
|   | 1-12     |
| Three-point type seat belt                    | 1-12     |
|   | 1-15     |
| Seat belt maintenance                         | 1-15     |
| Child safety                                  | 1-16     |
| ,   | 1-17     |
|   | 1-17     |
|   | <br>1-17 |
|   |          |

| Child restraints   | 1-18 |
|--|------|
| Precautions on child restraints  | 1-18 |
| Lower Anchors and Tethers for CHildren   |      |
| System (LATCH)   | 1-20 |
| Rear-facing child restraint installation   |      |
| using LATCH  | 1-22 |
| Rear-facing child restraint installation using the                                       |      |
| seat belts   | 1-25 |
| Forward-facing child restraint installation  | 1 00 |
| using LATCH  | 1-28 |
| Forward-facing child restraint installation using the seat belts                         | 1-30 |
| Booster seats  | 1-34 |
|  |      |
| Supplemental restraint system  | 1-38 |
| Precautions on supplemental restraint system   | 1-38 |
| NISSAN Advanced Air Bag System   | 4 4  |
| (front seats)  | 1-44 |
| Front seat-mounted side-impact supplemental air bag and roof-mounted curtain side-impact |      |
| supplemental air bag systems   | 1-49 |
| Seat belts with pretensioners (front seats)  | 1-50 |
| Supplemental air bag warning labels  | 1-52 |
| Supplemental air bag warning light   | 1-52 |
|  | 1-52 |
| Repair and replacement procedure   | 1-02 |



#### **SEATS**



## **WARNING**

- Do not ride in a moving vehicle when the seatback is reclined. This can be dangerous. The shoulder belt will not be against your body. In an accident, you could be thrown into it and receive neck or other serious injuries. You could also slide under the lap belt and receive serious internal injuries.
- For the most effective protection when the vehicle is in motion, the seat should be upright. Always sit

well back in the seat with both feet on the floor and adjust the seat properly. See "Precautions on seat belt usage" (P.1-10).


- After adjustment, gently rock in the seat to make sure it is securely locked.
- Do not leave children unattended inside the vehicle. They could unknowingly activate switches or controls. Unattended children could become involved in serious accidents.


The seatback should not be reclined any more than needed for comfort. Seat belts are most effective when the passenger sits well back and straight up in the seat. If the seatback is reclined, the risk of sliding under the lap belt and being injured is increased.



When adjusting the seat positions, be sure not to contact any moving parts to avoid possible injuries and/or damage.

Safety — Seats, seat belts and supplemental restraint system





Type B

FRONT SEATS

Front manual seat adjustment

#### Forward and backward:

Pull the lever (1) up and hold it while you slide the seat forward or backward to the desired position. Release the lever to lock the seat in position.

#### Reclining (Type A):

To recline the seatback, pull the lever (2) up and lean back. To bring the seatback forward, pull the lever up and lean your body forward. Release the lever to lock the seatback in position.

The reclining feature allows adjustment of the seatback for occupants of different sizes for added comfort and to help obtain proper seat belt fit. (See "Precautions on seat belt usage" (P.1-10).) Also, the seatback can be reclined to allow occupants to rest when the vehicle is stopped and the transmission is in the P (Park) position or N (Neutral) position with the parking brake fully applied.


#### Reclining (Type B):

To recline the seatback, turn the adjusting dial (2) toward the rear of the vehicle and lean back. To bring the seatback forward, turn the adjusting dial toward the front of the vehicle and lean your body forward. Release the dial to lock the seatback in position.

The reclining feature allows adjustment of the seatback for occupants of different sizes for added comfort and to help obtain proper seat belt fit. (See "Precautions on seat belt usage" (P.1-10).) Also, the seatback can be reclined to allow occupants to rest when the vehicle is stopped and the transmission is in the P (Park) position or N (Neutral) position with the parking brake fully applied.


#### NOTE:

- Depending on the passenger's seat sliding position when the passenger seat is unoccupied while driving, a noise may be heard as the side part of the passenger's seat contacts the seat belt tongue. In this case, move the seat to the rearmost position to avoid interference.
- If you are having difficulty turning the adjusting dial, park the vehicle and then open the door or get out of the vehicle to operate the dial.



Seat lifter (for driver's seat):

Pull up or push down the adjusting lever to adjust the seat height until the desired position is achieved.



**REAR SEATS** 

#### **Folding**

#### Before folding the rear seats:

Secure the seat belts on the seat belt hooks on the side wall. (See "Seat belt hooks" (P.1-15).)

To fold the seatback, pull the adjusting knob  $\bigcirc$  .

To return the seatback to the seating position, lift up each seatback and push it to the upright position until it is latched.

#### **HEAD RESTRAINTS/HEADRESTS**

### **A** CAUTION

When folding or returning the seatback(s) to the upright position, to avoid injury to yourself and others:

Make sure that the seat path is clear before moving the seat.



#### **WARNING**

- Do not fold down the rear seats when occupants are in the rear seat area or any objects are on the rear seats.
- Never allow anyone to ride in the cargo area or on the rear seats when they are in the fold-down position. Use of these areas by passengers without proper restraints could result in serious injury in an accident or sudden stop.
- Properly secure all cargo with ropes or straps to help prevent it from sliding or shifting. Do not place cargo higher than the seatbacks. In a sudden stop or collision, unsecured cargo could cause personal

#### injury.


When returning the seatbacks to the upright position, be certain they are completely secured in the latched position. If they are not completely secured, passengers may be injured in an accident or sudden stop.



#### **WARNING**

Head restraint/headrest supplement the other vehicle safety systems. They may provide additional protection against injury in certain rear end collisions. Adjustable head restraints/headrests must be adjusted properly, as specified in this section. Check the adjustment after someone else uses the seat. Do not attach anything to the head restraint/headrest stalks or remove the head restraint/headrest. Do not use the seat if the head restraint/ headrest has been removed. If the head restraint/headrest was removed, reinstall and properly adjust the head restraint/headrest before an occupant uses the seating position. Failure to follow these instructions can reduce the effectiveness of the head restraint/ headrest. This may increase the risk of serious injury or death in a collision.






The illustration shows the seating positions equipped with head restraint/headrest.


- ▲ Indicates the seating position is equipped with a head restraint.
- Indicates the seating position is equipped with a headrest.
- + indicates the seating position is not equipped with a head restraint or headrest.
- Your vehicle is equipped with a head restraint/headrest that may be integrated, adjustable or non-adjustable.
- Adjustable head restraints/headrests have multiple notches along the stalk to lock them in a desired adjustment position.

- The non-adjustable head restraints/headrests have single locking notch to secure them to the seat frame.
- Proper Adjustment:
  - For the adjustable type, align the head restraint/headrest so the center of your ear is approximately level with the center of the head restraint/headrest.
  - If your ear position is still higher than the recommended alignment, place the head restraint/headrest at the highest position.
- If the head restraint/headrest has been removed, ensure that it is reinstalled and locked in place before riding in that designated seating position.




#### ADJUSTABLE HEAD RESTRAINT/ HEADREST COMPONENTS

- 1. Removable head restraint/headrest
- 2. Multiple notches
- 3. Lock knob
- 4. Stalks



#### NON-ADJUSTABLE HEAD RE-STRAINT/HEADREST COMPONENTS


- Removable head restraint/headrest
- Single notch
- Lock knob
- Stalks



#### **REMOVE**


Use the following procedure to remove the head restraint/headrest.

- 1. Pull the head restraint/headrest up to the highest position.
- Push and hold the lock knob.
- Remove the head restraint/headrest from the seat.
- 4. Store the head restraint/headrest properly in a secure place so it is not loose in the vehicle.
- 5. Reinstall and properly adjust the head restraint/headrest before an occupant uses the seating position.



#### **INSTALL**


- 1. Align the head restraint/headrest stalks with the holes in the seat. Make sure that the head restraint/headrest is facing the correct direction. The stalk with the adjustment notch (1) must be installed in the hole with the lock knob (2).
- 2. Push and hold the lock knob and push the head restraint/headrest down.
- 3. Properly adjust the head restraint/headrest before an occupant uses the seating position.






#### For adjustable head restraint/headrest

Adjust the head restraint/headrest so the center is level with the center of your ears. If your ear position is still higher than the recommended alignment, place the head restraint/headrest at the highest position.




For non-adjustable head restraint/head-rest

Make sure the head restraint/headrest is positioned so the lock knob is engaged in the notch before riding in that designated seating position.



#### Raise


To raise the head restraint/headrest, pull it up. Make sure the head restraint/headrest is positioned so the lock knob is engaged in the notch before riding in that designated seating position.



#### Lower

To lower, push and hold the lock knob and push the head restraint/headrest down.

Make sure the head restraint/headrest is positioned so the lock knob is engaged in the notch before riding in that designated seating position.



FRONT-SEAT ACTIVE HEAD RE-STRAINTS (if so equipped)

The Active Head Restraint moves forward utilizing the force that the seatback receives from the occupant in a rear-end collision. The movement of the head restraint helps support the occupant's head by reducing its backward movement and helping absorb some of the forces that may lead to whiplash-type injuries.

Active Head Restraints are effective for collisions at low to medium speeds in which it is said that whiplash injury occurs most.

Active Head Restraints operate only in certain rear-end collisions. After the collision, the head restraints return to their original positions.

The front head restraints have multiple adjustment notches.


Properly adjust the Active Head Restraints as described in this section.


#### **SEAT BELTS**


#### PRECAUTIONS ON SEAT BELT USAGE

If you are wearing your seat belt properly adjusted, and you are sitting upright and well back in your seat with both feet on the floor, your chances of being injured or killed in an accident and/or the severity of injury may be greatly reduced. NISSAN strongly encourages you and all of your passengers to buckle up every time you drive, even if your seating position includes a supplemental air bag.

Most U.S. states and Canadian provinces or territories specify that seat belts be worn at all times when a vehicle is being driven.







## WARNING

- Every person who drives or rides in this vehicle should use a seat belt at all times. Children should be properly restrained in the rear seat and, if appropriate, in a child restraint,
- The seat belt should be properly adjusted to a snug fit. Failure to do so may reduce the effectiveness of the entire restraint system and increase the chance or severity of injury in an accident. Serious injury or death can occur if the seat belt is not worn properly.
- Always route the shoulder belt over your shoulder and across your chest. Never put the belt behind vour back, under vour arm or across your neck. The belt should be away from your face and neck, but not falling off your shoulder.
- Position the lap belt as low and snug as possible AROUND THE HIPS, NOT THE WAIST. A lap belt worn too high could increase the risk of internal injuries in an accident.

- Be sure the seat belt tonque is securely fastened to the proper buckle.
- Do not wear the seat belt inside out or twisted. Doing so may reduce its effectiveness.
- Do not allow more than one person to use the same seat belt.
- Never carry more people in the vehicle than there are seat belts.
- If the seat belt warning light glows continuously while the ignition is turned ON with all doors closed and all seat belts fastened, it may indicate a malfunction in the system. Have the system checked by a NISSAN dealer.
- No changes should be made to the seat belt system. For example, do not modify the seat belt, add material, or install devices that may change the seat belt routing or tension. Doing so may affect the operation of the seat belt system. Modifying or tampering with the seat belt system may result in serious personal injury.

- Once a seat belt pretensioner has activated, it cannot be reused and must be replaced together with the retractor. See a NISSAN dealer.
- Removal and installation of the pretensioner system components should be done by a NISSAN dealer.
- All seat belt assemblies, including retractors and attaching hardware, should be inspected after any collision by a NISSAN dealer. NISSAN recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Seat belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.
- All child restraints and attaching hardware should be inspected after any collision. Always follow the restraint manufacturer's inspection instructions and replacement recommendations. The child restraints should be replaced if they are

#### damaged.

#### PREGNANT WOMEN

NISSAN recommends that pregnant women use seat belts. The seat belt should be worn snug, and always position the lap belt as low as possible around the hips, not the waist. Place the shoulder belt over your shoulder and across your chest. Never put the lap/shoulder belt over your abdominal area. Contact your doctor for specific recommendations.

#### INJURED PERSONS

NISSAN recommends that injured persons use seat belts, depending on the injury. Check with your doctor for specific recommendations.

#### THREE-POINT TYPE SEAT BELT

## **A** WARNING

- Every person who drives or rides in this vehicle should use a seat belt at all times.
- Do not ride in a moving vehicle when the seatback is reclined. This can be dangerous. The shoulder belt will not be against your body. In an accident, you could be thrown into it and receive neck or other serious

- injuries. You could also slide under the lap belt and receive serious internal injuries.
- For the most effective protection when the vehicle is in motion, the seat should be upright. Always sit well back in the seat with both feet on the floor and adjust the seat belt properly.
- Do not allow children to play with the seat belts. Most seating positions are equipped with Automatic Locking Retractor (ALR) mode seat belts. If the seat belt becomes wrapped around a child's neck with the ALR mode activated, the child can be seriously injured or killed if the seat belt retracts and becomes tight. This can occur even if the vehicle is parked. Unbuckle the seat belt to release the child. If the seat belt can not be unbuckled or is already unbuckled, release the child by cutting the seat belt with a suitable tool (such as a knife or scissors) to release the seat belt.

#### Fastening the seat belts

1. Adjust the seat. (See "Seats" (P.1-2).)



- 2. Slowly pull the seat belt out of the retractor and insert the tongue into the buckle until you hear and feel the latch engage.
  - The retractor is designed to lock during a sudden stop or on impact. A slow pulling motion permits the belt to move and allows you some freedom of movement in the seat.
  - If the seat belt cannot be pulled from its fully retracted position, firmly pull the belt and release it. Then smoothly pull the belt out of the retractor.



- 3. Position the lap belt portion low and snug on the hips as shown.
- 4. Pull the shoulder belt portion toward the retractor to take up extra slack. Be sure the shoulder belt is routed over your shoulder and across your chest.

The front passenger seat and the rear seating positions three-point seat belts have two modes of operation:

- Emergency Locking Retractor (ELR)
- Automatic Locking Retractor (ALR)

The Emergency Locking Retractor (ELR) mode allows the seat belt to extend and retract to allow the driver and passengers some freedom

of movement in the seat. The ELR locks the seat belt when the vehicle slows down rapidly or during certain impacts.


The Automatic Locking Retractor (ALR) mode (child restraint mode) locks the seat belt for child restraint installation.

When ALR mode is activated the seat belt cannot be extended again until the seat belt tongue is detached from the buckle and fully retracted. The seat belt returns to the ELR mode after the seat belt fully retracts. For additional information, see "Child restraints" (P.1-18).

The ALR mode should be used only for child restraint installation. During normal seat belt use by an occupant, the ALR mode should not be activated. If it is activated, it may cause uncomfortable seat belt tension.


### **WARNING**

When fastening the seat belts, be certain that seatbacks are completely secured in the latched position. If they are not completely secured, passengers may be injured in an accident or sudden stop.



Unfastening the seat belts To unfasten the seat belt, push the button on the

buckle. The seat belt automatically retracts.



Shoulder belt height adjustment (for front seats)

The shoulder belt anchor height should be adjusted to the position best for you. (See "Precautions on seat belt usage" (P.1-10).)

To adjust, pull the adjustment button (1), and then move the shoulder belt anchor to the desired position (2), so that the belt passes over the center of the shoulder. The belt should be away from your face and neck, but not falling off of your shoulder. Release the adjustment button to lock the shoulder belt anchor into position.

The range of height adjustment of the shoulder




belt may vary depending on the model.



#### **WARNING**

- After adjustment, release the adjustment button and try to move the shoulder belt anchor up and down to make sure it is securely fixed in position.
- The shoulder belt anchor height should be adjusted to the position best for you. Failure to do so may reduce the effectiveness of the entire restraint system and increase the chance or severity of injury in an accident.



#### Seat belt hooks

When the rear seat belts are not in use and when folding down the rear seats, hook the rear seat belts on the seat belt hooks.

#### SEAT BELT EXTENDERS

If, because of body size or driving position, it is not possible to properly fit the lap-shoulder belt and fasten it, an extender that is compatible with the installed seat belts is available that can be purchased. The extender adds approximately 8 in (200 mm) of length and may be used for either the driver or front passenger seating position. See a NISSAN dealer for assistance with purchasing an extender if an extender is required.



#### WARNING

- Only NISSAN seat belt extenders, made by the same company which made the original equipment seat belts, should be used with NISSAN seat belts.
- Adults and children who can use the standard seat belt should not use an extender. Such unnecessary use could result in serious personal injury in the event of an accident.
- Never use seat belt extenders to install child restraints. If the child restraint is not secured properly, the child could be seriously injured in a collision or a sudden stop.

#### SEAT BELT MAINTENANCE

• To clean the seat belt webbing, apply a mild soap solution or any solution recommended for cleaning upholstery or carpets. Then wipe with a cloth and allow the seat belts to dry in the shade. Do not allow the seat belts to retract until they are completely drv.



#### **CHILD SAFETY**

- If dirt builds up in the shoulder belt guide of the seat belt anchors, the seat belts may retract slowly. Wipe the shoulder belt guide with a clean, dry cloth.
- Periodically check to see that the seat belt and the metal components, such as buckles, tongues, retractors, flexible wires and anchors, work properly. If loose parts, deterioration, cuts or other damage on the webbing is found, the entire seat belt assembly should be replaced.

### **A** WARNING

Do not allow children to play with the seat belts. Most seating positions are equipped with Automatic Locking Retractor (ALR) mode seat belts. If the seat belt becomes wrapped around a child's neck with the ALR mode activated, the child can be seriously injured or killed if the seat belt retracts and becomes tight. This can occur even if the vehicle is parked. Unbuckle the seat belt to release the child. If the seat belt can not be unbuckled or is already unbuckled, release the child by cutting the seat belt with a suitable tool (such as a knife or scissors) to release the seat belt.

# Children need adults to help protect them. They need to be properly restrained.

In addition to the general information in this manual, child safety information is available from many other sources, including doctors, teachers, government traffic safety offices, and community organizations. Every child is different, so be sure to learn the best way to transport your child.

There are three basic types of child restraint

#### systems:

- · Rear-facing child restraint
- Forward-facing child restraint
- Booster seat

The proper restraint depends on the child's size. Generally, infants up to about 1 year and less than 20 lbs (9 kg) should be placed in rearfacing child restraints. Forward-facing child restraints are available for children who outgrow rear-facing child restraints and are at least 1 year old. Booster seats are used to help position a vehicle lap/shoulder belt on a child who can no longer use a forward-facing child restraint.



Infants and children need special protection. The vehicle's seat belts may not fit them properly. The shoulder belt may come too close to the face or neck. The lap belt may not fit over their small hip bones. In an accident, an improperly fitting seat belt could cause serious or fatal injury. Always use appropriate child restraints.

All U.S. states and Canadian provinces or territories require the use of approved child restraints for infants and small children. See "Child restraints" (P.1-18).

A child restraint may be secured in the vehicle by using either the LATCH (Lower Anchors and Tethers for CHildren) system or with the vehicle seat belt. See "Child restraints" (P.1-18) for more information.

NISSAN recommends that all pre-teens and children be restrained in the rear seat. Studies show that children are safer when properly restrained in the rear seat than in the front seat.

This is especially important because your vehicle has a supplemental restraint system (Air bag system) for the front passenger. See "Supplemental restraint system" (P.1-38).

#### **INFANTS**

Infants up to at least 1 year old should be placed in a rear-facing child restraint. NISSAN recommends that infants be placed in child restraints that comply with Federal Motor Vehicle Safety Standards or Canadian Motor Vehicle Safety Standards. You should choose a child restraint that fits your vehicle and always follow the manufacturer's instructions for installation and use.

#### SMALL CHILDREN

Children that are over 1 year old and weigh at least 20 lbs (9 kg) should remain in a rear-facing child restraint as long as possible up to the height or weight limit of the child restraint. Children who outgrow the height or weight limit of the rear-facing child restraint and are at least 1 year old should be secured in a forward-facing child restraint with a harness. Refer to the manufacturer's instructions for minimum and maximum weight and height recommendations. NISSAN recommends that small children be placed in child restraints that comply with Federal Motor Vehicle Safety Standards or Canadian Motor Vehicle Safety Standards. You should choose a child restraint that fits your vehicle and always follow the manufacturer's instructions for installation and use.

#### LARGER CHILDREN

Children should remain in a forward-facing child restraint with a harness until they reach the maximum height or weight limit allowed by the child restraint manufacturer.

Once a child outgrows the height or weight limit of the harness-equipped forward-facing child restraint. NISSAN recommends that the child be placed in a commercially available booster seat to obtain proper seat belt fit. For a seat belt to fit properly, the booster seat should raise the child


so that the shoulder belt is properly positioned across the chest and the top, middle portion of the shoulder. The shoulder belt should not cross the neck or face and should not fall off the shoulder. The lap belt should lie snugly across the lower hips or upper thighs, not the abdomen.


A booster seat can only be used in seating positions that have a three-point type seat belt. The booster seat should fit the vehicle seat and have a label certifying that it complies with Federal Motor Vehicle Safety Standards or Canadian Motor Vehicle Safety Standards. Once the child has grown so the shoulder belt is no longer on or near the face and neck, and the lap belt can be positioned properly across the lower hips or upper thighs, use the seat belt without the booster seat.



Never let a child stand or kneel on any seat and do not allow a child in the cargo area. The child could be seriously injured or killed in a sudden stop or collision.

#### **CHILD RESTRAINTS**





PRECAUTIONS ON CHILD RE-STRAINTS

## **A** WARNING

- Failure to follow the warnings and instructions for proper use and installation of child restraints could result in serious injury or death of a child or other passengers in a sudden stop or collision:
  - The child restraint must be used and installed properly. Always follow all of the child restraint manufacturer's instructions for installation and use.
  - Infants and children should never be held on anyone's lap.
     Even the strongest adult cannot resist the forces of a collision.
  - Do not put a seat belt around both a child and another passenger.
  - NISSAN recommends that all child restraints be installed in the rear seat. Studies show that children are safer when properly restrained in the rear seat than

- in the front seat. If you must install a forward-facing child restraint in the front seat, see "Forward-facing child restraint installation using the seat belts" (P.1-30).
- Even with the NISSAN Advanced Air Bag System, never install a rear-facing child restraint in the front seat. An inflating air bag could seriously injure or kill a child. A rear-facing child restraint must only be used in the rear seat.
- Be sure to purchase a child restraint that will fit the child and vehicle. Some child restraints may not fit properly in your vehicle.
- Child restraint anchor points are designed to withstand loads from child restraints that are properly fitted.
- Never use the anchor points for adult seat belts or harnesses.
- A child restraint with a top tether strap should not be used in the front passenger seat.

- Keep seatbacks as upright as possible after fitting the child restraint.
- Infants and children should always be placed in an appropriate child restraint while in the vehicle.
- When the child restraint is not in use, keep it secured with the LATCH system or a seat belt. In a sudden stop or collision, loose objects can injure occupants or damage the vehicle.

## CAUTION

A child restraint in a closed vehicle can become very hot. Check the seating surface and buckles before placing a child in the child restraint.

This vehicle is equipped with a universal child restraint anchor system, referred to as the LATCH (Lower Anchors and Tethers for CHildren) system. Some child restraints include rigid or webbing-mounted attachments that can be connected to these anchors.

For details, see "Lower Anchors and Tethers for CHildren System (LATCH)" (P.1-20).


If you do not have a LATCH compatible child restraint, the vehicle seat belts can be used.

Several manufacturers offer child restraints for infants and small children of various sizes. When selecting any child restraint, keep the following points in mind:

- Choose only a restraint with a label certifying that it complies with Federal Motor Vehicle Safety Standard 213 or Canadian Motor Vehicle Safety Standard 213.
- Check the child restraint in your vehicle to be sure it is compatible with the vehicle's seat and seat belt system.
- If the child restraint is compatible with your vehicle, place your child in the child restraint and check the various adjustments to be sure the child restraint is compatible with your child. Choose a child restraint that is designed for your child's height and weight. Always follow all recommended procedures.
- If the combined weight of the child and child restraint is less than 65 lbs (29.5 kg), you may use either the LATCH anchors or the seat belt to install the child restraint (not both at the same time).

- If the combined weight of the child and child restraint is greater than 65 lbs (29.5 kg), use the vehicle's seat belt (not the lower anchors) to install the child restraint.
- Be sure to follow the child restraint manufacturer's instructions for installation.

All U.S. states and Canadian provinces or territories require that infants and small children be restrained in an approved child restraint at all times while the vehicle is being operated. Canadian law requires the top tether strap on forward-facing child restraints be secured to the designated anchor point on the vehicle.



Lower Anchors and Tethers for CHildren

System (LATCH) Your vehicle is equipped with special anchor

points that are used with LATCH (Lower Anchors and Tethers for CHildren) system compatible child restraints. This system may also be referred to as the ISOFIX or ISOFIX compatible system. With this system, you do not have to use a vehicle seat belt to secure the child restraint unless the combined weight of the child and child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and child restraint is greater than 65 lbs (29.5 kg), use the vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the

child restraint manufacturer's instructions for installation.

LATCH lower anchor




### **WARNING**

Failure to follow the warnings and instructions for proper use and installation of child restraints could result in serious injury or death of a child or other passengers in a sudden stop or collision:

- Attach LATCH system compatible child restraints only at the locations shown in the illustration.
- Do not secure a child restraint in the center rear seating position using the LATCH lower anchors. The child restraint will not be secured properly.
- Inspect the lower anchors by inserting your fingers into the lower anchor area. Feel to make sure there are no obstructions over the anchors such as seat belt webbing or seat cushion material. The child restraint will not be secured properly if the lower anchors are ob-

#### structed.


Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used to attach adult seat belts, or other items or equipment to the vehicle. Doing so could damage the child restraint anchorages. The child restraint will not be properly installed using the damaged anchorage, and a child could be seriously injured or killed in a collision.



LATCH lower anchor location

#### LATCH lower anchor location


The LATCH anchors are located at the rear of the seat cushion near the seatback. A label is attached to the seatback to help you locate the LATCH anchors.



LATCH webbing-mounted attachment

### Installing child restraint LATCH lower anchor attachments

LATCH compatible child restraints include two rigid or webbing-mounted attachments that can be connected to two anchors located at certain seating positions in your vehicle. With this system, you do not have to use a vehicle seat belt to secure the child restraint. Check your child restraint for a label stating that it is compatible with LATCH. This information may also be in the instructions provided by the child restraint manufacturer.



LATCH rigid attachment

When installing a child restraint, carefully read and follow the instructions in this manual and those supplied with the child restraint.


Top tether anchor

## WARNING

If the cargo cover (if so equipped) contacts the top tether strap when it is attached to the top tether anchor, remove the cargo cover from the vehicle or secure it on the cargo floor below its attachment location. If the cargo cover is not removed, it



- may damage the top tether strap during a collision. Your child could be seriously injured or killed in a collision if the child restraint top tether strap is damaged.
- Do not allow cargo to contact the top tether strap when it is attached to the top tether anchor. Properly secure the cargo so it does not contact the top tether strap. Cargo that is not properly secured or cargo that contacts the top tether strap may damage the top tether strap during a collision. Your child could be seriously injured or killed in a collision if the child restraint top tether strap is damaged.



Top tether anchor point locations



### **WARNING**

Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used to attach adult seat belts, or other items or equipment to the vehicle. Doing so could damage the child restraint anchorages. The child restraint will not be properly installed using the damaged anchorage, and a child could be seriously injured or killed

#### in a collision.

Anchor points are located on the back side of the seatbacks.

The child restraint top tether strap must be used when installing child restraints with the LATCH lower anchor attachments or seat belts.


If you have any questions when installing a top tether strap child restraint on the rear seat, consult a NISSAN dealer for details. REAR-FACING CHILD RESTRAINT IN-STALLATION USING LATCH

Refer to all Warnings and Cautions in the "Child safety" and "Child restraints" sections before installing a child restraint.

NISSAN does not recommend the use of the lower anchors if the combined weight of the child and the child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and the child restraint is greater than 65 lbs (29.5 kg), use the vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the child restraint manufacturer's instructions for installation.


Follow these steps to install a rear-facing child restraint using the LATCH system:


1. Position the child restraint on the seat. Always follow the child restraint manufacturer's instructions.



Rear-facing web-mounted — step 2


2. Secure the child restraint anchor attachments to the LATCH lower anchors. Check to make sure the LATCH attachment is properly attached to the lower anchors.





Rear-facing - step 3


3. For child restraints that are equipped with webbing-mounted attachments, remove any additional slack from the anchor attachments. Press downward and rearward firmly in the center of the child restraint with your hand to compress the vehicle seat cushion and seatback while tightening the webbing of the anchor attachments.



Rear-facing — step 4

4. After attaching the child restraint, test it before you place the child in it. Push it from side to side while holding the child restraint near the LATCH attachment path. The child restraint should not move more than 1 inch (25 mm), from side to side. Try to tug it forward and check to see if the LATCH attachment holds the restraint in place. If the restraint is not secure, tighten the LATCH attachment as necessary, or put the restraint in another seat and test it again. You may need to try a different child restraint or try installing by using the vehicle seat belt (if applicable). Not all child restraints fit in all types of vehicles.


 Check to make sure the child restraint is properly secured prior to each use. If the child restraint is loose, repeat steps 1 through 4.



REAR-FACING CHILD RESTRAINT IN-STALLATION USING THE SEAT BELTS

# **WARNING**

The three-point seat belt with Automatic Locking Retractor (ALR) must be used when installing a child restraint. Failure to use the ALR mode will result in the child restraint not being properly secured. The restraint could tip over or be loose and cause injury to a child in a sudden stop or collision. Also, it can change the operation of the front passenger air bag. See "Front passenger air bag and status light" (P.1-46).



Rear-facing - step 1

Refer to all Warnings and Cautions in the "Child safety" (P.1-16) and "Child restraints" (P.1-18) before installing a child restraint.


NISSAN does not recommend the use of the lower anchors if the combined weight of the child and the child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and the child restraint is greater than 65 lbs (29.5 kg), use the vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the child restraint manufacturer's instructions for installation.

Follow these steps to install a rear-facing child restraint using the vehicle seat belts in the rear




#### seats:

1. Child restraints for infants must be used in the rear-facing direction and therefore must not be used in the front seat. Position the child restraint on the seat. Always follow the restraint manufacturer's instructions.




Rear-facing - step 2

2. Route the seat belt tongue through the child restraint and insert it into the buckle until you hear and feel the latch engage. Be sure to follow the child restraint manufacturer's instructions for belt routing.




Rear-facing - step 3

3. Pull the shoulder belt until the belt is fully extended. At this time, the seat belt retractor is in the Automatic Locking Retractor (ALR) mode (child restraint mode). It reverts to the Emergency Locking Retractor (ELR) mode when the seat belt is fully retracted.




Rear-facing — step 4

4. Allow the seat belt to retract. Pull up on the shoulder belt to remove any slack in the belt.



Rear-facing — step 5

 Remove any additional slack from the seat belt; press downward and rearward firmly in the center of the child restraint to compress the vehicle seat cushion and seatback while pulling up on the seat belt.



Rear-facing - step 6

- 6. After attaching the child restraint, test it before you place the child in it. Push it from side to side while holding the child restraint near the seat belt path. The child restraint should not move more than 1 inch (25 mm), from side to side. Try to tug it forward and check to see if the belt holds the restraint in place. If the restraint is not secure, tighten the seat belt as necessary, or put the restraint in another seat and test it again. You may need to try a different child restraint. Not all child restraints fit in all types of vehicles.
- Check to make sure that the child restraint is properly secured prior to each use. If the

seat belt is not locked, repeat steps 1 through 6.

After the child restraint is removed and the seat belt fully retracted, the ALR mode (child restraint mode) is canceled.


### FORWARD-FACING CHILD RE-STRAINT INSTALLATION USING LATCH

Refer to all Warnings and Cautions in the "Child safety" and "Child restraints" sections before installing a child restraint.

NISSAN does not recommend the use of the lower anchors if the combined weight of the child and the child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and the child restraint is greater than 65 lbs (29.5 kg), use the vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the child restraint manufacturer's instructions for installation.

Follow these steps to install a forward-facing child restraint using the LATCH system:


1. Position the child restraint on the seat. Always follow the child restraint manufacturer's instructions.



Forward-facing web-mounted - step 2

2. Secure the child restraint anchor attachments to the LATCH lower anchors. Check to make sure the LATCH attachment is properly attached to the lower anchors.

If the child restraint is equipped with a top tether strap, route the top tether strap and secure the tether strap to the tether anchor point. See "Installing top tether strap" (P.1-30). Do not install child restraints that require the use of a top tether strap in seating positions that do not have a top tether anchor.




Forward-facing rigid-mounted - step 2

3. The back of the child restraint should be secured against the vehicle seatback.

If necessary, adjust or remove the head restraint to obtain the correct child restraint fit. If the head restraint is removed, store it in a secure place. Be sure to reinstall the head restraint when the child restraint is removed. See "Head restraints/headrests" (P.1-5) for head restraint adjustment information.


If the seating position does not have a head restraint and it is interfering with the proper child restraint fit, try another seating position or a different child restraint.





Forward-facing - step 4


- 4. For child restraints that are equipped with webbing-mounted attachments, remove any additional slack from the anchor attachments. Press downward and rearward firmly in the center of the child restraint with your knee to compress the vehicle seat cushion and seatback while tightening the webbing of the anchor attachments.
- 5. Tighten the tether strap according to the manufacturer's instructions to remove any slack.



Forward-facing - step 6

- 6. After attaching the child restraint, test it before you place the child in it. Push it from side to side while holding the child restraint near the LATCH attachment path. The child restraint should not move more than 1 inch (25 mm), from side to side. Try to tug it forward and check to see if the LATCH attachment holds the restraint in place. If the restraint is not secure, tighten the LATCH attachment as necessary, or put the restraint in another seat and test it again. You may need to try a different child restraint. Not all child restraints fit in all types of vehicles.
- 7. Check to make sure the child restraint is properly secured prior to each use. If the

child restraint is loose, repeat steps 1 through 6.



Installing top tether strap



### WARNING

Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used to attach adult seat belts, or other items or equipment to the vehicle. Doing so could damage the child restraint anchorages. The child restraint will not be properly installed using the damaged anchorage, and a child could be seriously injured or killed

#### in a collision.

The child restraint top tether strap must be used when installing the child restraint with the LATCH lower anchor attachments.

First, secure the child restraint with the LATCH lower anchors (rear outboard seat positions only).

 Remove the head restraint and store it in a secure place. Be sure to reinstall the head restraint when the child restraint is removed (rear outboard seat positions).

See "Head restraints/headrests" (P.1-5) for head restraint adjustment, removal and installation information.

Position the top tether strap over the top of the seatback.


- Secure the top tether strap to the tether anchor point on the back of the seatback behind the child restraint.
- Refer to the appropriate child restraint installation procedure steps in this section before tightening the tether strap.

If you have any questions when installing a top tether strap, consult your NISSAN dealer for details. FORWARD-FACING CHILD RESTRAINT INSTALLATION USING THE SEAT BELTS



### WARNING

The three-point seat belt with Automatic Locking Retractor (ALR) must be used when installing a child restraint. Failure to use the ALR mode will result in the child restraint not being properly secured. The restraint could tip over or be loose and cause injury to a child in a sudden stop or collision. Also, it can change the operation of the front passenger air bag. See "Front passenger air bag and status light" (P.1-46).



Forward-facing (front passenger seat) - step 1

Refer to all Warnings and Cautions in the "Child safety" and "Child restraints" sections before installing a child restraint.

NISSAN does not recommend the use of the lower anchors if the combined weight of the child and the child restraint exceeds 65 lbs (29.5 kg). If the combined weight of the child and the child restraint is greater than 65 lbs (29.5 kg), use the vehicle's seat belt (not the lower anchors) to install the child restraint. Be sure to follow the child restraint manufacturer's instructions for installation.


Follow these steps to install a forward-facing child restraint using the vehicle seat belt in the rear seats or in the front passenger seat:

- 1. If you must install a child restraint in the front seat, it should be placed in a forward-facing direction only. Move the seat to the rearmost position. Child restraints for infants must be used in the rear-facing direction and, therefore, must not be used in the front seat.
- 2. Position the child restraint on the seat. Always follow the child restraint manufacturer's instructions.

The back of the child restraint should be secured against the vehicle seatback.


If necessary, adjust or remove the head restraint to obtain the correct child restraint fit. If the head restraint is removed, store it in a secure place. Be sure to reinstall the head restraint when the child restraint is removed. See "Head restraints/headrests" (P.1-5) for head restraint adjustment, removal and installation information.

If the seating position does not have an adjustable head restraint and it is interfering with the proper child restraint fit, try another seating position or a different child restraint.




3. Route the seat belt tongue through the child restraint and insert it into the buckle until you hear and feel the latch engage. Be sure to follow the child restraint manufacturer's instructions for belt routing.

If the child restraint is equipped with a top tether strap, route the top tether strap and secure the tether strap to the tether anchor point (rear seat installation only). See "Installing top tether strap" (P.1-34). Do not install child restraints that require the use of a top tether strap in seating positions that do not have a top tether anchor.




Forward-facing - step 4

4. Pull the shoulder belt until the belt is fully extended. At this time, the seat belt retractor is in the Automatic Locking Retractor (ALR) mode (child restraint mode). It reverts to Emergency Locking Retractor (ELR) mode when the seat belt is fully retracted.



Forward-facing - step 5

5. Allow the seat belt to retract. Pull up on the shoulder belt to remove any slack in the belt.



Forward-facing - step 6

- Remove any additional slack from the seat belt; press downward and rearward firmly in the center of the child restraint with your knee to compress the vehicle seat cushion and seatback while pulling up on the seat belt.
- 7. Tighten the tether strap according to the manufacturer's instructions to remove any slack.



Forward-facing - step 8

- 8. After attaching the child restraint, test it before you place the child in it. Push it from side to side while holding the child restraint near the seat belt path. The child restraint should not move more than 1 inch (25 mm), from side to side. Try to tug it forward and check to see if the belt holds the restraint in place. If the restraint is not secure, tighten the seat belt as necessary, or put the restraint in another seat and test it again. You may need to try a different child restraint. Not all child restraints fit in all types of vehicles.
- 9. Check to make sure the child restraint is properly secured prior to each use. If the

seat belt is not locked, repeat steps 2 through 8.

# **PASS** AIR BAG




SSS1135

#### Forward-facing — step 10

10. If the child restraint is installed in the front passenger seat, place the ignition switch in the ON position. The front passenger air bag status light & should illuminate. If this light is not illuminated, see "Front passenger air bag and status light" (P.1-46). Move the child restraint to another seating position. Have the system checked by a NISSAN dealer.

After the child restraint is removed and the seat belt is fully retracted, the ALR mode (child restraint mode) is canceled.



Installing top tether strap



Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used to attach adult seat belts, or other items or equipment to the vehicle. Doing so could damage the child restraint anchorages. The child restraint will not be properly installed using the damaged anchorage, and a child could be seriously injured or killed

#### in a collision.

The child restraint top tether strap must be used when installing the child restraint with the seat belts.

First, secure the child restraint with the seat belt.

 Remove the head restraint and store it in a secure place. Be sure to reinstall the head restraint when the child restraint is removed (rear outboard seat positions).

See "Head restraints/headrests" (P.1-5) for head restraint adjustment, removal and installation information.

Position the top tether strap over the top of the seatback.

- Secure the top tether strap to the tether anchor point on the back of the seatback behind the child restraint.
- Refer to the appropriate child restraint installation procedure steps in this section before tightening the tether strap.

If you have any questions when installing a top tether strap, consult your NISSAN dealer for details.

#### **BOOSTER SEATS**


Precautions on booster seats



If a booster seat and seat belt are not used properly, the risk of a child being injured in a sudden stop or collision greatly increases:


- Make sure the shoulder portion of the belt is away from the child's face and neck and the lap portion of the belt does not cross the stomach.
- Make sure the shoulder belt is not behind the child or under the child's arm.
- A booster seat must only be installed in a seating position that has a lap/shoulder belt.






Booster seats of various sizes are offered by several manufacturers. When selecting any booster seat, keep the following points in mind:

- Choose only a booster seat with a label certifying that it complies with Federal Motor Vehicle Safety Standard 213 or Canadian Motor Vehicle Safety Standard 213.
- Check the booster seat in your vehicle to be sure it is compatible with the vehicle's seat and seat belt system.



- Make sure the child's head will be properly supported by the booster seat or vehicle seat. The seatback must be at or above the center of the child's ears. For example, if a low back booster seat (1) is chosen, the vehicle seatback must be at or above the center of the child's ears. If the seatback is lower than the center of the child's ears, a high back booster seat (2) should be used.
- If the booster seat is compatible with your vehicle, place your child in the booster seat and check the various adjustments to be sure the booster seat is compatible with your child. Always follow all recommended procedures.



All U.S. states and Canadian provinces or territories require that infants and small children be restrained in an approved child restraint at all times while the vehicle is being operated.

The instructions in this section apply to booster seat installation in the rear seats or the front passenger seat.

Booster seat installation




Do not use the lap/shoulder belt Automatic Locking Retractor (ALR) mode


#### when using a booster seat with the seat belts.

Refer to all Warnings and Cautions in the "Child safety", "Child restraints" and "Booster seats" sections earlier in this section before installing a child restraint.

Follow these steps to install a booster seat in the rear seat or in the front passenger seat:



- 1. If you must install a booster seat in the front seat, move the seat to the rearmost position.
- 2. Position the booster seat on the seat. Only place it in a forward-facing direction. Always follow the booster seat manufacturer's instructions.



Front passenger position

The booster seat should be positioned on the vehicle seat so that it is stable.

If necessary, adjust or remove the head restraint to obtain the correct booster seat fit. If the head restraint is removed, store it in a secure place. Be sure to reinstall the head restraint when the booster seat is removed. See "Head restraints/headrests" (P.1-5) for head restraint adjustment, removal and installation information.

If the seating position does not have a head restraint and it is interfering with the proper booster seat fit, try another seating position or a different booster seat.



- 4. Position the lap portion of the seat belt low and snug on the child's hips. Be sure to follow the booster seat manufacturer's instructions for adjusting the seat belt routing.
- 5. Pull the shoulder belt portion of the seat belt toward the retractor to take up extra slack. Be sure the shoulder belt is positioned across the top, middle portion of the child's shoulder. Be sure to follow the booster seat. manufacturer's instructions for adjusting the seat belt routing.
- 6. Follow the warnings, cautions and instructions for properly fastening a seat belt shown in "Seat belts" (P.1-10).

# **PASS AIR BAG**



SSS1135

7. If the booster seat is installed in the front passenger seat, place the ignition switch in the ON position. The front passenger air bag status light 💃 may or may not illuminate depending on the size of the child and the type of booster seat used. See "Front passenger air bag and status light" (P.1-46).

#### SUPPLEMENTAL RESTRAINT SYSTEM

#### PRECAUTIONS ON SUPPLEMENTAL RESTRAINT SYSTEM

This Supplemental Restraint System (SRS) section contains important information concerning the following systems:

- Driver and passenger supplemental frontimpact air bag (NISSAN Advanced Air Bag System)
- Front seat-mounted side-impact supplemental air bag
- Roof-mounted curtain side-impact supplemental air bag
- Seat belt with pretensioner

Supplemental front-impact air bag system: The NISSAN Advanced Air Bag System can help cushion the impact force to the head and chest of the driver and front passenger in certain frontal collisions.


Front seat-mounted side-impact supplemental air bag system: This system can help cushion the impact force to the chest and pelvic area of the driver and front passenger in certain side impact collisions. The side air bag is designed to inflate on the side where the vehicle is impacted.

Roof-mounted curtain side-impact supplemental air bag system: This system can help cushion the impact force to the head of occupants in front and rear outboard seating positions in certain side impact collisions. The curtain air bags are designed to inflate on the side where the vehicle is impacted.

These supplemental restraint systems are designed to **supplement** the crash protection provided by the driver and passenger seat belts and are not a substitute for them. Seat belts should always be correctly worn and the occupant seated a suitable distance away from the steering wheel, instrument panel and door finishers. (See "Seat belts" (P.1-10) for instructions and precautions on seat belt usage.)

The supplemental air bags operate only when the ignition switch is in the ON position.

After the ignition is placed in the ON position, the supplemental air bag warning light illuminates. The supplemental air bag warning light will turn off after about 7 seconds if the systems are operational.





## **A** WARNING


- The front air bags ordinarily will not inflate in the event of a side impact, rear impact, rollover, or lower severity frontal collision. Always wear your seat belts to help reduce the risk or severity of injury in various kinds of accidents.
- The front passenger air bag will not inflate if the passenger air bag status light is lit or if the front passenger seat is unoccupied. See "Front passenger air bag and status light" (P.1-46).
- The seat belts and the front air bags are most effective when you are sitting well back and upright in the seat with both feet on the floor. The front air bags inflate with great force. Even with the NISSAN Advanced Air Bag System, if you are unrestrained, leaning forward, sitting sideways or out of position in any way, you are at greater risk of injury or death in a crash. You may also receive serious or fatal injuries from the front air bag if you are up against it when it inflates. Always sit


- back against the seatback and as far-away as practical from the steering wheel or instrument panel. Always use the seat belts.
- The driver and front passenger seat belt buckles are equipped with sensors that detect if the seat belts are fastened. The Advanced Air Bag System monitors the severity of a collision and seat belt usage then inflates the air bags. Failure to properly wear seat belts can increase the risk or severity of injury in an accident.
- The front passenger seat is equipped with occupant classification sensors (weight sensors) that turn the front passenger air bag OFF under some conditions. This sensor is only used in this seat. Failure to be properly seated and wearing the seat belt can increase the risk or severity of injury in an accident. See "Front passenger air bag and status light" (P.1-46).
- Keep hands on the outside of the steering wheel. Placing them inside the steering wheel rim could increase the risk that they are injured


if the front air bag inflates.

















## **WARNING**


- Never let children ride unrestrained or extend their hands or face out of the window. Do not attempt to hold them in your lap or arms. Some examples of dangerous riding positions are shown in the illustrations.
- Children may be severely injured or killed when the front air bags, side air bags or curtain air bags inflate if they are not properly restrained. Pre-teens and children should be properly restrained in the rear seat, if possible.
- Even with the NISSAN Advanced Air Bag System, never install a rearfacing child restraint in the front seat. An inflating front air bag could seriously injure or kill your child. See "Child restraints" (P.1-18) for details.








Do not lean against doors or windows.






# **A** WARNING

Front seat-mounted side-impact supplemental air bags and roof-mounted curtain side-impact supplemental air bags:

 The side air bags and curtain air bags ordinarily will not inflate in the event of a frontal impact, rear impact, rollover or lower severity side collision. Always wear your seat belts to help reduce the risk or severity of injury in various kinds of accidents.

- The seat belts, the side air bags and curtain air bags are most effective when you are sitting well back and upright in the seat. The side air bag and curtain air bag inflate with great force. Do not allow anyone to place their hand, leg or face near the side air bag on the side of the seatback of the front seat or near the side roof rails. Do not allow anyone sitting in the front seats or rear outboard seats to extend their hand out of the window or lean against the door. Some examples of dangerous riding positions are shown in the previous illustrations.
- When sitting in the rear seat, do not hold onto the seatback of the front seat. If the side air bag inflates, you may be seriously injured. Be especially careful with children, who should always be properly restrained. Some examples of dangerous riding positions are shown in the illustrations.
- Do not use seat covers on the front seatbacks. They may interfere with side air bag inflation.



- Crash zone sensor
- 2. Supplemental front-impact air bag modules
- Front seat-mounted side-impact supplemental air bag modules
- Occupant classification sensors (weight sensors)
- 5. Occupant classification system control unit

- Roof-mounted curtain side-impact supplemental air bag inflators
- Roof-mounted curtain side-impact supplemental air bags modules
- 8. Seat belt with pretensioners
- 9. Satellite sensors
- Air bag Control Unit (ACU)

# NISSAN ADVANCED AIR BAG SYSTEM (front seats)



### **WARNING**

To ensure proper operation of the passenger's advanced air bag system, please observe the following items.

- Do not allow a passenger in the rear seat to push or pull on the seatback pocket.
- Do not place heavy loads heavier than 9 lbs. (4 kg) on the seatback, head restraint or in the seatback pocket.
- Do not store luggage behind the seat that can press into the seatback.
- Confirm the operating condition with the front passenger air bag status light.
- If you notice that the front passenger air bag status light is not operating, please take your vehicle to your NISSAN dealer to check the occupant classification system.

-44 Safety — Seats, seat belts and supplemental restraint system



Until you have confirmed with your dealer that your passenger seat occupant classification system is working properly, position the occupants in the rear seating positions.

This vehicle is equipped with the NISSAN Advanced Air Bag System for the driver and front passenger seats. This system is designed to meet certification requirements under U.S. regulations. It is also permitted in Canada. All of the information, cautions and warnings in this manual still apply and must be followed.

The driver supplemental front-impact air bag is located in the center of the steering wheel. The passenger supplemental front-impact air bag is mounted in the instrument panel above the glove box. The front air bags are designed to inflate in higher severity frontal collisions, although they may inflate if the forces in another type of collision are similar to those of a higher severity frontal impact. They may not inflate in certain frontal collisions. Vehicle damage (or lack of it) is not always an indication of proper front air bag operation.

The NISSAN Advanced Air Bag System has dual stage air bag inflators. The system monitors information from the Air bag Control Unit (ACU), seat belt buckle sensors and the occupant classification sensors (weight sensors). Inflator operation is based on the severity of a collision and seat belt usage for the driver. For the front passenger, the occupant classification sensors are also monitored. Based on information from the sensors, only one front air bag may inflate in a crash, depending on the crash severity and whether the front occupants are belted or unbelted. Additionally, the front passenger air bag may be automatically turned OFF under some conditions, depending on the information provided by the occupant classification sensors. If the front passenger air bag is OFF, the passenger air bag status light will be illuminated (if the seat is unoccupied, the light will not be illuminated, but the air bag will be off). (See "Front passenger air bag and status light" (P.1-46) for further details.) One front air bag inflating does not indicate improper performance of the system.

If you have any questions about your air bag system, contact NISSAN or a NISSAN dealer, If you are considering modification of your vehicle due to a disability, you may also contact NISSAN. Contact information is contained in the front of this Owner's Manual.

When a front air bag inflates, a fairly loud noise may be heard, followed by release of smoke. This smoke is not harmful and does not indicate

a fire. Care should be taken not to inhale it, as it may cause irritation and choking. Those with a history of a breathing condition should get fresh air promptly.

Front air bags, along with the use of seat belts, help to cushion the impact force on the head and chest of the front occupants. They can help save lives and reduce serious injuries. However, an inflating front air bag may cause facial abrasions or other injuries. Front air bags do not provide restraint to the lower body.

Even with NISSAN Advanced Air Bags, seat belts should be correctly worn and the driver and passenger seated upright as far as practical away from the steering wheel or instrument panel. The front air bags inflate quickly in order to help protect the front occupants. Because of this, the force of the front air bag inflating can increase the risk of injury if the occupant is too close to, or is against, the air bag module during inflation.

The front air bags deflate quickly after a collision.

The front air bags operate only when the ignition switch is in the ON position.

After the ignition is placed in the ON position, the supplemental air bag warning light illuminates. The supplemental air bag warning light will turn off after about 7 seconds if the system is operational.

# PASS AIR BAG



SSS1135

Front passenger air bag status light

Front passenger air bag and status light

## **A** WARNING

The front passenger air bag is designed to automatically turn OFF under some conditions. Read this section carefully to learn how it operates. Proper use of the seat, seat belt and child restraints is necessary for most effective protection. Failure to follow all instructions in this manual concerning the use of seats, seat belts and child restraints can increase the risk or severity of injury in

#### an accident.

### Status light:

The front passenger air bag status light  $\frac{1}{5}$  is located on the instrument panel. After the ignition switch is placed in the "ON" position, the front passenger air bag status light illuminates for about 7 seconds and then turns off or illuminates depending on the front passenger seat occupied status. The light operates as follows:

- Unoccupied passenger seat: The light is OFF and the front passenger air bag is OFF and will not inflate in a crash.
- Passenger's seat occupied by a small adult, child or child restraint as outlined in this section: The light illuminates to indicate that the front passenger air bag is OFF and will not inflate in a crash.
- Occupied passenger seat and the passenger meets the conditions outlined in this section: The ½ light is OFF to indicate that the front passenger air bag is operational.

#### Front passenger air bag:

The front passenger air bag is designed to automatically turn OFF when the vehicle is operated under some conditions as described below as permitted by U.S. regulations. If the front passenger air bag is OFF, it will not inflate in a crash. The driver air bag and other air bags in your vehicle are not part of this system.

The purpose of the regulation is to help reduce the risk of injury or death from an inflating air bag to certain front passenger seat occupants, such as children, by requiring the air bag to be automatically turned OFF.

The occupant classification sensors (weight sensors) are on the seat cushion frame under the front passenger seat and are designed to detect an occupant and objects on the seat. For example, if a child is in the front passenger seat, the Advanced Air Bag System is designed to turn the passenger air bag OFF in accordance with the regulations. Also, if a child restraint of the type specified in the regulations is on the seat, the occupant classification sensors can detect it and cause the air bag to turn OFF.

Front passenger seat adult occupants who are properly seated and using the seat belt as outlined in this manual should not cause the passenger air bag to be automatically turned OFF. For small adults it may be turned OFF, however, if the occupant does not sit in the seat properly (for example, by not sitting upright, by sitting on an edge of the seat, or by otherwise being out of position), this could cause the

sensors to turn the air bag OFF. Always be sure to be seated and wearing the seat belt properly for the most effective protection by the seat belt and supplemental air bag.

NISSAN recommends that pre-teens and children be properly restrained in a rear seat. NISSAN also recommends that appropriate child restraints and booster seats be properly installed in a rear seat. If this is not possible, the occupant classification sensors are designed to operate as described above to turn the front passenger air bag OFF for specified child restraints. Failing to properly secure child restraints and to use the Automatic Locking Retractor (ALR) mode (child restraint mode) may allow the restraint to tip or move in an accident or sudden stop. This can also result in the passenger air bag inflating in a crash instead of being OFF. (See "Child restraints" (P.1-18) for proper use and installation.)

If the front passenger seat is not occupied, the passenger air bag is designed not to inflate in a crash. However, heavy objects placed on the seat could result in air bag inflation, because of the object being detected by the occupant classification sensors. Other conditions could also result in air bag inflation, such as if a child is standing on the seat, or if two children are on the seat, contrary to the instructions in this manual. Always be sure that you and all vehicle occupants are seated and restrained properly.

Using the passenger air bag status light, you can monitor when the front passenger air bag is automatically turned OFF with the seat occupied. The light will not illuminate when the front passenger seat is unoccupied.

If an adult occupant is in the seat but the passenger air bag status light is illuminated (indicating that the air bag is OFF), it could be that the person is a small adult, or is not sitting on the seat properly.

If a child restraint must be used in the front seat. the passenger air bag status light may or may not be illuminated, depending on the size of the child and the type of child restraint being used. If the air bag status light is not illuminated (indicating that the air bag might inflate in a crash), it could be that the child restraint or seat belt is not being used properly. Make sure that the child restraint is installed properly, the seat belt is used properly and the occupant is positioned properly. If the air bag status light is not illuminated, reposition the occupant or child restraint in a rear seat.

If the passenger air bag status light will not illuminate even though you believe that the child restraint, the seat belts and the occupant are properly positioned, the system may be sensing an unoccupied seat (in which case the air bag is

OFF). Your NISSAN dealer can check that the system is OFF by using a special tool. However, until you have confirmed with your dealer that your air bag is working properly, reposition the occupant or child restraint in a rear seat.

The air bag system and passenger air bag status light will take a few seconds to register a change in the passenger seat status. However, if the seat becomes unoccupied, the air bag status light will remain off.

If a malfunction occurs in the front passenger air bag system, the supplemental air bag warning light 🖈 , located in the meter and gauges area. will blink. Have the system checked by a NISSAN dealer.

Other supplemental front-impact air bag precautions

### WARNING

Do not place any objects on the steering wheel pad or on the instrument panel. Also, do not place any objects between any occupant and the steering wheel or instrument panel. Such objects may become dangerous projectiles and cause injury if the front air bags inflate.


- Do not place objects with sharp edges on the seat. Also, do not place heavy objects on the seat that will leave permanent impressions in the seat. Such objects can damage the seat or occupant classification sensors (weight sensors). This can affect the operation of the air bag system and result in serious personal injury.
- Do not use water or acidic cleaners (hot steam cleaners) on the seat.
   This can damage the seat or occupant classification sensors. This can also affect the operation of the air bag system and result in serious personal injury.
- Immediately after inflation, several front air bag system components will be hot. Do not touch them; you may severely burn yourself.
- No unauthorized changes should be made to any components or wiring of the supplemental air bag system.
   This is to prevent accidental inflation of the supplemental air bag or damage to the supplemental air bag system.

- Do not make unauthorized changes to your vehicle's electrical system, suspension system or front end structure. This could affect proper operation of the front air bag system.
- Tampering with the front air bag system may result in serious personal injury. Tampering includes changes to the steering wheel and the instrument panel assembly by placing material over the steering wheel pad and above the instrument panel or by installing additional trim material around the air bag system.
- Removing or modifying the front passenger seat may affect the function of the air bag system and result in serious personal injury.
- Modifying or tampering with the front passenger seat may result in serious personal injury. For example, do not change the front seats by placing material on the seat cushion or by installing additional trim material, such as seat covers, on the seat that is not specifically designed to assure proper air bag operation. Additionally, do not stow any ob-

- jects under the front passenger seat or the seat cushion and seatback. Such objects may interfere with the proper operation of the occupant classification sensors.
- No unauthorized changes should be made to any components or wiring of the seat belt system. This may affect the front air bag system. Tampering with the seat belt system may result in serious personal injury.
- Work on and around the front air bag system should be done by a NISSAN dealer. Installation of electrical equipment should also be done by a NISSAN dealer. The Supplemental Restraint System (SRS) wiring harnesses\* should not be modified or disconnected. Unauthorized electrical test equipment and probing devices should not be used on the air bag system.
- A cracked windshield should be replaced immediately by a qualified repair facility. A cracked windshield could affect the function of the supplemental air bag system.

#### \*The SRS wiring harness connectors are vellow and orange for easy identification.

When selling your vehicle, we request that you inform the buyer about the front air bag system and guide the buyer to the appropriate sections in this Owner's Manual.



FRONT SEAT-MOUNTED SIDE-IM-PACT SUPPLEMENTAL AIR BAG AND ROOF-MOUNTED CURTAIN SIDE-IM-PACT SUPPLEMENTAL AIR BAG SYS-**TEMS** 

The side air bags are located in the outside of the seatback of the front seats. The curtain air bags are located in the side roof rails. All of the information, cautions and warnings in this manual still apply and must be followed. The side air bags and curtain air bags are designed to inflate in higher severity side collisions, although they may inflate if the forces in another type of collision are similar to those of a higher severity side impact. They are designed

to inflate on the side where the vehicle is impacted. They may not inflate in certain side collisions on the side where the vehicle is impacted.

Vehicle damage (or lack of it) is not always an indication of proper side air bag and curtain air bag operation.

When the side air bags and curtain air bags inflate, a fairly loud noise may be heard, followed by release of smoke. This smoke is not harmful and does not indicate a fire. Care should be taken not to inhale it, as it may cause irritation and choking. Those with a history of a breathing condition should get fresh air promptly.

Side air bags, along with the use of seat belts, help to cushion the impact force on the chest and pelvic area of the front occupants. Curtain air bags help to cushion the impact force to the head of occupants in the front and rear outboard seating positions. They can help save lives and reduce serious injuries. However, side air bags and curtain air bags may cause abrasions or other injuries. Side air bags and curtain air bags do not provide restraint to the lower body.

The seat belts should be correctly worn and the driver and passenger seated upright as far as practical away from the side air bags. Rear seat passengers should be seated as far away as practical from the door finishers and side roof rails. The side air bags and curtain air bags inflate quickly in order to help protect the occupants in the outboard seating positions. Because of this, the force of the side air bags and curtain air bags inflating can increase the risk of injury if the occupant is too close to, or is against, these air bag modules during inflation. The side air bags and curtain air bags will remain inflated for a short period of time.

The side air bags and curtain air bags operate only when the ignition switch is in the ON position.

After turning the ignition switch to the ON position, the supplemental air bag warning light illuminates. The supplemental air bag warning light will turn off after about 7 seconds if the systems are operational.

### **A** WARNING

 Do not place any objects near the seatback of the front seats. Also, do not place any objects (an umbrella, bag, etc.) between the front door finisher and the front seat. Such objects may become dangerous projectiles and cause injury if a side air bag inflates.

- Right after inflation, several side air bag and curtain air bag system components will be hot. Do not touch them; you may severely burn yourself.
- No unauthorized changes should be made to any components or wiring of the side air bag and curtain air bag systems. This is to prevent damage to or accidental inflation of the side air bag and curtain air bag systems.
- Do not make unauthorized changes to your vehicle's electrical system, suspension system or side panel.
   This could affect proper operation of the side air bag and curtain air bag systems.
- Tampering with the side air bag system may result in serious personal injury. For example, do not change the front seats by placing material near the seatbacks or by installing additional trim material, such as seat covers, around the side air bag.
- Work around and on the side air bag and curtain air bag systems should be done by a NISSAN dealer. In-

stallation of electrical equipment should also be done by a NISSAN dealer. The Supplemental Restraint System (SRS) wiring harnesses\* should not be modified or disconnected. Unauthorized electrical test equipment and probing devices should not be used on the side air bag and curtain supplemental air bag systems.

# \*The SRS wiring harness connectors are yellow and orange for easy identification.

When selling your vehicle, we request that you inform the buyer about the side air bag and curtain air bag systems and guide the buyer to the appropriate sections in this Owner's Manual.

SEAT BELTS WITH PRETENSIONERS (front seats)

# **A** WARNING

- The pretensioners cannot be reused after activation. They must be replaced together with the retractor and buckle as a unit.
- If the vehicle becomes involved in a collision but a pretensioner is not

activated, be sure to have the pretensioner system checked and, if necessary, replaced by a NISSAN dealer.

- No unauthorized changes should be made to any components or wiring of the pretensioner system. This is to prevent damage to or accidental activation of the pretensioners. Tampering with the pretensioner system may result in serious personal injury.
- Work around and on the pretensioner system should be done by a NISSAN dealer. Installation of electrical equipment should also be done by a NISSAN dealer. Unauthorized electrical test equipment and probing devices should not be used on the pretensioner system.
- If you need to dispose of a pretensioner or scrap the vehicle, contact a NISSAN dealer. Correct pretensioner disposal procedures are set forth in the appropriate NISSAN Service Manual, Incorrect disposal procedures could cause personal injury.

The pretensioner system may activate with the supplemental air bag system in certain types of collisions. Working with the seat belt retractor, it helps tighten the seat belt when the vehicle becomes involved in certain types of collisions, helping to restrain front seat occupants.


The pretensioner is encased with the seat belt retractor. These seat belts are used the same way as conventional seat belts.

When a pretensioner activates, smoke is released and a loud noise may be heard. The smoke is not harmful and does not indicate a fire. Care should be taken not to inhale it, as it may cause irritation and choking. Those with a history of a breathing condition should get fresh air promptly.

After pretensioner activation, load limiters allow the seat belt to release webbing (if necessary) to reduce forces against the chest.

The supplemental air bag warning light \* is used to indicate malfunctions in the pretensioner system. See "Supplemental air bag warning light" (P.1-52). If the operation of the supplemental air bag warning light indicates there is a malfunction, have the system checked by a NISSAN dealer.

When selling your vehicle, we request that you inform the buyer about the pretensioner system and guide the buyer to the appropriate sections in this Owner's Manual.



### SUPPLEMENTAL AIR BAG WARNING LABELS

Warning labels about the supplemental frontimpact air bag system are placed in the vehicle as shown in the illustration.

### (1) SRS air bag

The warning labels are located on the surface of the sun visors.



### SUPPLEMENTAL AIR BAG WARNING LIGHT

The supplemental air bag warning light, displaying *p* in the instrument panel, monitors the circuits for the air bag systems, pretensioners and all related wiring.

When the ignition switch is in the ON position, the supplemental air bag warning light illuminates for about 7 seconds and then turns off. This means the system is operational.

If any of the following conditions occur, the air bag and/or pretensioner systems need servicing:

- The supplemental air bag warning light remains on after approximately 7 seconds.
- The supplemental air bag warning light flashes intermittently.
- The supplemental air bag warning light does not come on at all.

Under these conditions, the air bag and/or pretensioner systems may not operate properly. They must be checked and repaired. Take your vehicle to the nearest NISSAN dealer.



If the supplemental air bag warning light is on, it could mean that the front air bag, side air bag, curtain air bag and/or pretensioner systems will not operate in an accident. To help avoid injury to yourself or others, have your vehicle checked by a NISSAN dealer as soon as possible.

### REPAIR AND REPLACEMENT PRO-**CEDURE**

The front air bags, side air bags, curtain air bags and pretensioners are designed to activate on a one-time-only basis. As a reminder, unless it is damaged, the supplemental air bag warning light will remain illuminated after inflation has oc-



curred. Repair and replacement of these systems should be done only by a NISSAN dealer. When maintenance work is required on the vehicle, the front air bags, side air bags, curtain air bags and pretensioners and related parts should be pointed out to the person performing the maintenance. The ignition switch should always be in the LOCK position when working under the hood or inside the vehicle.

### **WARNING**

- Once a front air bag, side air bag or curtain air bag has inflated, the air bag module will not function again and must be replaced. Additionally, the activated pretensioners must also be replaced. The air bag module and pretensioner should be replaced by a NISSAN dealer. The air bag modules and pretensioner system cannot be repaired.
- The front air bag, side air bag and curtain air bag systems, and pretensioner system should be inspected by a NISSAN dealer if there is any damage to the front end or side portion of the vehicle.

If you need to dispose of a supplemental air bag or pretensioner or scrap the vehicle, contact a NISSAN dealer. Correct supplemental air bag and pretensioner system disposal procedures are set forth in the appropriate NISSAN Service Manual. Incorrect disposal procedures could cause personal injury.

### **MEMO**

# 2 Instruments and controls

| Cockpit   |      |
|---|------|
| Instrument panel                                  | 2-4  |
| Meters and gauges                                 | 2-5  |
| Speedometer and odometer                          | 2-6  |
| Tachometer  | 2-8  |
| Engine coolant temperature gauge                  | 2-8  |
| Fuel gauge  | 2-9  |
| Vehicle information display                       | 2-9  |
| Outside air temperature                           | 2-10 |
| Continuously Variable Transmission (CVT) position |      |
| indicator (if so equipped)                        | 2-10 |
| Trip computer                                     | 2-10 |
| Warning/indicator lights and audible reminders    | 2-12 |
| Checking bulbs                                    | 2-13 |
| Warning lights                                    | 2-13 |
| Indicator lights                                  | 2-17 |
| Audible reminders                                 | 2-19 |
| Integrated control system (if so equipped)        | 2-21 |
| Drive mode  | 2-21 |
| Setup function                                    | 2-22 |
|   | 2-27 |
| Eco information                                   | 2-28 |


| Security systems                                | 2-2  |
|---|------|
| Vehicle Security System                         | 2-2  |
| NISSAN Vehicle Immobilizer System               | 2-3  |
| Windshield wiper and washer switch              | 2-3  |
| Rear window wiper and washer switch             | 2-34 |
| Rear window and outside mirror defroster switch | 2-3  |
| Headlight and turn signal switch                | 2-3  |
| Headlight switch                                | 2-3  |
| Turn signal switch                              | 2-38 |
| Fog light switch (if so equipped)               | 2-3  |
| Horn  | 2-3  |
| Vehicle Dynamic Control (VDC) off switch        | 2-39 |
| Heated seats (if so equipped)                   | 2-4  |
| Clock (if so equipped)                          | 2-4  |
| Adjusting the time                              | 2-4  |
| Power outlet                                    | 2-4  |
| Storage   | 2-4  |
| Cup holders                                     | 2-4  |
| Cargo floor box                                 | 2-4  |
| Glove box                                       | 2-4  |
| Coat hook                                       | 2-4  |
| Cargo cover (if so equipped)                    | 2-4  |
|   |      |



| Windows                   | 2-45 | Interior lights                           | 2-49 |
|---------------------------|------|---|------|
| Power windows             | 2-45 | Map lights (if so equipped)               | 2-50 |
| Moonroof (if so equipped) | 2-48 | Map light control switch (if so equipped) | 2-50 |
| Power moonroof            | 2-48 | Cargo light                               | 2-51 |



### COCKPIT




- Outside mirror remote control switch
- Headlight, fog light and turn signal switch
  - Headlight
  - Turn signal light
  - Fog light\*
- Paddle shifter\*
- Steering wheel

- Electric power steering system
- Horn
- Driver's supplemental air bag
- Wiper and washer switch
- Shift lever
  - Continuously Variable Transmission (CVT)
  - Manual Transmission (MT)

- Fuse box cover
- Vehicle Dynamic Control (VDC) OFF switch
- All-Wheel Drive (AWD) switch\*
- Tilting steering wheel lever
- Steering-wheel-mounted controls (left side)
  - Audio control
  - Bluetooth® Hands-Free Phone System control
- Ignition switch (models without Intelligent Key system)
- Steering-wheel-mounted controls (right side)
  - Cruise control switches
- 14. Heated seat switch\*
- if so equipped

### **INSTRUMENT PANEL**




- 1. Meters and gauges
- 2. Center ventilator
- 3. Audio system\* or Navigation system\*\*
  - Clock\*
- 4. Hazard warning flasher switch
- 5. Integrated Control System\*
  - Drive mode
- 2-4 Instruments and controls

- Heater and air conditioner control
- Defroster switch
- Heater and air conditioner control (models without Integrated Control System)
  - Defroster switch
- 6. Front passenger supplemental air bag
- 7. Side ventilator



- 8. Fuel-filler door release handle
- 9. Hood release handle
- Push-button ignition switch (models with Intelligent Key system)
- 11. AUX/USB connector\*
- 12. Parking brake
- Cup holder
- 14. Power outlet
- 15. Glove box
- \*: if so equipped
- \*\*: Refer to the separate Navigation System Owner's Manual.

### **METERS AND GAUGES**



- Tachometer
- Engine coolant temperature gauge
- Vehicle information display
  - Odometer/twin trip odometer
  - Trip computer
  - Torque vectoring AWD (AWD model)
  - Outside air temperature

- Fuel gauge
- Speedometer
- Warning/indicator lights
- Instrument brightness control knob
- Continuously Variable Transmission (CVT) position indicator\*
- RESET switch for trip odometer/Trip computer


mode switch

if so equipped

The needle indicators may move slightly after the ignition switch is placed in the OFF or LOCK position. This is not a malfunction.




- For cleaning, use a soft cloth, dampened with water. Never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or cause discoloration to the lens.
- Do not spray any liquid such as water on the meter lens. Spraying liquid may cause the system to malfunction.



SPEEDOMETER AND ODOMETER

### Speedometer

The speedometer indicates vehicle speed in miles per hour (MPH) and kilometers per hour (km/h).



Odometer/twin trip odometer

### Odometer/twin trip odometer

The odometer (1) /twin trip odometer (2) are displayed when the ignition switch is in the ON position.

The odometer records the total distance the vehicle has been driven.

The twin trip odometer records the distance of individual trips.

### Changing the display:


Pushing the reset switch (3) located on the meter panel changes the display as follows:

TRIP A  $\rightarrow$  TRIP B  $\rightarrow$  Trip computer mode  $\rightarrow$ TRIP A

For trip computer information, see "Trip computer" (P.2-10).


### Resetting the trip odometer:

Pushing the reset switch (3) for approximately 1 second resets the trip odometer to zero.



### Loose fuel cap warning message

Push the reset switch (A) for more than 1 second to reset the LOOSE FUEL CAP warning message after the fuel cap has been tightened. For additional information see "Fuel-filler cap" (P.3-21) of this manual.



### Check tire pressure warning message


The CHECK TIRE PRES (pressure) warning message is displayed when the low tire pressure warning light (!) is illuminated and low tire pressure is detected. Check and adjust the tire pressure to the recommended COLD tire pressure shown on the Tire and Loading Information label. The CHECK TIRE PRES warning message turns off when the low tire pressure warning light (!) turns off.

The low tire pressure warning light (!) remains illuminated until the tires are inflated to the recommended COLD tire pressure. The CHECK TIRE PRES warning message is displayed each time the ignition switch is placed in the ON

position as long as the low tire pressure warning light (!) remains illuminated.

For more information see "Low tire pressure warning light" (P.2-15), "Tire Pressure Monitoring System (TPMS)" (P.5-4), and "Wheels and tires" (P.8-30).

Extended storage fuse warning message The SHIPPING MODE ON/PUSH STORAGE FUSE warning message may be displayed if the extended storage fuse switch is not pushed in (switched on). When this message is displayed, push in (switch on) the extended storage fuse switch to turn off the message. For more information, see "Extended storage fuse switch" (P.8-22).




### **TACHOMETER**

The tachometer indicates engine speed in revolutions per minute (RPM). **Do not rev the engine into the red zone** (1).



When engine speed approaches the red zone, shift to a higher gear or reduce engine speed. Operating the engine in the red zone may cause serious engine damage.



# ENGINE COOLANT TEMPERATURE GAUGE

The gauge ① indicates the engine coolant temperature.


The engine coolant temperature is within the normal range when the gauge is within the zone (2) shown in the illustration.

The engine coolant temperature varies with the outside air temperature and driving conditions.



If the gauge indicates engine coolant temperature near the hot (H) end of the

normal range, reduce vehicle speed to decrease temperature. If gauge is over the normal range, stop the vehicle as soon as safely possible. If the engine is overheated, continued operation of the vehicle may seriously damage the engine. See "If your vehicle overheats" (P.6-10) for immediate action required.



### **FUEL GAUGE**

The gauge (1) indicates the approximate fuel level in the tank.

The gauge may move slightly during braking, turning, acceleration, or going up or down hills.

### Refill the fuel tank before the gauge registers 0 (empty).

The low fuel warning light illuminates when the amount of fuel in the tank is getting low. Refuel as soon as it is convenient, preferably before the gauge reaches 0. There will be a small reserve of fuel in the tank when the fuel gauge reaches 0.


The Indicates that the fuel-filler door is

located on the front passenger's side of the vehicle.



### A CAUTION

- If the vehicle runs out of fuel, the 影響 malfunction indicator light (MIL) may come on. Refuel as soon as possible. After a few driving trips, the 틳땠 light should turn off. If the light remains on after a few driving trips, have the vehicle inspected by a NISSAN dealer.
- For additional information, see "Malfunction Indicator Light (MIL)" (P.2-18).



### VEHICLE INFORMATION DISPLAY

When the ignition switch is placed in the ON position, the vehicle information display shows the following information:

- Outside air temperature
- Continuously Variable Transmission (CVT) position indicator (if so equipped)
- Odometer/Instrument brightness control display
- Twin trip odometer/Trip computer



### **OUTSIDE AIR TEMPERATURE**


The outside air temperature is displayed in  ${^\circ}\text{F}$  or  ${^\circ}\text{C}.$ 

When the outside air temperature becomes 37°F (3°C) or lower, the outside air temperature display blinks to give a warning. The display will stop blinking after 1 minute or when the outside air temperature becomes 39°F (4°C) or above.

The display may differ from the actual outside temperature displayed on various signs or bill-boards.

### CONTINUOUSLY VARIABLE TRANS-MISSION (CVT) POSITION INDICATOR (if so equipped)

The Continuously Variable Transmission (CVT) position indicator indicates the shift lever position when the ignition switch is in the ON position.




### TRIP COMPUTER

The switch for the trip computer is located on the meter panel.

When the ignition switch is placed in the ON position, modes of the trip computer can be selected by pushing the trip computer mode switch (A).

Each time the trip computer mode switch (A) is pushed, the display will change as follows:

 $(TRIP\ A \to TRIP\ B) \to Current$  fuel consumption  $\to$  Distance to empty (dte)  $\to$  Average fuel consumption  $\to$  Elapsed time  $\to$  Torque vectoring AWD (AWD model) ( $\to$  TRIP A)



The current fuel consumption mode shows the current fuel consumption.

### Distance to empty (dte - mls or km)

The distance to empty (dte) mode provides you with an estimation of the distance that can be driven before refueling. The dte is constantly being calculated, based on the amount of fuel in the fuel tank and the actual fuel consumption.

The display is updated every 30 seconds.

The dte mode includes a low range warning feature. When the fuel level is low, the dte mode is automatically selected and the dte display will blink. Push the trip computer mode switch (a) to return to the mode that was selected before the warning occurred.

When the fuel level drops even lower, the dte display will change to "---".

- If the amount of fuel added is small, the display just before the ignition switch is turned off may continue to be displayed.
- When driving uphill or rounding curves, the fuel in the tank shifts, which may momentarily change the display.




# Average fuel consumption (mpg or I (liter)/100 km)

The average fuel consumption mode shows the average fuel consumption since the last reset. Resetting is done by pushing the trip computer mode switch (A) for approximately 1 second.

The display is updated every 30 seconds. At about the first 1/3 mile (500 m) after a reset, the display shows "---".

### Elapsed time

The elapsed time mode shows the time since the last reset. The displayed time can be reset by pushing the trip computer mode switch (A) for approximately 1 second.



### Torque vectoring AWD (AWD model)

The Torque vectoring mode shows the current amount of torque distributed to each wheel. Each torque indicator is displayed as a bar graph ① divided into 3 segments. The upper indicator displays the current amount of torque distribution (left and right) for the front wheels. The lower indicator displays the current amount of torque distribution (left and right) for the rear wheels. The number of segments shows the amount of torque currently distributed to each wheel.

### Resetting displays

When the average fuel consumption, elapsed time or TRIP B is displayed, push the trip computer mode switch (a) for longer than 3 seconds. The average fuel consumption, elapsed time and trip odometer (TRIP B only) displays will be reset at the same time.



# WARNING/INDICATOR LIGHTS AND AUDIBLE REMINDERS

| AWD           | All-Wheel Drive (AWD) warning light (AWD model)* |                 | Low fuel warning light                                    | (CRUISE)                  | Cruise indicator light                            |
|---------------|--|-----------------|---|---------------------------|---|
| ABS           | Anti-lock Braking System (ABS) warning           | ( <u>i</u> )    | Low tire pressure warning light                           | 1                         | Engine start operation indicator light*           |
| (e)           | light  |                 | Low washer fluid warning light*                           | €DŒ                       | Exterior light indicator                          |
| BRAKE         | Dalama Car Pala                                  | P <b></b> SHIF1 | P position selecting warning light*                       | 0+ 20/2                   | Front passenger air bag status light              |
| (0)           | Brake warning light                              | Ž.              | Seat belt warning light                                   |                           | High beam indicator light                         |
| - +           | Charge warning light                             |                 | Supplemental air bag warning light                        | SERVICE<br>ENGINE<br>SOON | Malfunction Indicator Light (MIL)                 |
| <b>(</b> 2)   | Door open warning light                          | 泉               | Vehicle Dynamic Control (VDC) warning light               | $\Leftrightarrow$         | Security indicator light                          |
| PS            | Electric power steering warning light            | AWD             | All-Wheel Drive (AWD) indicator light (AWD model)*        | $\Leftrightarrow$         | Turn signal/hazard indicator lights               |
| ه <u>ټ</u> ≻. | Engine oil pressure warning light                | AN IV           | All-Wheel Drive (AWD)-V indicator light (AWD model)*      | ÖFF                       | Vehicle Dynamic Control (VDC) off indicator light |
| <u></u> Ο     | Intelligent Key system warning light*            | CVT             | Continuously Variable Transmission (CVT) indicator light* | *: if so ed               | quipped   |



### CHECKING BULBS

With all doors closed, apply the parking brake and place the ignition switch in the ON position without starting the engine. The following lights will come on:

🛅, BRAKE OF (1), 🗠, SOON, 🙏, PS, AWD

The following lights come on briefly and then go off (if so equipped):

If any light does not come on, it may indicate a burned-out bulb or an open circuit in the electrical system. Have the system checked by a NISSAN dealer.

### WARNING LIGHTS

AWD All-Wheel Drive (AWD) warning light (AWD model)

When the ignition switch is in the "ON" position, the All-Wheel Drive (AWD) warning light will illuminate. It will turn off soon after the engine is started.

If the AWD system malfunctions or the revolution or radius of the front and the rear wheel differs, the AWD warning light will either remain illuminated or blink. (See "All-Wheel Drive (AWD)" (P.5-33).)

ABS or Anti-lock Braking System (ABS) warning light

When the ignition switch is in the ON position, the Anti-lock Braking System (ABS) warning light illuminates and then turns off. This indicates the ABS is operational.

If the ABS warning light illuminates while the engine is running, or while driving, it may indicate the ABS is not functioning properly. Have the system checked by a NISSAN dealer.

If an ABS malfunction occurs, the anti-lock function is turned off. The brake system then operates normally, but without anti-lock assistance. (See "Brake system" (P.5-39).)

BRAKE or Brake warning light

This light functions for both the parking brake and the foot brake systems.

### Parking brake indicator:

When the ignition switch is in the ON position, the light illuminates when the parking brake is applied.

### Low brake fluid warning light:

When the ignition switch is in the ON position, the light warns of a low brake fluid level. If the light illuminates while the engine is running with the parking brake not applied, stop the vehicle and perform the following:

- Check the brake fluid level. If brake fluid is necessary, add fluid and have the system checked by a NISSAN dealer. (See "Brake and clutch fluid" (P.8-11).)
- If the brake fluid level is correct, have the warning system checked by a NISSAN dealer.


## Anti-lock Braking System (ABS) warning indicator:

When the parking brake is released and the brake fluid level is sufficient, if both the brake warning light and the Anti-lock Braking System (ABS) warning light illuminate, it may indicate the ABS is not functioning properly. Have the brake system checked, and if necessary repaired, by a NISSAN dealer promptly. (See "Anti-lock Braking System (ABS) warning light" (P.2-13).)

### **A** WARNING

 Your brake system may not be working properly if the warning light is on. Driving could be dangerous. If you judge it to be safe, drive carefully to the nearest service station for repairs. Otherwise, have your vehicle towed because driving it could be dangerous.

- Pressing the brake pedal with the engine stopped and/or low brake fluid level may increase your stopping distance and braking will require greater pedal effort as well as pedal travel.
- If the brake fluid level is below the minimum or MIN mark on the brake fluid reservoir, do not drive until the brake system has been checked at a NISSAN dealer.



If the light illuminates while the engine is running, it may indicate the charging system is not functioning properly. Turn the engine off and check the alternator belt. If the belt is loose, broken, missing or if the light remains on, see a NISSAN dealer immediately.

### **A** CAUTION

Do not continue driving if the alternator belt is loose, broken or missing.

### Door open warning light

This light illuminates when any of the doors and/ or lift gate are not closed securely while the ignition switch is in the ON position.

# **PS** Electric power steering warning light

When the ignition switch is in the ON position, the electric power steering warning light illuminates. After starting the engine, the electric power steering warning light turns off. This indicates the electric power steering system is operational.

If the electric power steering warning light illuminates while the engine is running, it may indicate the electric power steering system is not functioning properly and may need servicing. Have the electric power steering system checked by a NISSAN dealer.

When the electric power steering warning light illuminates with the engine running, the power assist to the steering will cease operation but you will still have control of the vehicle. At this time, greater steering efforts are required to operate the steering wheel, especially in sharp turns and at low speeds.

See "Electric power steering system" (P.5-38).

### Engine oil pressure warning light

This light warns of low engine oil pressure. If the light flickers or illuminates during normal driving, pull off the road in a safe area, stop the engine **immediately** and call a NISSAN dealer or other authorized repair shop.

The engine oil pressure warning light is not designed to indicate a low oil level. Use the dipstick to check the oil level. (See "Engine oil" (P.8-8).)

### **A** CAUTION

Running the engine with the engine oil pressure warning light on could cause serious damage to the engine almost immediately. Such damage is not covered by warranty. Turn off the engine as soon as it is safe to do so.

| Intelligent Key system warning light (if so equipped)

After the ignition switch is placed in the ON position, this light comes on for about 2 seconds and then turns off.

This light illuminates or blinks as follows:



- The light blinks in yellow when the door is closed with the Intelligent Key left outside the vehicle and the ignition switch in the ACC or ON position. Make sure that the Intelligent Key is inside the vehicle.
- The light blinks in green when the Intelligent Key battery is running out of power. Replace the battery with a new one. (See "Key battery replacement" (P.8-22).)
- The light illuminates in yellow when it warns of a malfunction with Intelligent Key system.

If the warning light illuminates in yellow while the engine is stopped, it may be impossible to start the engine. If the light comes on while the engine is running, you can drive the vehicle. However in these cases, contact a NISSAN dealer for repair as soon as possible.



### Low fuel warning light

This light illuminates when the fuel in the tank is getting low. Refuel as soon as it is convenient, preferably before the fuel gauge reaches the 0 (empty) position.

There will be a small reserve of fuel remaining in the tank when the fuel gauge reaches the 0 position.



### (!) Low tire pressure warning light

Your vehicle is equipped with a Tire Pressure Monitoring System (TPMS) that monitors the tire pressure of all tires except the spare.


The low tire pressure warning light warns of low tire pressure or indicates that the TPMS is not functioning properly.

After the ignition switch is placed in the ON position, this light illuminates for about 1 second and turns off.

### Low tire pressure warning:

If the vehicle is being driven with low tire pressure, the warning light will illuminate. A CHECK TIRE PRES (pressure) warning message is also displayed in the vehicle information display.

When the low tire pressure warning light illuminates, you should stop and adjust the tire pressure to the recommended COLD tire pressure shown on the Tire and Loading Information label. The low tire pressure warning light does not automatically turn off when the tire pressure is adjusted. After the tire is inflated to the recommended pressure, the vehicle must be driven at speeds above 16 MPH (25 km/h) to activate the TPMS and turn off the low tire pressure warning light. Use a tire pressure gauge to check the tire pressure.



For additional information, see "Check tire pressure warning message" (P.2-7), "Tire Pressure Monitoring System (TPMS)" (P.5-4) and "Tire Pressure Monitoring System (TPMS)" (P.6-3).

#### TPMS malfunction:

If the TPMS is not functioning properly, the low tire pressure warning light will flash for approximately 1 minute when the ignition switch is placed in the ON position. The light will remain on after 1 minute. The CHECK TIRE PRES warning message is not displayed if the low tire pressure warning light illuminates to indicate a TPMS malfunction. Have the system checked by a NISSAN dealer.

For additional information, see "Tire Pressure Monitoring System (TPMS)" (P.5-4).



### **A** WARNING


- If the light does not illuminate with the ignition switch placed in the ON position, have the vehicle checked by a NISSAN dealer as soon as possible.
- If the light illuminates while driving, avoid sudden steering maneuvers or abrupt braking, reduce vehicle speed, pull off the road to a safe location and stop the vehicle as soon as possible. Driving with under-inflated tires may permanently damage the tires and increase the likelihood of tire failure. Serious vehicle damage could occur and may lead to an accident and could result in serious personal injury. Check the tire pressure for all four tires. Adjust the tire pressure to the recommended COLD tire pressure shown on the Tire and Loading Information label to turn the low tire pressure warning light OFF. If the light still illuminates while driving after adjusting the tire pressure. a tire may be flat. If you have a flat tire, replace it with a spare tire as

soon as possible.

- When a spare tire is mounted or a wheel is replaced, the TPMS will not function and the low tire pressure warning light will flash for approximately 1 minute. The light will remain on after 1 minute. Contact your NISSAN dealer as soon as possible for tire replacement and/or system resetting.
- Replacing tires with those not originally specified by NISSAN could affect the proper operation of the TPMS.

### **A** CAUTION

- The TPMS is not a substitute for the regular tire pressure check. Be sure to check the tire pressure regularly.
- If the vehicle is being driven at speeds of less than 16 MPH (25 km/h), the TPMS may not operate correctly.
- Be sure to install the specified size of tires to the four wheels correctly.



This light illuminates when the washer fluid is at a low level. Add washer fluid as necessary. (See "Window washer fluid" (P.8-12).)

P position selecting warning light (if so equipped)

The warning light blinks in red when the ignition switch is pushed to stop the engine with the shift lever in any position except the P (Park) position.

If this warning appears, move the shift lever to the P (Park) position or push the ignition switch to the ON position.

An inside warning chime will also sound.

See "Intelligent Key system" (P.3-10).

Seat belt warning light

The light and chime remind you to fasten seat belts. The light illuminates whenever the ignition switch is placed in the ON position, and will remain illuminated until the driver's seat belt is fastened. At the same time, the chime will sound for about 6 seconds unless the driver's seat belt is securely fastened.

The seat belt warning light for the front passenger will illuminate if the seat belt is not fastened when the front passenger's seat is



occupied. For about 5 seconds after the ignition switch is in the ON position, the system does not activate the warning light for the front passenger.

See "Seat belts" (P.1-10) for precautions on seat belt usage.

Supplemental air bag warning light After turning the ignition switch to the ON position, the supplemental air bag warning light will illuminate. The supplemental air bag warning light will turn off after about 7 seconds if the supplemental front air bag and supplemental side air bag, curtain side-impact air bag systems and/or pretensioner seat belt are operational.

If any of the following conditions occur, the front air bag, side air bag, curtain air bag and pretensioner systems need servicing and your vehicle must be taken to your nearest NISSAN dealer.

- The supplemental air bag warning light remains on after approximately 7 seconds.
- The supplemental air bag warning light flashes intermittently.
- The supplemental air bag warning light does not illuminate at all.

Unless checked and repaired, the Supplemental Restraint Systems and/or the pretensioners may not function properly.

For additional information, see "Supplemental restraint system" (P.1-38).



### **WARNING**

If the supplemental air bag warning light is on, it could mean that the front air bag, side air bag, curtain air bag and/or pretensioner systems will not operate in an accident. To help avoid injury to yourself or others, have your vehicle checked by a NISSAN dealer as soon as possible.



The light will blink when the Vehicle Dynamic Control (VDC) system or the traction control system is operating, thus alerting the driver that the vehicle is nearing its traction limits. The road surface may be slippery.

If the VDC warning light illuminates while the VDC system is on, this light alerts the driver to the fact that the VDC system's fail-safe mode is operating, for example the VDC system may not be functioning properly. Have the system checked by a NISSAN dealer. If a malfunction occurs in the system, the VDC system function

will be canceled but the vehicle is still driveable. For additional information, see "Vehicle Dynamic Control (VDC) system" (P.5-41) of this manual.

### INDICATOR LIGHTS

AWD All-Wheel Drive (AWD) indicator light (AWD model)

When the ignition switch is in the "ON" position, the All-Wheel Drive (AWD) indicator light illuminates and then turns off.

When selecting AWD mode while the engine is running, the AWD indicator light illuminates. (See "All-Wheel Drive (AWD)" (P.5-33).)

All-Wheel Drive (AWD-V) indicator light (AWD model)

When selecting AWD-V mode while the engine is running, the AWD-V indicator light illuminates. (See "All-Wheel Drive (AWD)" (P.5-33).)

CVT Continuously Variable Transmission (CVT) indicator light (if so equipped)

When the ignition switch is in the "ON" position, the Continuously Variable Transmission (CVT) indicator light illuminates and then turns off.



Cruise indicator light


#### Cruise main switch indicator:

This light illuminates when the cruise control main switch is pushed. The light turns off when the main switch is pushed again. When the cruise indicator light illuminates, the cruise control system is operational.

#### Cruise malfunction:

If the cruise indicator light blinks while the engine is running, it may indicate the cruise control system is not functioning properly. Have the system checked by a NISSAN dealer.

See "Cruise control" (P.5-30).



This light appears when the shift lever is in the P (Park) position (Continuously Variable Transmission (CVT) models) or N (Neutral) position (Manual Transmission (MT) models). This light means that the engine will start by pushing the ignition switch with the brake pedal depressed. You can start the engine directly in any position.

### Exterior light indicator

This indicator illuminates when the headlight switch is turned to the AUTO (if so equipped), EDGE or € position and the front parking lights, instrument panel lights, rear combination lights, license plate lights or headlights are on. The indicator turns off when these lights are turned off.



### Front passenger air bag status light

The front passenger air bag status light (located on the center of the instrument panel) will be lit and the passenger front air bag will be OFF depending on how the front passenger seat is being used.

For front passenger air bag status light operation, see "NISSAN Advanced Air Bag System (front seats)" (P.1-44) of this manual.



### High beam indicator light

This light illuminates when the headlight high beam is on and goes out when the low beam is selected.



### Malfunction Indicator Light (MIL)

If the malfunction indicator light comes on steady or blinks while the engine is running, it may indicate a potential emission control and/or Continuously Variable Transmission (CVT) malfunction.

The malfunction indicator light may also illuminate steady if the fuel-filler cap is loose or missing, or if the vehicle runs out of fuel. Check to make sure the fuel-filler cap is installed and closed tightly, and that the vehicle has at least 3 US gallons (11.4 liters) of fuel in the fuel tank.

After a few driving trips, the light should turn off if no other potential emission control system malfunction exists.

If this indicator light remains on for 20 seconds and then blinks for 10 seconds when the engine is not running, it indicates that the vehicle is not ready for an emission control system inspection/ maintenance test. (See "Readiness for Inspection/Maintenance (I/M) test" (P.9-20).)

### Operation:

The malfunction indicator light will come on in one of two ways:

Malfunction indicator light illuminated steady - An emission control system and/or CVT malfunction has been detected. Check the fuel-filler cap if the LOOSE FUEL CAP



warning message is displayed on the twin trip odometer. If the fuel-filler cap is loose or missing, tighten or install the cap and continue to drive the vehicle. The light should turn off after a few driving trips. If the Fight does not turn off after a few driving trips, have the vehicle inspected by a NISSAN dealer. You do not need to have your vehicle towed to the dealer.

Malfunction indicator light blinking — An engine misfire has been detected which may damage the emission control system.

To reduce or avoid emission control system damage:

- 1) Do not drive at speeds above 45 MPH (72 km/h).
- 2) Avoid hard acceleration or deceleration.
- 3) Avoid steep uphill grades.
- 4) If possible, reduce the amount of cargo being hauled or towed.

The malfunction indicator light may stop blinking and remain on.

Have the vehicle inspected by a NISSAN dealer. You do not need to have your vehicle towed to the dealer.



Continued vehicle operation without having the emission control system and/or CVT system checked and repaired as necessary could lead to poor driveability, reduced fuel economy, and possible damage to the emission control system.



Security indicator light

The light blinks when the ignition switch is in the ACC, OFF or LOCK position. This function indicates the security system equipped on the vehicle is operational.

If the security system is malfunctioning, this light will remain on while the ignition switch is in the ON position. For additional information, see "Security systems" (P.2-29).

The light flashes when the turn signal switch lever or hazard switch is turned on.

₩ Vehicle Dynamic Control (VDC) off indicator light

The light comes on when the Vehicle Dynamic Control (VDC) off switch is pushed to OFF. This indicates that the VDC system and traction control system are not operating.

### AUDIBLE REMINDERS

Key reminder chime

### Models with Intelligent Key system:

A chime will sound if the driver side door is opened while the ignition switch is pushed to the ACC position.

Make sure the ignition switch is pushed to the OFF position, and take the Intelligent Key with you when leaving the vehicle.

### Models without Intelligent Key system:

The key reminder chime sounds if the driver's side door is opened while the key is left in the ignition switch and the ignition switch is in the ACC, OFF or LOCK position. Remove the key and take it with you when leaving the vehicle.



### Light reminder chime

The light reminder chime will sound when the driver side door is opened with the light switch in the AUTO (if so equipped), store or so position, and the ignition switch is in the ACC, OFF or LOCK position.

Turn the light switch off when you leave the vehicle.

### Brake pad wear warning

The disc brake pads have audible wear warnings. When a brake pad requires replacement, it will make a high pitched scraping sound when the vehicle is in motion. This scraping sound will first occur only when the brake pedal is depressed. After more wear of the brake pad, the sound will always be heard even if the brake pedal is not depressed. Have the brakes checked as soon as possible if the warning sound is heard.

### Parking brake reminder chime

The parking brake reminder chime will sound if the vehicle is driven at more than 4 MPH (7 km/h) with the parking brake applied. Stop the vehicle and release the parking brake.

### Seat belt warning chime

The seat belt warning chime will sound for about 6 seconds unless the driver's seat belt is securely fastened.



# INTEGRATED CONTROL SYSTEM (if so equipped)

The Integrated Control System is located below the audio system or navigation system (if so equipped). Two Integrated Control System modes can be selected: Drive mode and Climate Control mode.

Depending on which Integrated Control System mode is selected (Drive mode or Climate Control mode), the screen display and some button functions will change.

#### Drive mode


In the Drive mode, three types of driving modes can be selected: NORMAL, SPORT and ECO. See "Drive mode" (P.5-25). In addition, while in the Drive mode, SETUP, Drive information and ECO information can be displayed and adjusted. See "Drive mode" (P.2-21).

### Climate Control mode

In the Climate Control mode, the climate control can be set and adjusted. See "Automatic air conditioner (with Integrated Control System)" (P.4-24).

### **DRIVE MODE**

When the Drive mode select button is pressed, the display and buttons appear as shown.



- . Drive mode select button
- SETUP button
- 3. Drive mode NORMAL button
- 4. Drive mode SPORT button
- 5. Drive mode ECO button
- 6. Display screen
- 7. Drive information button



- 3. ECO information button
- ENTER button/Selection dial


#### SETUP FUNCTION

While in the Drive mode, the following items can be set up by pressing the SETUP button.

- Display Brightness
- Button Brightness
- Clock Time Setting
- Select Language
- Select Units
- Auto Interior Illumination
- Selective Door unlock
- Auto Headlight Sensitivity (if so equipped)
- CLIMATE ECO


#### NOTE:

- The SETUP function cannot be adjusted while driving.
- When the battery is disconnected, the SETUP memory is erased and reverts to the default settings. If necessary, reset the SETUP memory after reconnecting the battery.



Setting Display Brightness and Button Brightness

- 1. Press the Drive Mode Select button.
- 2. Press the SETUP button.
- Turn the Selection dial to "Display Brightness" or "Button Brightness" then press the ENTER button.



 Turn the Selection dial to + to increase brightness or to - to decrease brightness, then press the ENTER button to apply the selection.

Display Brightness and Button Brightness can be manually adjusted during the day (when the headlight switch is off) or at night (when the headlight switch is on).


When the bar is at the minimum or maximum brightness level, the brightness level is the same as the daytime level (headlight switch is on) or nighttime level (headlight switch off).




Clock Time Setting

NOTE:

Clock Time Setting is used for displaying the ECO information. See "Eco information" (P.2-28).




- 1. Press the Drive Mode Select button.
- 2. Press the SETUP button.
- 3. Turn the Selection dial to "Clock Time Setting", then press the ENTER button.




- 4. Turn the Selection dial to select the day of the week, then press the ENTER button to apply the selection.
- 5. Turn the Selection dial to select the hour and AM or PM, then press the ENTER button to apply the selection.
- 6. Turn the Selection dial to select the minutes, then press the ENTER button to apply the selection.








- 1. Press the Drive Mode Select button.
- 2. Press the SETUP button.
- Turn the Selection dial to "Select Language", then press the ENTER button.




4. Turn the Selection dial to select the preferred language, then press the ENTER button to apply the selection.




### Select Units

- 1. Press the Drive Mode Select button.
- Press the SETUP button.
- Turn the Selection dial to "Select Units" then press the ENTER button.






 Turn the Selection dial to select "US" or "METRIC", then press the ENTER button to apply the selection.



### Auto Interior Illumination

Select to turn the illumination of the interior lights on or off when any door is unlocked.

- 1. Press the Drive Mode Select button.
- 2. Press the SETUP button.
- 3. Turn the Selection dial to "Auto Interior Illumination" then press the ENTER button.
- Turn the Selection dial to select "ON" or "OFF", then press the ENTER button to apply the selection.



### Selective Door Unlock


When this item is turned on, only the driver's door is unlocked after the door unlock operation is performed once. All of the doors can be unlocked if the door unlock operation is performed again within 1 minute.

When this item is turned off, all the doors will be unlocked after the door unlock operation is performed once.

- 1. Press the Drive Mode Select button.
- 2. Press the SETUP button.
- Turn the Selection dial to "Selective Door Unlock" then press the ENTER button.




 Turn the Selection dial to select "ON" or "OFF", then press the ENTER button to apply the selection. The indicator will turn red when selective door unlock is on.



# Auto Headlight Sensitivity (if so equipped)


Select to adjust the sensitivity of the automatic headlight.

- 1. Press the Drive Mode Select button.
- 2. Press the SETUP button.
- 3. Turn the Selection dial to "Auto Headlight Sensitivity" then press the ENTER button.



 Turn the Selection dial to + to increase sensitivity or to - to decrease sensitivity, then press the ENTER button to apply the selection.





### **DRIVE INFORMATION**

While in the Drive mode, push the Drive information button to display elapsed time, average speed and trip distance. Pressing the Drive information button a second time will display the G (gravity)-Force screen.

### Elapsed time

The elapsed time shows the time since the last reset.


### Average speed (km/h or MPH)

The average speed shows the average vehicle speed since the last reset.

### Trip distance (km or MILES)

The trip distance shows the distance driven since the last reset.

To reset the elapsed time, average speed and trip distance, push the ENTER button for more than one second. All three drive information displays will reset at the same time.



### G-Force screen

The G (gravity)-Force screen displays the current acceleration and deceleration (front-torear) and cornering (side-to-side) G-Force on the vehicle.




### **ECO INFORMATION**



Do not adjust the display controls while driving so that full attention may given to vehicle operation.

The following ECO INFO mode will appear on the display by pushing the ECO information button, then turning the selection dial to scroll through the different screens.

While driving, only one ECO information screen is displayed. The vehicle must be stopped to scroll through the different screens.



### Daily Reset

Records of up to the past 4 days of fuel consumption can be shown on the display.



### **SECURITY SYSTEMS**

### Weekly Reset

Records of up to the past 4 weeks of each week's fuel consumption can be shown on the display.

### NOTE:

When the clock is not set, the ECO information (daily and weekly) cannot be used.


### Reset at Start

Records of up to the past 4 times of each time of ignition switch ON fuel consumption can be shown on the display.

### Manual Reset

Records of up to the past 4 times of resetting fuel consumption can be shown on the display.

The displayed ECO INFO can be reset by pushing the ENTER button for longer than 1 second.



Your vehicle has two types of security systems, as follows:

- Vehicle security system
- NISSAN Vehicle Immobilizer System

The security condition will be shown by the security indicator light.


### VEHICLE SECURITY SYSTEM

The vehicle security system provides visual and audio alarm signals if someone opens the doors, or lift gate when the system is armed. It is not, however, a motion detection type system that activates when a vehicle is moved or when a vibration occurs.

The system helps deter vehicle theft but cannot prevent it, nor can it prevent the theft of interior or exterior vehicle components in all situations. Always secure your vehicle even if parking for a brief period. Never leave your keys in the vehicle, and always lock it when unattended. Be aware of your surroundings, and park in secure, well-lit areas whenever possible.

Many devices offering additional protection, such as component locks, identification markers, and tracking systems, are available at auto supply stores and specialty shops. Your NISSAN dealer may also offer such equipment. Check with your insurance company to see if you may be eligible for discounts for various theft protection features.





How to arm the vehicle security system

Close all windows.

The system can be armed even if the windows are open.

2. Models with Intelligent Key system:

Place the ignition switch in the OFF position and remove the Intelligent Key from the vehicle.

Models without Intelligent Key system:

Place the ignition switch in the LOCK position and remove the key.

- 3. Close all doors. Lock all doors. The doors can be locked with:
  - the LOCK A button on the keyfob or Intelligent Key (if so equipped)
  - any request switch (Intelligent Key equipped model)
  - the power door lock switch
  - the key master or mechanical (Intelligent Key equipped model)
- 4. Confirm that the security indicator light illuminates. The security indicator light stays on for about 30 seconds. The vehicle security system is now pre-armed. After about 30 seconds the vehicle security system automatically shifts into the armed phase. The security light begins to flash once every approximately 3 seconds. If, during this 30-second pre-arm time period, the door is unlocked, or the ignition switch is placed in the ACC or ON position, the system will not arm.

Even when the driver and/or passengers are in the vehicle, the system will activate with all doors locked with the ignition switch in the LOCK position. When turning the ignition switch to the ACC or ON position, the system will be released.

### Vehicle security system activation

The vehicle security system will give the following alarm:

- The headlights blink and the horn sounds intermittently.
- The alarm automatically turns off after approximately 50 seconds. However, the alarm reactivates if the vehicle is tampered with again.

The alarm is activated by:

Unlocking the door without using the keyfob, the Intelligent Key (if so equipped) the request switch (if so equipped) or the key. (Even if the door is opened by releasing the door inside lock knob, the alarm will activate.)

### How to stop an activated alarm

The alarm will stop by unlocking a door by pushing the UNLOCK a button on the keyfob or Intelligent Key, pushing the request switch or using the key. The alarm will not stop if the ignition switch is placed in the ACC or ON position.

If the system does not operate as described above, have it checked by a NISSAN dealer.



# NISSAN VEHICLE IMMOBILIZER SYSTEM

The NISSAN Vehicle Immobilizer System will not allow the engine to start without the use of the registered key.

If the engine fails to start using the registered key, it may be due to interference caused by another registered key, an automated toll road device or automated payment device on the key ring. Restart the engine using the following procedures:

- 1. Leave the ignition switch in the ON position for approximately 5 seconds.
- Place the ignition switch in the OFF or LOCK position and wait approximately 10 seconds.
- 3. Repeat step 1 and 2 again.
- Restart the engine while holding the device (which may have caused the interference) separate from the registered key.

If this procedure allows the engine to start, NISSAN recommends placing the registered key on a separate key ring to avoid interference from other devices.

Statement related to section 15 of FCC rules for NISSAN Vehicle Immobilizer System (CONT ASSY-BCM. ANT ASSY-IMMOBILISER)

#### FCC Notice:


#### For USA:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### For Canada:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



### Security indicator light

The security indicator light is located on the meter panel. It indicates the status of the NISSAN Vehicle Immobilizer System.

The light blinks whenever the ignition switch is in the LOCK, OFF or ACC position. This function indicates the security systems equipped on the vehicle are operational.

If the NISSAN Vehicle Immobilizer System is malfunctioning, this light will remain on while the ignition switch is in the ON position.

If the light still remains on and/or the engine will not start, see a NISSAN dealer for NISSAN Vehicle Immobilizer System



### WINDSHIELD WIPER AND WASHER SWITCH

service as soon as possible. Please bring all registered keys that you have when visiting a NISSAN dealer for service.



### **WARNING**

In freezing temperatures the washer solution may freeze on the windshield and obscure your vision which may lead to an accident. Warm windshield with the defroster before you wash the windshield.




### **CAUTION**

- Do not operate the washer continuously for more than 30 seconds.
- Do not operate the washer if the reservoir tank is empty.
- Do not fill the window washer reservoir tank with washer fluid concentrates at full strength. Some methyl alcohol based washer fluid concentrates may permanently stain the grille if spilled while filling the window washer reservoir tank.
- Pre-mix washer fluid concentrates with water to the manufacturer's recommended levels before pouring the fluid into the window washer

reservoir tank. Do not use the window washer reservoir tank to mix the washer fluid concentrate and water.

If the windshield wiper operation is interrupted by snow or ice, the wiper may stop moving to protect its motor. If this occurs, turn the wiper switch to the OFF position and remove the snow or ice that is on and around the wiper arms. In approximately 1 minute, turn the switch on again to operate the wiper.





The windshield wiper and washer operates when the ignition switch is in the ON position.

Push the lever down to operate the wiper at the following speed:

- Intermittent intermittent operation can be adjusted by turning the knob toward (A) (Slower) or (B) (Faster).
- Low continuous low speed operation
- High continuous high speed operation

Push the lever up (4) to have one sweep operation of the wiper.

Pull the lever toward you (5) to operate the washer. Then the wiper will also operate several times.

### Pulling up the wiper arm:

The wiper arm should be in the up position when replacing the wiper.

To pull up the wiper arm, push the lever (4) up twice when the ignition switch is in the "OFF" position within 1 minute. The wiper operation stops in mid-operation.

To replace the wiper arm, place the wiper arm in the down position and then push the lever (4) up once.

## CAUTION

- This function can be operated even if the ignition switch is in the "ON" position. However, to prevent an accident or damage when pulling up the wiper arm, be sure to observe the following precautions.
  - Make sure the shift lever is in the P (Park) position (Continuously Variable Transmission models).
  - Make sure the shift lever is in the N (Neutral) position, with the parking brake fully applied (Manual Transmission models).

- Never allow the passengers to operate the windshield wiper switch inadvertently.
- Do not operate the windshield wiper while the wiper arm is pulled up. The wiper arm may be damaged.



#### REAR WINDOW WIPER AND **WASHER SWITCH**



### WARNING

In freezing temperatures the washer solution may freeze on the rear window glass and obscure your vision. Warm the rear window with the defroster before you wash the rear window.




### A CAUTION

- Do not operate the washer continuously for more than 30 seconds.
- Do not operate the washer if the reservoir tank is empty.
- Do not fill the window washer reservoir tank with washer fluid concentrates at full strength. Some methyl alcohol based washer fluid concentrates may permanently stain the grille if spilled while filling the window washer reservoir tank.
- Pre-mix washer fluid concentrates with water to the manufacturer's recommended levels before pouring the fluid into the window washer reservoir tank. Do not use the

window washer reservoir tank to mix the washer fluid concentrate and water.

If the rear window wiper operation is interrupted by snow or ice, the wiper may stop moving to protect its motor. If this occurs, turn the wiper switch to the OFF position and remove the snow or ice that is on and around the wiper arms. In approximately 1 minute, turn the switch on again to operate the wiper.



The rear window wiper and washer operate when the ignition switch is in the ON position.


Turn the switch clockwise from the OFF position to operate the wiper.

- Intermittent (INT) intermittent operation (not adjustable)
- (2) Low (ON) continuous low speed operation


Push the switch forward (3) to operate the washer. Then the wiper will also operate several times.



# REAR WINDOW AND OUTSIDE MIRROR DEFROSTER SWITCH



Type A




Type B


# HEADLIGHT AND TURN SIGNAL SWITCH

To defog/defrost the rear window glass and outside mirrors (if so equipped), start the engine and push the switch (1) on. The indicator light (2) will illuminate. Push the switch again to turn the defroster off.

It will automatically turn off in approximately 15 minutes.



When cleaning the inner side of the rear window, be careful not to scratch or damage the rear window defroster.




#### HEADLIGHT SWITCH

#### Lighting

- Turn the switch to the roar position: The front parking, side marker, tail, license plate, instrument lights and daytime running lights (for NISMO models) will come on.
- Turn the switch to the position: Headlights will come on and all the other lights remain on. However, the daytime running lights (for NISMO models) will turn off.





#### Autolight system (if so equipped)

The autolight system allows the headlights to be set so they turn on and off automatically.

To set the autolight system:

- Make sure the headlight switch is in the AUTO position (1).
- 2. Place the ignition switch in the ON position.
- The autolight system automatically turns the headlights on and off.


To turn the autolight system off, turn the switch to the OFF, EDGE or ED position.

The autolight system can turn on the headlights automatically when it is dark and turn off the

headlights when it is light.

For US models (if so equipped): The headlights will also be turned on automatically at twilight or in rainy weather (when the windshield wiper is operated continuously).

If the ignition switch is placed in the OFF position and one of the doors is opened and this condition is continued, the headlights remain on for 5 minutes.




Be sure not to put anything on top of the photo sensor ① located on the top of the instrument panel. The photo sensor controls the autolight; if it is covered, the photo sensor reacts as if it is dark and the headlights will illuminate.

#### Automatic headlights off delay

You can keep the headlights on for up to 45 seconds after you place the ignition switch in OFF and open any door then close all the doors.





#### Headlight beam select

- To select the low beam, put the lever in the neutral position as shown.
- To select the high beam, push the lever forward while the switch is in the (D) position. Pull it back to select the low beam.
- Pulling the lever toward you will flash the headlight high beam even when the headlight switch is in the OFF position.

#### Battery saver system

- When the headlight switch is in the EDGE or so position while the ignition switch is in the ON position, the lights will automatically turn off within a period of time after the ignition switch has been placed in the OFF position.
- When the headlight switch remains in the EDGE or SD position after the lights automatically turn off, the lights will turn on when the ignition switch is placed in the ON position.

### A CAUTION

- When you turn on the headlight switch again after the lights automatically turn off, the lights will not turn off automatically. Be sure to turn the light switch to the OFF position when you leave the vehicle for extended periods of time, otherwise the battery will be discharged.
- Never leave the light switch on when the engine is not running for extended periods of time even if the headlights turn off automatically.

#### Daytime running light system (for NISMO models and Canada)


The daytime running lights automatically illuminate when the engine is started with the parking brake released. The daytime running lights operate with the headlight switch in the OFF position or in the EDGE position. Turn the headlight switch to the position for full illumination when driving at night. (For NISMO models: The daytime running lights will turn off.)


If the parking brake is applied before the engine is started, the daytime running lights do not illuminate. The daytime running lights illuminate once the parking brake is released. The daytime running lights will remain on until the ignition switch is placed in the OFF position.



When the daytime running light system is active, tail lights on your vehicle are not on. It is necessary at dusk to turn on your headlights. Failure to do so could cause an accident injuring yourself and others.








#### Instrument brightness control

The instrument brightness control operates when the ignition switch is in the ON position.

Push the control knob (A) to adjust the brightness of the instrument panel lights. The brightness indicator (B) will be shown briefly in the vehicle information display when the control is turned.

When the brightness level reaches the maximum or minimum, a beep will sound.



#### TURN SIGNAL SWITCH

#### 1 Turn signal


Move the lever up or down to signal the turning direction. When the turn is completed, the turn signals cancel automatically.

#### 2 Lane change signal

To indicate a lane change, move the lever up or down to the point where lights begin flashing.



#### **HORN**




#### FOG LIGHT SWITCH (if so equipped)

To turn the fog lights on, turn the headlight switch to the  ${\rm sp}$  position, then turn the switch to the  ${\rm sp}$  position. To turn them off, turn the switch to the OFF position.

The headlights must be on for the fog lights to operate.

When the headlight switch is in the AUTO position, turning the fog light switch to the \*D position will turn on the headlights, fog lights and the other lights while the ignition switch is in the ON position or the engine is running.




To sound the horn, push the center pad area of the steering wheel.

# **A** WARNING

Do not disassemble the horn. Doing so could affect proper operation of the supplemental front air bag system. Tampering with the supplemental front air bag system may result in serious personal injury.



# VEHICLE DYNAMIC CONTROL (VDC) OFF SWITCH



The vehicle should be driven with the Vehicle Dynamic Control (VDC) system on for most driving conditions.

If the vehicle is stuck in mud or snow, the VDC system reduces the engine output to reduce wheel spin. The engine speed will be reduced even if the accelerator is depressed to the floor. If maximum engine power is needed to free a stuck vehicle, turn the VDC system off.

To turn off the VDC system, push the VDC OFF switch. The  $\mbox{\em \&}\$  indicator light will illuminate.

Push the VDC OFF switch again or restart the engine to turn on the system. (See "Vehicle Dynamic Control (VDC) system" (P.5-41).)

#### **HEATED SEATS (if so equipped)**

# **A** WARNING


Do not use or allow occupants to use the seat heater if you or the occupants cannot monitor elevated seat temperatures or have an inability to feel pain in body parts that contact the seat. Use of the seat heater by such people could result in serious injury.

## **A** CAUTION

- The battery could run down if the seat heater is operated while the engine is not running.
- Do not use the seat heater for extended periods or when no one is using the seat.
- Do not put anything on the seat which insulates heat, such as a blanket, cushion, seat cover, etc.
   Otherwise, the seat may become overheated.
- Do not place anything hard or heavy on the seat or pierce it with a pin or similar object. This may result in

damage to the heater.

- Any liquid spilled on the heated seat should be removed immediately with a dry cloth.
- When cleaning the seat, never use gasoline, thinner, or any similar materials.
- If any malfunctions are found or the heated seat does not operate, turn the switch off and have the system checked by a NISSAN dealer.



The seats are warmed by built-in heaters. The switches located on the center console can be operated independently of each other.

- 1. Start the engine.
- 2. Select heat range.
  - ① For high heat, push the HI (High) side of the switch.
  - 2 For low heat, push the LO (Low) side of the switch.
  - The indicator light in the switch ③ will illuminate when the heater is on.
- To turn off the heater, return the switch to the level position. Make sure the indicator light goes off.




#### **CLOCK** (if so equipped)

The heater is controlled by a thermostat, automatically turning the heater on and off. The indicator light will remain on as long as the switch is on.

When the vehicle's interior is warmed, or before you leave the vehicle, be sure to turn off the switch.

The digital clock (in the audio unit) displays time when the ignition switch is in the ACC or ON position. The clock ON or OFF mode can be selected. For details of the digital clock in the NAVIGATION SYSTEM, refer to "Clock" (P.4-8).

If the power supply is disconnected, the clock will not indicate the correct time. Readjust the time.



#### ADJUSTING THE TIME


Push the CLOCK button 1 to turn the clock on or off.

- Push and hold the CLOCK button 1 until the clock display starts to flash.
- 2. Push the SEEK/TRACK button ② to adjust the hours.
- Push the TUNE/FF-REW button (3) to adjust the minutes.
- 4. Push the CLOCK button (1) again to exit the clock set mode.

The display will return to the regular clock display after 5 seconds.



#### **POWER OUTLET**



The power outlet is located in the instrument panel.

# A CAUTION

- The outlet and plug may be hot during or immediately after use.
- Do not use with accessories that exceed a 12 volt, 120W (10A) power draw. Do not use double adapters or more than one electrical accessory.
- Use power outlet with the engine running to avoid discharging the vehicle battery.

- Avoid using power outlet when the air conditioner, headlights or rear window defroster is on.
- This power outlet is not designed for use with a cigarette lighter unit.
- Push the plug in as far as it will go. If good contact is not made, the plug may overheat or the internal temperature fuse may open.
- Before inserting or disconnecting a plug, be sure the electrical accessory being used is turned OFF.
- When not in use, be sure to close the cap. Do not allow water or any liquid to contact the outlet.

#### **STORAGE**


#### **CUP HOLDERS**




### A CAUTION

- Avoid abrupt starting and braking when the cup holder is being used to prevent spilling the drink. If the liquid is hot, it can scald you or your passenger.
- Use only soft cups in the cup holder. Hard objects can injure you in an accident.





Center console




Door (front and rear)

#### Soft bottle holders

# **A** CAUTION


- Do not use bottle holder for any other objects that could be thrown about in the vehicle and possibly injure people during sudden braking or an accident.
- Do not use bottle holder for open liquid containers.



#### **CARGO FLOOR BOX**

1. To open the cargo floor box, pull the board  $(\mathbf{A})$ .






**GLOVE BOX** 



Keep glove box lid closed while driving to help prevent injury in an accident or a sudden stop.

To open the glove box, pull the handle.

To close, push the lid in until the lock latches. The glove box light illuminates when the head-light switch is turned on.



#### **COAT HOOK**

The coat hook is located above the rear side window.



Do not apply a total load of more than 2 kg (4 lb) to the hook.

CARGO COVER (if so equipped)




#### WARNING

- Never put anything on the cargo cover, no matter how small. Any object on it could cause an injury in an accident or sudden stop.
- Do not leave the cargo cover in the vehicle with it disengaged from the holder.
- The child restraint top tether strap may be damaged by contact with the cargo cover or items in the luggage area. Remove the cargo cover from the vehicle or secure it and any luggage. Your child could be seriously injured or killed in a collision if the top tether strap is damaged.

The cargo cover keeps the luggage compartment contents hidden from the outside.





To install the cargo cover:

- Open the lift gate.
- Fix the clip (A) on the lift gate lower garnish.
- Fix the clip (B) on the lift gate side garnish.
- 4. Hook the rope on the clip located on the lift gate side garnish.

#### **WINDOWS**

#### To remove the cargo cover:

- 1. Open the lift gate.
- 2. Remove the rope from the lift gate side garnish.
- 3. Remove the clip (B) from the lift gate side garnish.
- 4. Remove the clip (A) from the lift gate lower garnish.

#### POWER WINDOWS




### **WARNING**

- Make sure that all passengers have their hands, etc. inside the vehicle while it is in motion and before closing the windows. Use the window lock switch to prevent unexpected use of the power windows.
- Do not leave children unattended inside the vehicle. They could unknowingly activate switches or controls and become trapped in the window. Unattended children could become involved in serious accidents.

The power windows operate when the ignition switch is in the ON position, or for about 45 seconds after the ignition switch is placed in the OFF position. If the driver's or front passenger's door is opened during this period of about 45 seconds, power to the windows is canceled.






- Window lock button.
- 2. Driver side window
- Rear left passenger side window
- 4. Front passenger side window
- 5. Rear right passenger side window

# Main power window switch (driver's side)

To open or close the window, push down (A) or pull up (B) the switch and hold it. The main switch (driver side switches) will open or close all the windows.

#### Locking passengers' windows


When the lock button © is pushed in, only the driver side window can be opened or closed. Push it in again to cancel.



#### Passenger side power window switch

The passenger side switch will open or close only the corresponding window. To open or close the window, push down or pull up the switch and hold it.





#### Automatic operation

The automatic operation is available for the switch that has an /Al mark on its surface.

To fully open or close the window, completely push down or pull up the switch and release it; the switch need not be held. The window will automatically open or close all the way. To stop the window, just push or lift the switch in the opposite direction.

A light push or pull on the switch will cause the window to open or close until the switch is released.

Auto-reverse function



There are some small distances immediately before the closed position which cannot be detected. Make sure that all passengers have their hands, etc., inside the vehicle before closing the window.

If the control unit detects something caught in the window as it is closing, the window will be immediately lowered.

The auto reverse function can be activated when the window is closed by automatic operation when the ignition switch is in the ON position or for 45 seconds after the ignition switch is placed in the OFF position.

Depending on the environment or driving conditions, the auto reverse function may be activated if an impact or load similar to something being caught in the window occurs.

If the windows do not close automatically If the power window automatic function (closing

only) does not operate properly, perform the following procedure to initialize the power window system.

- 1. Place the ignition switch in the ON position.
- 2. Close the door.
- 3. Open the window completely by operating the power window switch.
- 4. Pull the power window switch and hold it to close the window, and then hold the switch more than 3 seconds after the window is closed completely.
- 5. Release the power window switch. Operate the window by the automatic function to confirm the initialization is complete.

If the power window automatic function does not operate properly after performing the procedure above, have your vehicle checked by a NISSAN dealer.



#### **MOONROOF** (if so equipped)

# **A** WARNING

- In an accident you could be thrown from the vehicle through an open moonroof. Always use seat belts and child restraints.
- Do not allow anyone to stand up or extend any portion of their body out of the moonroof opening while the vehicle is in motion or while the moonroof is closing.

## **A** CAUTION

- Remove water drops, snow, ice or sand from the moonroof before opening.
- Do not place any heavy object on the moonroof or surrounding area.


#### POWER MOONROOF

The moonroof only operates when the ignition switch is in the ON position.

The moonroof is operational for about 45 seconds, even if the ignition switch is turned to the OFF position. If the driver's door or the passenger's door is opened during this period of about 45 seconds, power to the moonroof is canceled.

#### Sunshade

The sunshade will open automatically when the moonroof is opened. However, it must be closed manually.



#### Sliding the moonroof

To fully open or close the moonroof, push the switch toward (2) (1) or (2) (2) and release it; it need not be held. The roof will automatically open or close all the way. To stop the roof, push the switch in any direction while it is opening or closing.

#### Tilting the moonroof

To tilt up, first close the moonroof by pushing the switch toward (2) 2. Push the switch toward (2) again and release it; it need not be held. To tilt down the moonroof, push the switch toward (2) 1.



#### Auto reverse function



### WARNING

There are some small distances immediately before the closed position which cannot be detected. Make sure that all passengers have their hands, etc., inside the vehicle before closing the moonroof.

If the control unit detects something caught in the moonroof when it is closing, the moonroof will be immediately opened.

The auto reverse function can be activated when the moonroof is closed by automatic operation when the ignition switch is in the ON position or for about 45 seconds after the ignition switch is turned to the OFF position.

If the moonroof cannot be closed automatically when the auto reverse function activates due to a malfunction, push and hold the switch toward ∠⇒ (2).

Depending on the environment or driving conditions, the auto reverse function may be activated if an impact or load similar to something being caught in the moonroof occurs.

#### If the moonroof does not operate

If the moonroof does not operate properly, perform the following procedure to initialize the moonroof operation system.

- 1. If the moonroof is open, close it fully by repeatedly pushing the switch toward < **(2)**.
- 2. Push and hold the switch toward (2) to tilt the moonroof up.
- 3. Release the moonroof switch after the moonroof moves slightly up and down.
- 4. Push and hold the switch toward (4) (1) to fully tilt the moonroof down.
- 5. Check if the moonroof switch operates normally.

If the moonroof does not operate properly after performing the procedure above, have your vehicle checked by a NISSAN dealer.


#### **INTERIOR LIGHTS**



## A CAUTION

Do not use for extended periods of time with the engine stopped. This could result in a discharged battery.






#### MAP LIGHTS (if so equipped)

Operate the map light switch to turn the map light on or off.

1 : ON position

(2): OFF position



# MAP LIGHT CONTROL SWITCH (if so equipped)

The map lights control switch has three positions: ON (1), OFF (2) and center.

#### ON position

When the switch is in the ON position ①, the map lights will illuminate.

#### OFF position

When the switch is in the OFF position ②, the map lights will not illuminate, regardless of the condition.

#### Center position

When the switch is in the center position, the map lights will illuminate under the following conditions:

- ignition switch is placed in the OFF position (models with Intelligent Key system)
  - remain on for about 15 seconds.
- the key is removed from the ignition switch (models without Intelligent Key system)
  - remain on for about 15 seconds.
- doors are unlocked by pushing the UN-LOCK button (on the keyfob or Intelligent Key) or the request switch (Intelligent Key system equipped model), with the ignition switch in the LOCK position
  - remain on for about 15 seconds.
- any door is opened and then closed with the ignition switch in the LOCK position
  - remain on for about 15 seconds.
- any door is opened with the ignition switch in the ACC or ON position
  - remain on while the door is opened.
     When the door is closed, the lights go off.

The lights will turn off after a period of time when the lights remain illuminated to prevent the battery from becoming discharged.



#### **CARGO LIGHT**

The cargo room lights illuminate when the lift gate is opened. When the lift gate is closed, the lights will turn off.



#### **MEMO**



# 3 Pre-driving checks and adjustments

| Keys   | 3-2  |
|--|------|
| NISSAN Vehicle Immobilizer System keys       | 3-2  |
| Intelligent Keys (if so equipped)            | 3-3  |
| Doors  | 3-4  |
| Locking with key                             | 3-5  |
| Locking with inside lock knob                | 3-5  |
| Locking with power door lock switch          | 3-5  |
| Automatic door locks                         | 3-6  |
| Child safety rear door lock                  | 3-6  |
| Remote keyless entry system (if so equipped) | 3-7  |
| How to use remote keyless entry system       | 3-8  |
| Intelligent Key system (if so equipped)      | 3-10 |
| Intelligent Key operating range              | 3-12 |
| Door locks/unlocks precaution                | 3-12 |
| Intelligent Key operation                    | 3-13 |
| Battery saver system                         | 3-14 |
|  |      |


| Warning lights and audible reminders            | 3-1 |
|---|-----|
| Troubleshooting guide                           | 3-1 |
| How to use remote keyless entry function        | 3-1 |
| Hood  | 3-1 |
| Lift gate                                       | 3-2 |
| Front side and rear unique parts (NISMO models) | 3-2 |
| Fuel-filler door                                | 3-2 |
| Opening the fuel-filler door                    | 3-2 |
| Fuel-filler cap                                 | 3-2 |
| Tilt steering column                            | 3-2 |
| Tilt operation                                  | 3-2 |
| Sun visors                                      | 3-2 |
| Mirrors   | 3-2 |
| Inside mirror                                   | 3-2 |
| Outside mirrors                                 | 3-2 |
| Vanity mirror                                   | 3-2 |
|   |     |



#### **KEYS**

A key number plate is supplied with your keys. Record the key number and keep it in a safe place (such as your wallet), not in the vehicle. If you lose your keys, see a NISSAN dealer for duplicates by using the key number. NISSAN does not record any key numbers so it is very important to keep track of your key number plate.

A key number is only necessary when you have lost all keys and do not have one to duplicate from. If you still have a key, this key can be duplicated by a NISSAN dealer.



- 1. Master key (2 sets)
- 2. Key number plate

# NISSAN VEHICLE IMMOBILIZER SYSTEM KEYS

Your vehicle can only be driven with the master keys which are registered to the NISSAN Vehicle Immobilizer System components in your vehicle. These keys have a transponder chip in the key head.


#### Never leave these keys in the vehicle.

Additional or replacement keys:

If you still have a key, the key number is not necessary when you need extra NISSAN Vehicle Immobilizer System keys. Your dealer can duplicate your existing key. As many as 5 keys can be used with one vehicle. You should bring all the registered keys that you have to a NISSAN dealer for registration. This is because the registration process will erase the memory of all key codes previously registered into the NISSAN Vehicle Immobilizer System. After the registration process, these components will only recognize keys coded into the NISSAN Vehicle Immobilizer System during registration. Any key that is not given to your dealer at the time of registration will no longer be able to start your vehicle.



Do not allow the NISSAN Vehicle Immobilizer System key, which contains an electrical transponder, to come in contact with salt water. This could cause the system to malfunction.



- Intelligent Key (2 sets)
- Mechanical key (inside Intelligent Key) (2 sets)
- Key number plate

#### INTELLIGENT KEYS (if so equipped)

Your vehicle can only be driven with the Intelligent Keys which are registered to your vehicle's Intelligent Key system components and NISSAN Vehicle Immobilizer System components. As many as 4 Intelligent Keys can be registered and used with one vehicle. The new keys must be registered by a NISSAN dealer prior to use with the Intelligent Key system and NISSAN Vehicle Immobilizer System of your vehicle. Since the registration process requires erasing all memory in the Intelligent Key components when registering new keys, be sure to take all Intelligent Keys that you have to the NISSAN dealer.




### A CAUTION

- Be sure to carry the Intelligent Key with you when driving. The Intelligent Key is a precision device with a built-in transmitter. To avoid damaging it, please note the following.
  - The Intelligent Key is water resistant; however, wetting may damage the Intelligent Key. If the Intelligent Key gets wet, immediately wipe until it is completely dry.
  - Do not bend, drop or strike it against another object.
  - If the outside temperature is below 14°F (-10°C) degrees, the battery of the intelligent key may not function properly.
  - Do not place the Intelligent Key for an extended period in a place where temperatures exceed 140°F (60°C).

- Do not change or modify the Intelligent Key.
- Do not use a magnet key holder.
- Do not place the Intelligent Key near an electric appliance such as a television set, personal computer or cellular phone.
- Do not allow the Intelligent Key to come into contact with water or salt water, and do not wash it in a washing machine. This could affect the system function.
- If an Intelligent Key is lost or stolen, NISSAN recommends erasing the ID code of that Intelligent Key. This will prevent the Intelligent Key from unauthorized use to unlock the vehicle. For information regarding the erasing procedure, please contact a NISSAN dealer.





#### Mechanical key

To remove the mechanical key, release the lock knob at the back of the Intelligent Key.

To install the mechanical key, firmly insert it into the Intelligent Key until the lock knob returns to the lock position.

Use the mechanical key to lock or unlock the doors. (See "Doors" (P.3-4).)



### A CAUTION

Always carry the mechanical key installed in the Intelligent Key.


#### **DOORS**



#### **WARNING**

- Always have the doors locked while driving. Along with the use of seat belts, this provides greater safety in the event of an accident by helping to prevent persons from being thrown from the vehicle. This also helps keep children and others from unintentionally opening the doors, and will help keep out intruders.
- Before opening any door, always look for and avoid oncoming traffic.
- Do not leave children unattended inside the vehicle. They could unknowingly activate switches or controls. Unattended children could become involved in serious accidents.






#### LOCKING WITH KEY

The power door lock system allows you to lock or unlock all doors simultaneously.

- Turning the driver's door key cylinder to the front of the vehicle (1) will lock all doors and the lift gate.
- Turning the driver's door key cylinder once to the rear of the vehicle (2) will unlock the driver's door. After returning the key to the neutral position, turning it to the rear again within 5 seconds will unlock all doors and the lift gate.




#### LOCKING WITH INSIDE LOCK KNOB

To lock the door without the key, move the inside lock knob to the lock position (1) then close the door.

To unlock, move the inside lock knob to the unlock position (2).

When locking the door without a key, be sure not to leave the key inside the vehicle.



Driver's armrest

#### LOCKING WITH POWER DOOR LOCK **SWITCH**

Operating the power door lock switch will lock or unlock all the doors. The switch is located on the driver's door armrest.

To lock the doors, push the power door lock switch to the lock position (1) with the driver's door open, then close the door.

#### When locking the door this way, be sure not to leave the key inside the vehicle.

To unlock the doors, push the power door lock switch to the unlock position (2).



#### Lockout protection

Lockout protection function helps to prevent the keys from being accidentally locked inside the vehicle.

#### For models with Intelligent Key system:

- When the power door lock switch is moved to the lock position with the ignition switch placed in the ACC or ON position and any door open, all doors will lock and then unlock automatically.
- When the power door lock switch is moved to the lock position with the Intelligent Key left in the vehicle and any door open, all doors will unlock automatically and a chime will sound after the door is closed.

#### For models without Intelligent Key system:

When the power door lock switch is moved to the lock position with the key in the ignition switch and any door open, all doors will lock and then unlock automatically.

#### AUTOMATIC DOOR LOCKS

- All doors lock automatically when the vehicle speed reaches 15 MPH (24 km/h).
- All doors unlock automatically when the ignition switch is placed in the OFF position (models with Intelligent Key system).


 All doors unlock automatically when the key is removed from the ignition switch (models without Intelligent Key system).

# The automatic unlock function can be deactivated or activated.

To deactivate or activate the automatic door unlock system, perform the following procedure.

- 1. Close all doors.
- 2. Place the ignition switch in the ON position.
- 3. Within 20 seconds of performing step 2.
  - Push and hold the power door lock switch to the (UNLOCK) position for more than 5 seconds.
- When activated, the hazard warning lights will flash twice. When deactivated, the hazard warning lights will flash once.
- The ignition switch must be placed in the OFF and ON position again between each setting change.

When the automatic door unlock system is deactivated, the doors do not unlock when the ignition is placed in the OFF position. To unlock the door manually, use the inside lock knob or the power door lock switch.



#### CHILD SAFETY REAR DOOR LOCK

Child safety rear door locks help prevent the rear doors from being opened accidentally, especially when small children are in the vehicle.

When the levers are in the lock position (1), the rear doors can be opened only from the outside.

To disengage, move the levers to the unlock position (2).



#### REMOTE KEYLESS ENTRY SYSTEM (if so equipped)

It is possible to lock/unlock all doors (including the lift gate), and activate the panic alarm by using the keyfob from outside the vehicle.

#### Before locking the doors, make sure the kev is not left in the vehicle.

The keyfob can operate at a distance of approximately 33 ft (10 m) from the vehicle. (The effective distance depends upon the conditions around the vehicle.)

As many as 5 keyfobs can be used with one vehicle. For information concerning the purchase and use of additional keyfobs, contact a NISSAN dealer.

The keyfob will not function in the following situations.

- When the keyfob is not within the operational range.
- When the doors are open or not closed securely.
- When the ignition switch is in the "ON" position.
- When the battery is discharged.



The remote keyless entry keyfob transmits radio waves when the buttons are pushed. The FAA advises that the radio waves may affect aircraft navigation and communication systems. Do not operate the keyfob while on an airplane. Make sure the buttons are not operated unintentionally when the unit is stored during a flight.



### A CAUTION

The following conditions or occurrences will damage the keyfob.

- Do not allow the keyfob to become wet.
- Do not drop the keyfob.
- Do not strike the keyfob sharply against another object.
- If the outside temperature is below 14°F (-10°C), the battery of the Intelligent Key may not function properly.
- Do not place the keyfob for an extended period in an area where temperatures exceed 140°F (60°C).


If a keyfob is lost or stolen, NISSAN recommends erasing the ID code of that keyfob. This will prevent the keyfob

from unauthorized use to unlock the vehicle. For information regarding the erasing procedure, please contact a NISSAN dealer.

If the indicator light on the keyfob does not illuminate when pushing the buttons, the keyfob battery may be discharged.

For information regarding the replacement of a battery, see "Key battery replacement" (P.8-22).





- 1 LOCK button
- ② UNLOCK button
- 3 PANIC button
- (4) Battery indicator light

# HOW TO USE REMOTE KEYLESS ENTRY SYSTEM

### Locking doors

- 1. Remove the key from the ignition switch.
- 2. Close all the doors.
- 3. Push the LOCK **1** button **1** on the keyfob.
- All the doors will lock.
   All of the doors will lock when the LOCK

- **a** button is pushed even though a door remains open.
- The hazard indicator flashes twice and the horn chirps once.
- When the LOCK button is pushed with all doors locked, the hazard indicator flashes twice and the horn chirps once as a reminder that the doors are already locked.
- Operate the door handles to confirm that the doors have been securely locked.

#### Unlocking doors

- Push the UNLOCK button on the keyfob.
  - · The driver's door unlocks.
  - The hazard indicator flashes once if all doors are completely closed.
- Push the UNLOCK button again within 5 seconds.
  - · All the doors and the lift gate unlock.
  - The hazard indicator flashes once if all doors are completely closed.

All doors will be locked automatically unless one of the following operations is performed within 1 minute of pushing the UNLOCK button.

- Opening any door (including the lift gate).
- Placing the ignition switch in the ON position.

#### Using panic alarm

If you are near your vehicle and feel threatened, you may activate the alarm to call attention as follows:

- Push the PANIC ≱ button ③ on the keyfob for more than 1 second.
- The theft warning alarm and headlights will stay on for 25 seconds.
- 3. The panic alarm stops when:
  - · It has run for 25 seconds, or
  - Any of the buttons on the keyfob is pushed. (Note: the PANIC button must be pushed for more than 1 second.)

#### Battery indicator light

The battery indicator light (4) illuminates when you push any button. If the light does not illuminate, the battery is weak or needs replacement. For information regarding replacement of a battery, see "Key battery replacement" (P.8-22).

Setting hazard indicator and horn mode

This vehicle is set in hazard indicator and horn mode when you first receive the vehicle.

In hazard indicator and horn mode, when the LOCK h button (1) is pushed, the hazard indicator flashes twice and the horn chirps once. When the UNLOCK button (2) is pushed, the hazard indicator flashes once.

If the horn chirp is not necessary, you can switch to hazard indicator only mode by following the switching procedure.


In hazard indicator only mode, when the LOCK button is pushed, the hazard indicator flashes twice. When the UNLOCK a button is pushed, neither the hazard indicator nor the horn operates.

| Mode (Pushing the 🔒 or 🔒 button) | DOOR LOCK                     | DOOR UNLOCK                         |
|----------------------------------|-------------------------------|-------------------------------------|
| Hazard indicator and horn mode   | HAZARD - twice<br>HORN - once | HAZARD - <b>once</b><br>HORN - none |
| Hazard indicator mode            | HAZARD - twice                | HAZARD - none                       |

#### Switching procedure:

To switch the hazard indicator and horn operation, push the LOCK (1) and UNLOCK (2) buttons on the keyfob simultaneously for more than 2 seconds.

- When the hazard indicator mode is set, the hazard indicator flashes 3 times.
- When the hazard indicator and horn mode is set, the hazard indicator flashes once and the horn chirps once.





# INTELLIGENT KEY SYSTEM (if so equipped)

# **A** WARNING

- Radio waves could adversely affect electric medical equipment. Those who use a pacemaker should contact the electric medical equipment manufacturer for the possible influences before use.
- The Intelligent Key transmits radio waves when the buttons are pushed. The FAA advises that the radio waves may affect aircraft navigation and communication systems. Do not operate the Intelligent Key while on an airplane. Make sure the buttons are not operated unintentionally when the unit is stored during a flight.

The Intelligent Key system can operate all the door locks using the remote controller function or pushing the request switch on the vehicle without taking the key out from a pocket or purse. The operating environment and/or conditions may affect the Intelligent Key system operation.

Be sure to read the following before using the Intelligent Key system.

#### 3-10 Pre-driving checks and adjustments



- Be sure to carry the Intelligent Key with you when operating the vehicle.
- Never leave the Intelligent Key in the vehicle when you leave the vehicle.

The Intelligent Key is always communicating with the vehicle as it receives radio waves. The Intelligent Key system transmits weak radio waves. Environmental conditions may interfere with the operation of the Intelligent Key system under the following operating conditions.

- When operating near a location where strong radio waves are transmitted, such as a TV tower, power station and broadcasting station.
- When in possession of wireless equipment, such as a cellular phone, transceiver, and CB radio.
- When the Intelligent Key is in contact with or covered by metallic materials.
- When any type of radio wave remote control is used nearby.
- When the Intelligent Key is placed near an electric appliance such as a personal

- computer.
- When the vehicle is parked near a parking meter.

In such cases, correct the operating conditions before using the Intelligent Key function or use the mechanical key.

Although the life of the battery varies depending on the operating conditions, the battery's life is approximately 2 years. If the battery is discharged, replace it with a new one.

Since the Intelligent Key is continuously receiving radio waves, if the key is left near equipment which transmits strong radio waves, such as signals from a TV and personal computer, the battery life may become shorter.

For information regarding replacement of a battery, see "Key battery replacement" (P.8-22).

As many as 4 Intelligent Keys can be registered and used with one vehicle. For information about the purchase and use of additional Intelligent Keys, contact a NISSAN dealer.




 Do not allow the Intelligent Key, which contains electrical components, to come into contact with water or salt water. This could affect the system function.


- Do not drop the Intelligent Key.
- Do not strike the Intelligent Kev sharply against another object.
- Do not change or modify the Intelligent Kev.
- Wetting may damage the Intelligent Key. If the Intelligent Key gets wet, immediately wipe until it is completely dry.
- If the outside temperature is below 14°F (-10°C) degrees, the battery of the Intelligent Key may not function properly.
- Do not place the Intelligent Key for an extended period in an area where temperatures exceed 140°F (60°C).
- Do not attach the Intelligent Key with a key holder that contains a magnet.
- Do not place the Intelligent Key near equipment that produces a magnetic field, such as a TV, audio equipment, personal computers or cellular phone.

If an Intelligent Key is lost or stolen, NISSAN recommends erasing the ID code of that Intelligent Key from the vehicle. This may prevent the unauthorized use of the Intelligent Key to operate the vehicle. For information regarding the erasing procedure, contact a NISSAN dealer.

The Intelligent Key function can be disabled. For information about disabling the Intelligent Key function, contact a NISSAN dealer.







The Intelligent Key functions can only be used when the Intelligent Key is within the specified operating range from the request switch (1).


When the Intelligent Key battery is discharged or strong radio waves are present near the operating location, the Intelligent Key system's operating range becomes narrower, and the Intelligent Key may not function properly.

The operating range is within 31.50 in (80 cm) from each request switch (1).

If the Intelligent Key is too close to the door glass, handle or rear bumper, the request

switches may not function.

When the Intelligent Key is within the operating range, it is possible for anyone who does not carry the Intelligent Key to push the request switch to lock/unlock the doors including the lift gate.





# DOOR LOCKS/UNLOCKS PRECAUTION


- Do not push the door handle request switch with the Intelligent Key held in your hand as illustrated. The close distance to the door handle will cause the Intelligent Key system to have difficulty recognizing that the Intelligent Key is outside the vehicle.
- After locking with the door handle request switch, verify the doors are securely locked by testing them.
- To prevent the Intelligent Key from being left inside the vehicle, make sure you carry the key with you and then lock the doors.



Do not pull the door handle before pushing the door handle request switch. The door will be unlocked but will not open. Release the door handle once and pull it again to open the door.







#### INTELLIGENT KEY OPERATION

You can lock or unlock the doors without taking the key out from your pocket or bag.

When you carry the Intelligent Key with you, you can lock or unlock all doors by pushing the door handle request switch (driver's or front passenger's) (A) or lift gate request switch (B) within the range of operation.

When you lock or unlock the doors, the hazard indicator will flash and the horn (or the outside chime) will sound as a confirmation. For details, see "Setting hazard indicator and horn mode" (P.3-17).



#### Locking doors

- Place the ignition switch in the OFF position and carry the Intelligent Key with you.\*1
- 2. Close all the doors.\*2
- Push the door handle request switch (driver's or front passenger's) (A) or the lift gate request switch (B) while carrying the Intelligent Key with you.\*3
- 4. All the doors and the lift gate will lock.
- The hazard indicator flashes twice and the outside chime sounds twice.
- \*1: Doors will lock with the request switch while the ignition switch is in the ACC or ON position.
- \*2: Doors will not lock with the request switch while any door is open.
- \*3: Doors will not lock with the request switch when the Intelligent Key is left inside the vehicle. However, when an Intelligent Key is inside the vehicle, doors can be locked with another registered Intelligent Key.

#### Unlocking doors

- Push the door handle request switch (A) or the lift gate request switch (B) while carrying the Intelligent Key with you.
- The hazard indicator flashes once and outside chime sounds once. The corresponding door or the lift gate will unlock.

- Push the request switch again within 1 minute.
- The hazard indicator flashes once and outside chime sounds once again. All the doors and the lift gate will unlock.

All doors will be locked automatically unless one of the following operations is performed within 1 minute after pushing the request switch while the doors are locked.

- Opening any door.
- · Pushing the ignition switch.

During this 1-minute time period, if the UNLOCK button on the Intelligent Key is pushed, all

doors will be locked automatically after another minute.

#### Opening lift gate

- 1. Carry the Intelligent Key.
- 2. Push the lift gate opener switch (c).
- 3. The lift gate will unlock.

#### BATTERY SAVER SYSTEM

When all the following conditions are met for a period of time, the battery saver system will cut off the power supply to prevent battery discharge.

 The ignition switch is in the ACC position, and

- · All doors are closed, and
- The shift lever is in the P (Park) position (Continuously Variable Transmission models).

# WARNING LIGHTS AND AUDIBLE REMINDERS

To help prevent the vehicle from moving unexpectedly by erroneous operation of the Intelligent Key listed on the following chart or to help prevent the vehicle from being stolen, chime or beep sounds inside and outside the vehicle and a warning light illuminates or blinks.

When a chime or beep sounds or the warning light illuminates or blinks, be sure to check the vehicle and Intelligent Key.

See "Troubleshooting guide" (P.3-15) and "Warning/indicator lights and audible reminders" (P.2-12).

Intelligent Key system warning light: 🖺

P position selecting warning light:

### TROUBLESHOOTING GUIDE

|  | Symptom   | Possible cause   | Action to take  |
|--|---|--|---|
| When pushing the ignition switch to stop the engine                | The P position selecting warning light in the meter illuminates and the inside warning chime sounds continuously (Continuously Variable Transmission models).       | The shift lever is not in the P (Park) position.   | Shift the shift lever to the P (Park) position.   |
| When shifting the shift lever to the P (Park) position.            | The inside warning chime sounds continuously (Continuously Variable Transmission models).   | The ignition switch is in the ACC or ON position.  | Push the ignition switch to the OFF position.   |
| When opening the driver's door to get out of the vehicle           | The inside warning chime sounds continuously.   | The ignition switch is in the ACC position.  | Push the ignition switch to the OFF position.   |
| When closing the door after get-<br>ting out of the vehicle        | The Intelligent Key system warning light in the meter blinks in yellow, and the outside chime sounds 3 times and the inside warning chime sounds for a few seconds. | The ignition switch is in the ACC or ON position.  | Push the ignition switch to the OFF position.   |
|  | The P position selecting warning light in the meter illuminates and the outside chime sounds continuously (Continuously Variable Transmission models).              | The ignition switch is in the ACC or OFF position and the shift lever is not in the P (Park) position. | Move the shift lever to the P (Park) position and push the ignition switch to the OFF position. |
| When closing the door with the inside lock knob turned to LOCK     | The outside chime sounds for a few seconds and all the doors unlock.  | The Intelligent Key is inside the vehicle.   | Carry the Intelligent Key with you.   |
| When pushing the request switch                                    |   | The Intelligent Key is inside the vehicle.   | Carry the Intelligent Key with you.   |
| or the LOCK <b>6</b> button on the ntelligent Key to lock the door | A door is not closed securely.  | Close the door securely.   |   |
| When pushing the ignition switch to start the engine               | The Intelligent Key system warning light in the meter blinks in green.  | The battery charge is low.   | Replace the battery with a new one. (See "Key battery replacement" (P.8-22).)                   |
|  | The Intelligent Key system warning light in the meter blinks in yellow and the inside warning chime sounds for a few seconds.                                       | The Intelligent Key is not in the vehicle.   | Carry the Intelligent Key with you.   |
| When pushing the ignition switch                                   | The Intelligent Key system warning light in the meter illuminates in yellow.  | It warns of a malfunction with the Intelligent Key system.   | Contact a NISSAN dealer.  |



#### HOW TO USE REMOTE KEYLESS **ENTRY FUNCTION**



#### WARNING

- Radio waves could adversely affect electric medical equipment. Those who use a pacemaker should contact the electric medical equipment manufacturer for the possible influences before use.
- The Intelligent Key transmits radio waves when the buttons are pushed. The FAA advises that the radio waves may affect aircraft navigation and communication systems. Do not operate the Intelligent Key while on an airplane. Make sure the buttons are not operated unintentionally when the unit is stored during a flight.

### **CAUTION**

Do not allow the Intelligent Key. which contains electrical components, to come into contact with water or salt water. This could affect the system function.

- Do not drop the Intelligent Key.
- Do not strike the Intelligent Kev sharply against another object.
- Do not change or modify the Intelligent Kev.
- Wetting may damage the Intelligent Key. If the Intelligent Key gets wet, immediately wipe until it is completelv drv.
- If the outside temperature is below 14°F (-10°C) degrees, the battery of the intelligent key may not function properly.
- Do not place the Intelligent Key for an extended period in an area where temperatures exceed 140°F (60°C).
- Do not attach the Intelligent Key with a key holder that contains a magnet.
- Do not place the Intelligent Key near equipment that produces a magnetic field, such as a TV, audio equipment, personal computers or cellular phone.


The remote keyless entry function can operate all door locks using the remote keyless entry function of the Intelligent Key. The remote keyless entry function can operate at a distance of approximately 33 ft (10 m) from the vehicle. (The operating distance depends upon the conditions around the vehicle.)

The remote keyless entry function will not operate:

- When the Intelligent Key is not within the operational range.
- When the doors are open or not closed securely.
- When the Intelligent Key battery is discharged.

The remote keyless entry function can also operate the vehicle alarm.

3-16 Pre-driving checks and adjustments



- 1 LOCK **1** button
- ② UNLOCK button
- (3) PANIC ≱ button

When you lock or unlock the doors, the hazard indicator will flash and the horn will sound as a confirmation. For details, see "Setting hazard indicator and horn mode" (P.3-17).

#### Locking doors

- Place the ignition switch in the OFF position and carry the Intelligent Key with you.\*
- 2. Carry the Intelligent Key with you.
- 3. Close all the doors.
- 4. Push the LOCK **6** button **1** on the Intelligent Key.

- 5. All the doors and the lift gate will lock.
- 6. The hazard indicator flashes twice and the horn chirps once.
- \*: Doors will lock with the Intelligent Key while the ignition switch is in the ACC or ON position.

Operate the door handles to confirm that the doors have been securely locked.

#### Unlocking doors

- Push the UNLOCK button on the Intelligent Key once.
- The hazard indicator flashes once. The driver's door will unlock.
- Push the UNLOCK button again within 1 minute.
- The hazard indicator flashes once. All the doors and the lift gate will unlock.

All doors will be locked automatically unless one of the following operations is performed within 1 minute after pushing the UNLOCK button while the doors are locked.

- Opening any door (including the lift gate).
- Pushing the ignition switch.

During this 1-minute time period, if the UNLOCK button is pushed, all doors will be locked automatically after another 1 minute.



#### Using panic alarm

If you are near your vehicle and feel threatened, you may activate the alarm to call attention as follows:

- Push the PANIC ≱ button ③ on the Intelligent Key for more than 1 second.
- The theft warning alarm and headlights will stay on for 25 seconds.
- 3. The panic alarm stops when:
  - It has run for 25 seconds, or

mode when you first receive the vehicle.

 Any of the buttons on the Intelligent Key is pushed. (Note: the PANIC button must be pushed for more than 1 second.)

Setting hazard indicator and horn mode This vehicle is set in hazard indicator and horn

In hazard indicator and horn mode, when the LOCK **1** button **1** is pushed, the hazard indicator flashes twice and the horn chirps once. When the UNLOCK **1** button **2** is pushed, the hazard indicator flashes once.

If horns are not necessary, the system can be switched to the hazard indicator mode.

In hazard indicator mode, when the LOCK button is pushed, the hazard indicator flashes twice. When the UNLOCK button is pushed, neither the hazard indicator nor the

horn operates.

#### Hazard indicator and horn mode:

| Operation  | DOOR LOCK                               | DOOR UNLOCK   |
|--|---|---|
| Pushing door handle request switch or lift gate request switch | HAZARD - twice<br>OUTSIDE CHIME - twice | HAZARD - <b>once</b><br>OUTSIDE CHIME - <b>once</b> |
| Pushing 🔒 or 🔒 button  | HAZARD - twice<br>HORN - once           | HAZARD - <b>once</b><br>HORN - none                 |


#### Hazard indicator mode:

| Operation  | DOOR LOCK                                     | DOOR UNLOCK                           |
|--|---|---------------------------------------|
| Pushing door handle request switch or lift gate request switch | HAZARD - <b>twice</b><br>OUTSIDE CHIME - none | HAZARD - none<br>OUTSIDE CHIME - none |
| Pushing 🚹 or 🔒 button  | HAZARD - <b>twice</b><br>HORN - none          | HAZARD - none<br>HORN - none          |

### Switching procedure:

To switch the hazard indicator and horn (chime) operation, push the LOCK (1) and UNLOCK (2) buttons on the Intelligent Key simultaneously for more than 2 seconds.

- When the hazard indicator mode is set, the hazard indicator flashes 3 times.
- When the hazard indicator and horn mode is set, the hazard indicator flashes once and the horn chirps once.






#### HOOD

# **A** WARNING

- Make sure the hood is completely closed and latched before driving.
   Failure to do so could cause the hood to fly open and result in an accident.
- If you see steam or smoke coming from the engine compartment, to avoid injury do not open the hood.



When opening the hood:

- Pull the hood release handle 1 located below the instrument panel; the hood will then spring up slightly.
- Locate the lever (2) in between the hood and grille, and pull the lever up with your fingertips.
- 3. Raise the hood 3.
- 4. Remove the support rod 4 and insert it into the slot 5.

Hold the coated part (A) when removing or resetting the support rod. Avoid direct contact with the metal parts, as they may be hot immediately after the engine has

#### been stopped.

When closing the hood:


- 1. While supporting the hood, return the support rod to its original position.
- Slowly lower the hood to about 8 to 12 in (20 to 30 cm) above the hood lock, then let it drop.
- 3. Make sure it is securely latched.



#### LIFT GATE

# **A** WARNING

- Always be sure the lift gate has been closed securely to prevent it from opening while driving.
- Do not drive with the lift gate open.
   This could allow dangerous exhaust gases to be drawn into the vehicle.
   See "Exhaust gas (carbon monoxide)" (P.5-3) of this manual.
- Do not leave children unattended inside the vehicle. They could unknowingly activate switches or controls. Unattended children could become involved in serious accidents.
- Make sure that all passengers have their hands, etc. inside the vehicle before closing the lift gate.



To open the lift gate, unlock it and push the lift gate opener switch  $\textcircled{\textbf{A}}$  . Pull up the lift gate to open.

The lift gate can be unlocked by:


- pushing the UNLOCK button on the keyfob or the Intelligent Key (if so equipped) twice.
- pushing the lift gate request switch with the Intelligent Key carried with you (if so equipped).
- pushing the power door lock switch to the unlock position.
- inserting the key into the driver's door key cylinder and turning it to the rear of the vehicle twice.

# FRONT SIDE AND REAR UNIQUE PARTS (NISMO models)

The NISMO models have the following unique parts on the front, side and rear of the vehicle.


- Front bumper (P.6-14)
- Daytime running light (P.2-37, P.8-26, P.8-28)
- Side sill extensions
- Rear spoiler (P.7-3)

#### **FUEL-FILLER DOOR**






Do not place your foot on or step on the front bumper. Also, do not step on the side sill extensions when getting in or out of the vehicle. Doing so may result in damage to the front bumper and side sill extensions.



#### OPENING THE FUEL-FILLER DOOR

To open the fuel-filler door, pull the release handle located below the instrument panel. To lock, close the fuel-filler door securely.



#### **FUEL-FILLER CAP**

To remove the fuel-filler cap:

- 1. Turn the fuel-filler cap counterclockwise (1) to remove.
- 2. Put the fuel-filler cap on the cap holder (A) while refueling.

To install the fuel-filler cap:

- 1. Insert the fuel-filler cap straight into the fuelfiller tube.
- 2. Turn the fuel-filler cap clockwise (2) until a single click is heard.



# **A** WARNING

- Gasoline is extremely flammable and highly explosive under certain conditions. You could be burned or seriously injured if it is misused or mishandled. Always stop engine and do not smoke or allow open flames or sparks near the vehicle when refueling.
- Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically. Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire.
- Use only an original equipment type fuel-filler cap as a replacement. It has a built-in safety valve needed for proper operation of the fuel system and emission control system. An incorrect cap can result in a serious malfunction and possible injury. It could also cause the malfunction indicator light to come on.
- Never pour fuel into the throttle body to attempt to start your vehicle.

- Do not fill a portable fuel container in the vehicle or trailer. Static electricity can cause an explosion of flammable liquid, vapor or gas in any vehicle or trailer. To reduce the risk of serious injury or death when filling portable fuel containers:
  - Always place the container on the ground when filling.
  - Do not use electronic devices when filling.
  - Keep the pump nozzle in contact with the container while you are filling it.
  - Use only approved portable fuel containers for flammable liquid.


# **A** CAUTION

- If fuel is spilled on the vehicle body, flush it away with water to avoid paint damage.
- Insert the cap straight into the fuelfiller tube, then tighten until the fuel-filler cap clicks. Failure to tighten the fuel-filler cap properly may

cause the sweet malfunction indicator light (MIL) to illuminate. If the sight illuminates because the fuel-filler cap is loose or missing, tighten or install the cap and continue to drive the vehicle. The sweet light should turn off after a few driving trips. If the sweet light does not turn off after a few driving trips, have the vehicle inspected by a NISSAN dealer.

For additional information, see "Malfunction Indicator Light (MIL)" (P.2-18).

The LOOSE FUEL CAP warning message will be displayed if the fuel-filler cap is not properly tightened. It may take a few driving trips for the message to be displayed. Failure to tighten the fuel-filler cap properly after the LOOSE FUEL CAP warning message is displayed may cause the Malfunction Indicator Light (MIL) to illuminate.



### LOOSE FUEL CAP warning message

The LOOSE FUEL CAP warning message is displayed on the vehicle information display when the fuel-filler cap is not tightened correctly after the vehicle has been refueled. It may take a few driving trips for the message to be displayed. To turn off the warning message, do the following procedure:

- 1. Remove and install the fuel-filler cap as previously described as soon as possible.
- 2. Tighten the fuel-filler cap until it clicks.
- 3. Push the trip computer mode switch (A) for about 1 second to turn off the LOOSE FUEL CAP warning message after tightening the

fuel cap.


#### **TILT STEERING COLUMN**



Do not adjust the steering wheel while driving. You could lose control of your vehicle and cause an accident.




#### **SUN VISORS**



#### **TILT OPERATION**

Push the lock lever down (1) and adjust the steering wheel up or down (2) to the desired position.


Pull the lock lever up ③ securely to lock the steering wheel in place.



# **A** CAUTION


- Do not store the main sun visor before storing the extension sun visor.
- Do not pull the extension sun visor forcedly downward.
- 1. To block out glare from the front, swing down the main sun visor (1).
- To block glare from the side, remove the main sun visor from the center mount and swing it to the side (2).
- Draw out the extension sun visor (3) from the main sun visor to block from further glare.

#### **MIRRORS**



#### INSIDE MIRROR

Adjust the angle of the inside mirror to the desired position.



The night position (1) will reduce glare from the headlights of vehicles behind you at night.

Use the day position (2) when driving in daylight hours.

# WARNING

Use the night position only when necessary, because it reduces rear view clarity.


#### **OUTSIDE MIRRORS**



# **WARNING**


Objects viewed in the outside mirror on the passenger side are closer than they appear. Be careful when moving to the right. Using only this mirror could cause an accident. Use the inside mirror or glance over your shoulder to properly judge distances to other objects.





# Defrosting outside mirrors (if so equipped)

The outside mirrors will be heated when the rear window defroster switch is operated. (See "Rear window and outside mirror defroster switch" (P.2-35).)



#### Foldable outside mirrors

Fold the outside mirror by pushing it toward the rear of the vehicle.


#### Adjusting outside mirrors

The outside mirror control switch is located at the lower part of the instrument panel.

The outside mirror will operate only when the ignition switch is in the ACC or ON position.

Move the switch right ① or left ② to select the right or left side mirror, then adjust ③ using the control switch.





### **VANITY MIRROR**

To use the front vanity mirror, pull down the sun visor and pull up the cover.



### **MEMO**



# 4 Heater, air conditioner, audio and phone systems

| Safety note                                   | . 4-3 |
|---|-------|
| Control panel buttons - color screen (Type A) | . 4-3 |
| How to use touch screen                       | . 4-4 |
| How to use the BACK button                    | . 4-6 |
| How to use brightness control and display     |       |
| ON/OFF button                                 |       |
| How to use the SETUP button                   |       |
| Control panel buttons — color screen (Type B) | 4-10  |
| How to use touch screen                       | 4-10  |
| How to use the BACK button                    | 4-11  |
| How to use the APPS-i button                  | 4-12  |
| How to use brightness control button          | 4-15  |
| How to use the ON·OFF button/Volume           |       |
| control knob                                  |       |
| How to use the CAMERA button                  | 4-15  |
| RearView monitor (if so equipped)             | 4-15  |
| How to read the displayed lines               | 4-16  |
| Difference between predictive and             |       |
| actual distances                              | 4-17  |
| Adjusting the screen (if so equipped)         | 4-19  |
| Operating tips                                | 4-19  |
| Ventilators                                   | 4-19  |
| Center ventilators                            | 4-19  |
| Side ventilators                              | 4-20  |

| Heater and air conditioner                                 | 4-20 |
|--|------|
| Manual air conditioner (if so equipped)                    | 4-21 |
| Automatic air conditioner (with Integrated                 |      |
| Control System)  | 4-24 |
| Operating tips (for automatic air conditioner)             | 4-27 |
| In-cabin microfilter                                       | 4-27 |
| Servicing air conditioner                                  | 4-27 |
| Audio system   |      |
| Audio operation precautions                                |      |
| FM-AM-SAT radio with Compact Disc (CD) player              |      |
| (Type A)   | 4-41 |
| FM-AM-SAT radio with Compact Disc (CD) player              |      |
| (Type B)   | 4-48 |
| FM-AM-SAT radio with Compact Disc (CD) player              |      |
| (Type C)   |      |
| CD/USB memory care and cleaning                            |      |
| Steering wheel switch for audio control                    |      |
|  | 4-70 |
| NissanConnect <sup>TM</sup> App smartphone integration (if |      |
|  | 4-71 |
| Registering with NissanConnect <sup>TM</sup> App           |      |
| Connect phone  |      |
| Application download                                       | 4-71 |
| Car phone or CB radio                                      | 4-71 |



| Bluetooth® Hands-Free Phone System (Type A)             | 4-72 |
|---|------|
| Regulatory information                                  | 4-74 |
| Using the system  | 4-74 |
| Control buttons   | 4-76 |
| Getting started   | 4-76 |
| List of voice commands                                  | 4-78 |
| Speaker Adaptation (SA) mode                            | 4-82 |
| Troubleshooting guide                                   | 4-84 |
| Bluetooth <sup>®</sup> Hands-Free Phone System (Type B) | 4-85 |
| Regulatory information                                  | 4-86 |
| Voice command   | 4-86 |
| Connecting procedure                                    | 4-87 |
| Vehicle phonebook                                       | 4-87 |
| Making a call   | 4-87 |
| Receiving a call  | 4-88 |
| During a call   | 4-88 |
|   |      |

| Ending a call                                    | 4-8  |
|--|------|
| Text messaging                                   | 4-8  |
| Bluetooth® settings                              | 4-9  |
| Phone settings                                   | 4-9  |
| NISSAN voice recognition system (if so equipped) | 4-9  |
| Using the system                                 | 4-93 |
| System features                                  | 4-9  |
| Bluetooth® hands-free phone system               |      |
| voice commands                                   | 4-9  |
| Navigation system voice commands                 | 4-9  |
| Audio system voice commands                      | 4-9  |
| Information voice commands                       | 4-9  |
| My APPS voice commands                           | 4-9  |
| Help voice commands                              | 4-9  |
| Troubleshooting guide                            | 4-9  |
|  |      |




#### **SAFETY NOTE**

# **WARNING**

- Do not disassemble or modify this system. If you do, it may result in accidents, fire, or electric shock.
- . Do not use this system if you notice any abnormality, such as a frozen screen or lack of sound. Continued use of the system may result in accident, fire or electric shock.
- In case you notice any foreign object in the system hardware, spill liquid on it, or notice smoke or smell coming from it, stop using the system immediately and contact your nearest NISSAN dealer. Ignoring such conditions may lead to accidents, fire, or electric shock.

Do not attempt to operate the system in extreme temperature conditions [below -4°F (-20°C) and above 158°F (70°C)]. Operating this system under these conditions may result in system malfunctions.

#### CONTROL PANEL BUTTONS — **COLOR SCREEN (Type A)**



- \*/) (brightness control) button (P.4-6) 1.
- 2. Display screen
- MAP button\*
- NAV button\*
- TRAF button\*
- SETUP button (P.4-6)
- **BACK** button (P.4-6) 7.

- TUNE/SCROLL knob (P.4-48)
- Power button/Volume control knob (P.4-48)

\*For navigation system control buttons, refer to the separate Navigation System Owner's Manual.

When you use this system, make sure the engine is running.

If you use the system with the engine not running (ignition ON or ACC) for a long time, it will discharge the battery, and the engine will not start.

Reference symbols:

"Example" — Words marked in quotes refer to a key shown only on the display. These keys can be selected by touching the screen.

HOW TO USE TOUCH SCREEN

# **A** CAUTION

- The glass screen on the liquid crystal display may break if it is hit with a hard or sharp object. If the glass screen breaks, do not touch it. Doing so could result in an injury.
- To clean the display, never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or deteriorate the panel.
- Do not splash any liquid such as water or car fragrance on the display. Contact with liquid will cause

#### the system to malfunction.


To help ensure safe driving, some functions cannot be operated while driving.

The on-screen functions that are not available while driving will be "grayed out" or muted.

Park the vehicle in a safe location and then operate the navigation system.



- ALWAYS give your full attention to driving.
- Avoid using vehicle features that could distract you. If distracted, you could lose control of your vehicle and cause an accident.




Touch screen operation

#### Selecting the item:

Touch an item to select. For example, to select the "Audio" key, touch the "Audio" key ① on the screen.









For screens where an item can be adjusted incrementally, such as when adjusting the bass and treble for the audio system, touch the "+" key (1) or the "-" key (2) to adjust the settings of an item.

When there are more items than can be displayed on one screen, touch the up arrow (3) to scroll up the page or touch the down arrow (4) to scroll down the page.



Other items are adjusted by selecting one of a set number of conditions. For example, the Display Mode can be set to "Automatic", "Day" or "Night". To adjust this type of item, touch the item (1). The item will cycle through the available settings and the red indicator lights to the left of the setting condition (2) will come on or turn off accordingly.



### Inputting characters:

Touch the letter key (1).

There are some options available when inputting characters.

#### 123/ABC:

Changes the available character set to numbers.

#### Space:

Inserts a space.

#### Delete:

Deletes the last inputted character with one touch. Touch and hold the "Delete" key to delete all of the characters.



#### OK:

Completes the character input.

#### Touch screen maintenance

If you clean the display screen, use a dry, soft cloth. If additional cleaning is necessary, use a small amount of neutral detergent with a soft cloth. Never spray the screen with water or detergent. Dampen the cloth first and then wipe the screen.

#### HOW TO USE THE BACK BUTTON


Push the **BACK** button to return to the previous screen.

#### HOW TO USE BRIGHTNESS CON-TROL AND DISPLAY ON/OFF BUTTON

To change the display brightness, push the \*/> button. Pushing the button again will change the display to the day or the night display.


If no operation is performed within 5 seconds, the display will return to the previous display.

Push and hold the \*/ button for more than two seconds to turn the display off. Push the button again to turn the display on.



#### HOW TO USE THE SETUP BUTTON

When the SETUP button is pushed, the Setup screen will appear on the display. You can select and/or adjust several functions, features and modes that are available for your vehicle.



#### Audio setup

Select the "Audio" key to adjust the following items to the preferred setting. These settings can also be displayed by pushing the AUDIO button (TUNE/SCROLL knob).

#### Bass, Treble, Balance and Fade:

Controls the sound of the audio system. Balance adjusts the sound between the left and right speakers. Fade adjusts the sound between the front and rear speakers.

#### Speed Volume:

Controls the level to which the volume is adjusted as the vehicle's driving speed changes. Choose a setting between 1 and 5 or choose 0



to disable the feature entirely.

#### **AUX Level:**


Controls the volume level of incoming sound when an auxiliary device is connected to the system. Available options are Quiet, Medium and Loud.

### Navigation setup

Refer to the separate Navigation System Owner's Manual for information regarding this item.


#### XM setup

For SiriusXM Satellite Radio setup, refer to "FM-AM-SAT radio with Compact Disc (CD) player (Type B)" (P.4-48).



### System setup

Select the "System" key to select and/or adjust various functions of the system. A screen with additional options will appear.



#### Display:

Select the "Display" key to adjust the appearance of the display. The following settings can be adjusted:

### Brightness:

The brightness of the display can be set to Very Bright, Bright, Default, Dark or Very Dark. Touch the "Brightness" key to cycle through the options.

#### Display Mode:


The display can be adjusted to fit the level of lighting in the vehicle. Touch the "Display Mode" key to cycle through the options. "Day" and "Night" modes are suited for the respective



times of day, while "Automatic" controls the display automatically.

#### Scroll Direction:

The direction that menus scroll can be adjusted. Choose either "up" or "down".



#### Clock:

Select the "Clock" key to adjust the time and the appearance of the clock on the display. The following settings can be adjusted:

#### • Time Format:

The clock can be set to 12 hours or 24 hours.

#### Use GPS Clock:

When this setting is activated, the clock is set and continually updated via the GPS used by the Navigation System.

#### Set Clock Manually:


When this setting is activated, the clock can be set manually. Touch the "+" or "-" key to adjust the hours and minutes up or down.

#### Daylight Savings Time:

When this setting is activated, daylight savings time is on. Touch the "Daylight Savings Time" key to toggle the setting on or off.

#### Time Zone:

Choose the applicable time zone from the list.



Language:

Select the "Language" key to adjust the language used by the system. The language can be set to English, Français or Español.

#### Touch click:

Select the "Touch Click" key to toggle the touch click feature on or off. When activated, a click sound will be heard every time a key on the screen is touched.

### Beep tones:

Select the "Beep Tones" key to toggle the beep tones feature on or off. When activated, a beep sound will be heard when a pop-up message appears on the screen or a button on the unit (such as the \*/) button) is pushed and held for two seconds.

#### Reset all settings/memory:


Select the "Reset All Settings/Memory" key to return all settings to default and to clear the memory.

### Traffic Info setup

Refer to the separate Navigation System Owner's Manual for information regarding this item.



# CONTROL PANEL BUTTONS — COLOR SCREEN (Type B)



- I. MAP button\*
- 2. Display screen
- 4. APPS□ button (P.4-12)
- 5. (brightness control) button (P.4-6)
- 6. BACK button (P.4-11)

- ON-OFF button/VOL (volume) control knob (P.4-15)
- 8. CAMERA button (P.4-15)
- 9. NAV button\*

\*For information regarding the Navigation system control buttons, refer to the separate Navigation System Owner's Manual.

When you use this system, make sure the engine is running.

If you use the system with the engine not running (ignition ON or ACC) for a long time, it will discharge the battery, and the engine will not start.

Reference symbols:

"Example" — Words marked in quotes refer to a key shown only on the display. These keys can be selected by touching the screen.

HOW TO USE TOUCH SCREEN

# **A** CAUTION

- The glass screen on the liquid crystal display may break if it is hit with a hard or sharp object. If the glass screen breaks, do not touch it. Doing so could result in an injury.
- To clean the display, never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or deteriorate the panel.
- Do not splash any liquid such as water or car fragrance on the display. Contact with liquid will cause

4-10 Heater, air conditioner, audio and phone systems



#### the system to malfunction.


To help ensure safe driving, some functions cannot be operated while driving.

The on-screen functions that are not available while driving will be "grayed out" or muted.

Park the vehicle in a safe location and then operate the navigation system.



- ALWAYS give your full attention to driving.
- Avoid using vehicle features that could distract vou. If distracted, you could lose control of your vehicle and cause an accident.



Touch screen operation

#### Selecting the item:

Touch an item to select. To select the "Audio" key, touch the "Audio" key (1) on the screen.

#### Adjusting the item:

Touch the "+" key or the "-" key to adjust the settings of an item. Touch the up arrow to scroll up the page. Touch the down arrow to scroll down the page.

#### Inputting characters:

Touch the letter or number key. There are some options available when inputting characters.

123/ABC:

Changes the keyboard between numbers and alphabets.

Space:

Inserts a space.

Delete:

Deletes the last inputted character with one touch. Touch and hold the "Delete" key to delete all of the characters.

OK:

Completes the character input.


#### Touch screen maintenance


If you clean the display screen, use a dry, soft cloth. If additional cleaning is necessary, use a small amount of neutral detergent with a soft cloth. Never spray the screen with water or detergent. Dampen the cloth first and then wipe the screen.

#### HOW TO USE THE BACK BUTTON

Push the BACK button to return to the previous screen.







### HOW TO USE THE APPS-I BUTTON

For more information about the "SiriusXM Travel Link", and "SiriusXM Traffic" features, see the separate Navigation System Owner's Manual.

For more information about the "My Apps" key, see "NissanConnect<sup>TM</sup> App smartphone integration" (P.4-71).

For more information about the "Voice Commands" key, see "NISSAN voice recognition system" (P.4-92).

To select and/or adjust several functions, features and modes that are available for your vehicle:

- 1. Push the APPS□ button.
- 2. Touch the "Settings" key.
- 3. Touch the desired item.



|               | Menu Item             | Result   |
|---------------|-----------------------|--|
| Audio         |                       | For more details, see "FM-AM-SAT radio with Compact Disc (CD) player (Type C)" (P.4-57).   |
| Navigation    |                       | See the separate Navigation System Owner's Manual for more information.  |
| Phone & Bluet | tooth                 | For more details, see "Bluetooth <sup>®</sup> Hands-Free Phone System (Type B)" (P.4-85).  |
| System        |                       | Touch this key to select and/or adjust various functions of this system. A screen with additional options will appear.   |
| Dis           | splay                 | Touch this key to adjust the appearance of the display.  |
|               | Brightness            | Adjusts the brightness of the display.   |
|               | Display Mode          | Adjusts to fit the level of lighting in the vehicle. Touch key to cycle through options. "Day" and "Night" modes are suited for the respective times of day while "Auto" controls the display automatically. |
|               | Scroll Direction      | Adjusts the direction of the menu scroll. Choose to either move up or down.  |
| Clo           | ock                   | Touch this key to adjust the time.   |
| •             | Time Format           | The clock can be set to 12 hours or 24 hours.  |
|               | Date Format           | Select from five possible formats of displaying the day, month, and year.  |
|               | Clock Mode            | Adjust the mode for the clock. "Auto" uses the system's GPS to automatically maintain the time. "Manual" allows you to set the clock using the "Set Clock Manually" key.                                     |
|               | Set Clock Manually    | Adjust the clock manually, Touch the "+" or "-" keys to adjust the hours, minutes, day, month and year up or down "Clock Mode" must be set to manual for this option to be available.                        |
|               | Daylight Savings Time | Adjusts the daylight savings time on or off.   |
|               | Time Zone             | Choose the applicable time zone from the list.   |
| Lar           | nguage                | Touch this key to change the language on the display.  |
| Ca            | ımera                 | Touch this key to change the camera settings.  |
| <u> </u>      | Display Mode          | Touch this key to select the touch-screen display mode (day, night, or automatic).   |
|               | Brightness            | Adjust touch-screen brightness.  |
|               | Contrast              | Adjust touch-screen contrast.  |

|         |           | Color                           | Adjust touch-screen color.  |
|---------|-----------|---------------------------------|---|
|         | Temperatu | ure Unit                        | Touch this key to change the temperature unit being displayed (Fahrenheit or Celsius).  |
|         | Touchscre | een click                       | Toggles the touch-screen click feature on or off. When activated a click sound will be heard every time a key on the screen is touched.   |
|         | System B  | eeps                            | Toggle the system beep tones feature on or off. When activated, a beep sound will be heard when a pop-up message appears on the screen or a button on the unit (such as the **/> **/******************************* |
|         | Return to | Factory Settings / Clear Memory | Touch this key to return all settings to default and to clear the memory.   |
|         | Software  | Licenses                        | Touch this key to display software licensing information.   |
| Traffic |           |                                 | Touch this key to display traffic settings. See the separate Navigation System Owner's Manual for more information.   |
| SXM     |           |                                 | Touch this key to display SXM status information. For SXM setup, see "FM-AM-SAT radio with Compact Disc (CD) player (Type C)" (P.4-57).   |



# HOW TO USE BRIGHTNESS CONTROL BUTTON

To change the display brightness, push the \*/>
button. Pushing the button again will change the display to the day or the night display.

If no operation is performed within 5 seconds, the display will return to the previous display.

Push and hold the \*/ button for more than two seconds to turn the display off. Push the button again to turn the display on.

#### HOW TO USE THE ON-OFF BUTTON/ VOLUME CONTROL KNOB

Push the ON-OFF button to turn audio function on and off. Turn the volume control knob to adjust audio volume.

#### HOW TO USE THE CAMERA BUTTON

For more information regarding the CAMERA button, see "RearView monitor" (P.4-15).

# **REARVIEW MONITOR** (if so equipped)

When the shift lever is shifted into the R (Reverse) position, the monitor display shows the view to the rear of the vehicle.

The system is designed as an aid to the driver in situations such as slot parking or parallel parking.



# WARNING

Failure to follow the warnings and instructions for proper use of the Rear-View Monitor could result in serious injury or death.

- The RearView monitor is a convenience but it is not a substitute for proper backing. Always turn and look out the windows, and check mirrors to be sure that it is safe to move before operating the vehicle. Always back up slowly.
- The system is designed as an aid to the driver in showing large stationary objects directly behind the vehicle, to help avoid damaging the vehicle.
- The system cannot completely eliminate blind spots and may not show every object.


- Underneath the bumper and the corner areas of the bumper cannot be viewed on the RearView Monitor because of its monitoring range limitation. The system will not show small objects below the bumper, and may not show objects close to the bumper or on the ground.
- Objects viewed in the RearView Monitor differ from actual distance because a wide-angle lens is used.
- Objects in the RearView Monitor will appear visually opposite than when viewed in the rear view and outside mirrors.
- Make sure that the lift gate is securely closed when backing up.
- Do not put anything on the Rear-View camera. The RearView camera is installed above the license plate.
- When washing the vehicle with high-pressure water, be sure not to spray it around the camera. Otherwise, water may enter the camera unit causing water condensation on the lens, a malfunction, fire or an electric shock.



 Do not strike the camera. It is a precision instrument. Otherwise, it may malfunction or cause damage resulting in a fire or an electric shock.



Do not scratch the camera lens when cleaning dirt or snow from the lens.



# HOW TO READ THE DISPLAYED LINES

Guiding lines which indicate the vehicle width and distances to objects with reference to the bumper line (A) are displayed on the monitor.

Distance guide lines:


Indicate distances from the bumper.

- Red line 1 : approx. 1.5 ft (0.5 m)
- Yellow line (2): approx. 3 ft (1 m)
- Green line 3: approx. 7 ft (2 m)
- Green line 4 : approx. 10 ft (3 m)

Vehicle width guide lines (5):

Indicate the vehicle width when backing up.






# Models with CAMERA button (if so equipped):

The on-screen guidelines can be set to on or off.


- With the shift lever in the R (Reverse) position:
  - Push the CAMERA button to toggle the feature on and off.
- With the shift lever in any position other than the R (Reverse) position:
  - 1) Push the CAMERA button.
  - 2) Touch the "Show Guidelines" key to toggle the feature on or off.



# DIFFERENCE BETWEEN PREDICTIVE AND ACTUAL DISTANCES

### Backing up on a steep uphill

When backing up the vehicle up a hill, the distance guide lines and the vehicle width guide lines are shown closer than the actual distance. For example, the display shows 3 ft (1 m) to the place (A), but the actual 3 ft (1 m) distance on the hill is the place (B). Note that any object on the hill is viewed in the monitor further than it appears.




# Backing up on a steep downhill

When backing up the vehicle down a hill, the distance guide lines and the vehicle width guide lines are shown further than the actual distance. For example, the display shows 3 ft (1 m) to the place (a), but the actual 3 ft (1 m) distance on the hill is the place (B). Note that any object on




the hill is viewed in the monitor closer than it appears.



Backing up near a projecting object

The vehicle may seem to nearly clear the object in the display. However, the vehicle may hit the object if it projects over the actual backing up course.





Backing up behind a projecting object

The position (c) is shown further than the position (d) in the display. However, the position (c) is actually at the same distance as the position (d). The vehicle may hit the object when backing up to the position (d) if the object projects over the actual backing up

course.

### ADJUSTING THE SCREEN (if so equipped)


For detailed information, see "How to use the APPS-i button" (P.4-12).

#### **OPERATING TIPS**

- When the shift lever is shifted to the R (Reverse) position, the monitor screen automatically changes to the RearView Monitor mode. However, the radio can be heard.
- When the view is switched, the display images on the screen may be displayed with some delay.
- When the temperature is extremely high or low, the screen may not clearly display objects. This is not a malfunction.
- When strong light is directly coming on the camera, objects may not be displayed clearly. This is not a malfunction.
- Vertical lines may be seen in objects on the screen. This is due to strong reflected light from the bumper. This is not a malfunction.
- The screen may flicker under fluorescent light. This is not a malfunction.
- The colors of objects on the RearView Monitor may differ somewhat from the actual color of objects. This is not a malfunction.

#### **VENTILATORS**

- Objects on the monitor may not be clear in a dark environment. This is not a malfunction.
- If dirt, rain or snow accumulates on the camera, the RearView Monitor may not display objects clearly. Clean the camera.
- Do not use alcohol, benzine or thinner to clean the camera. This will cause discoloration. To clean the camera, wipe with a cloth dampened with diluted mild cleaning agent and then wipe with a dry cloth.
- Do not damage the camera as the monitor screen may be adversely affected.
- Do not use wax on the camera window. Wipe off any wax with a clean cloth dampened with mild detergent diluted with water.




### CENTER VENTILATORS

Adjust the air flow direction of ventilators as illustrated.

Adjust the air flow direction of the ventilators by moving the center knob (up/down and left/right) until the preferred position is achieved.



#### **HEATER AND AIR CONDITIONER**



#### SIDE VENTILATORS

Open or close the vents, and adjust the air flow direction of ventilators as illustrated.

### **WARNING**


- The air conditioner cooling function operates only when the engine is running.
- Do not leave children or adults who would normally require the support of others alone in your vehicle. Pets should not be left alone either. On hot, sunny days, temperatures in a closed vehicle could quickly become high enough to cause severe or possibly fatal injuries to people or animals.
- Do not use the recirculation mode for long periods as it may cause the interior air to become stale and the windows to fog up.

Start the engine and operate the heater and the air conditioner system.

#### NOTE:

- Odors from inside and outside the vehicle can build up in the air conditioner unit. Odor can enter the passenger compartment through the vents.
- When parking, set the heater and air conditioner controls to turn off air

recirculation to allow fresh air into the passenger compartment. This should help reduce odors inside the vehicle.



- Air intake lever (Outside air circulation ← /Air recirculation ← )
- 2. Air flow control dial
- 3. Fan speed control 🐉 dial
- 4. A/C (Air Conditioner) button
- 5. Temperature control dial
- Rear window defroster [ttt] button (See "Rear window and outside mirror defroster switch" (P.2-35).)

# MANUAL AIR CONDITIONER (if so equipped)

To turn off the heater and air conditioner, turn the fan speed control \* dial to the OFF (0) position.

#### Controls

#### Outside air circulation:

Move the air intake lever to the sposition. The air flow is drawn from outside the vehicle.

#### Air recirculation:

Move the air intake lever to the Sposition. The air flow is circulated inside the vehicle.

#### Air flow control:

Turn the air flow control dial to change the air flow mode.

- Air flows from the center and side ventilators.
- Air flows from the center and side ventilators and foot outlets.
- Air flows mainly from the foot outlets.
- Air flows from the defroster and foot outlets.
- Air flows mainly from the defroster outlets.
- When the more of the air conditioner will automatically turn on.
   This will dehumidify the air and help to defog the windows.



#### Fan speed control:

Turn the fan speed control speed dial clockwise to increase the fan speed.

Turn the fan speed control \* dial counter-clockwise to decrease the fan speed.

#### A/C (Air Conditioner) operation:

Push the A/C button to turn on or off the air conditioner. When the air conditioner is on, the A/C indicator light on the button illuminates.

#### Temperature control:

Turn the temperature control dial to set the desired temperature. Turn the dial between the middle and the right position to select the hot temperature. Turn the dial between the middle and the left position to select the cool temperature.

#### Heater operation

#### Heating:

This mode is used to direct heated air to the foot outlets.

- Move the air intake lever to the sposition.
- 2. Turn the air flow control dial to the position.
- Turn the fan speed control dial to the desired position.

 Turn the temperature control dial to the desired position between the middle and the hot (right) position.

#### Ventilation:

This mode directs outside air to the side and center ventilators.

- 1. Move the air intake lever to the 😂 position.
- 2. Turn the air flow control dial to the position.
- Turn the fan speed control state dial to the desired position.

#### **Defrosting or defogging:**

This mode directs the air to the defroster outlets to defrost/defog the windows.

- 1. Move the air intake lever to the 😂 position.
- 2. Turn the air flow control dial to the work position.
- Turn the fan speed control st dial to the desired position.
- Turn the temperature control dial to the desired position between the middle and the hot (right) position.
- To remove frost from the outside surface of the windshield quickly, turn the temperature control dial to the maximum hot position and the fan speed control dial to the maximum position.

 When the wo position is selected, the air conditioner will automatically turn on. This will dehumidify the air and help to defog the windows.

#### Bi-level heating:

This mode directs cool air from the side and center vents and warm air from the foot outlets. When the temperature control dial is turned to the maximum hot or cool position, the air between the ventilators and the foot outlets is the same temperature.

- Move the air intake lever to the sposition.
- Turn the air flow control dial to the position.
- Turn the fan speed control state dial to the desired position.
- Turn the temperature control dial to the desired position.

#### Heating and defogging:

This mode heats the interior and defogs the windows.

- Move the air intake lever to the sposition.
- Turn the air flow control dial to the position.
- 3. Turn the fan speed control \* dial to the desired position.

4. Turn the temperature control dial to the desired position.

When the position is selected, the air conditioner will automatically turn on. This will dehumidify the air and help to defog the windows.

### Air conditioner operation

The air conditioner system should be operated for approximately 10 minutes at least once a month. This helps prevent damage to the air conditioner system due to the lack of lubrication.

#### Cooling:

This mode is used to cool and dehumidify the air.

- 1. Move the air intake lever to the seposition.
- 2. Turn the air flow control dial to the position.
- 3. Turn the fan speed control # dial to the desired position.
- 4. Push the A/C button on (The A/C indicator light will illuminate.)
- 5. Turn the temperature control dial to the desired position between the middle and the cool (left) position.
- For quick cooling when the outside temperature is high, move the air intake lever to the Exposition. Be sure to move the air intake lever to the 😂 position for normal

- cooling.
- A visible mist may be seen coming from the ventilators in hot, humid conditions as the air is cooled rapidly. This does not indicate a malfunction.

#### **Dehumidified heating:**

This mode is used to heat and dehumidify the air.

- 1. Move the air intake lever to the seposition.
- 2. Turn the air flow control dial to the ... position.
- 3. Turn the fan speed control # dial to the desired position.
- 4. Push the A/C button on. (The A/C indicator light will illuminate.)
- 5. Turn the temperature control dial to the desired position between the middle and the hot (right) position.


#### Dehumidified defogging:

This mode is used to defog the windows and dehumidify the air.

- 1. Move the air intake lever to the seposition.
- 2. Turn the air flow control dial to the with position.
- 3. Turn the fan speed control 🔅 dial to the desired position.

4. Turn the temperature control dial to the desired position.

When the position is selected, the air conditioner will automatically turn on. This will dehumidify the air and help to defog the windows.



- 1. AUTO button/Temperature control dial
- 2. OFF button
- 3. A/C button
- 4. CLIMATE button
- Display screen\*
- 6. Air flow control buttons
- 7. Fan speed control 🛊 dial

- 8. Front defroster 🙀 button
- Air intake button (Outside air circulation ← /Air recirculation ← )
- Rear window defroster (133) button (See "Rear window and outside mirror defroster switch" (P.2-35).)
- \*: Temperature is displayed in °F (US) or °C (Canada).

# AUTOMATIC AIR CONDITIONER (with Integrated Control System)

### Automatic operation (AUTO)

The AUTO mode may be used year-round as the system automatically controls constant temperature, air flow distribution and fan speed.

To turn off the heater and air conditioner, push the CLIMATE button to change to the Climate Control Mode, then push the OFF button.

#### Cooling and dehumidified heating:

- Push the AUTO button. (The AUTO indicator will be displayed.)
- Turn the temperature control dial to set the preferred temperature. The temperature range is between 60°F (18°C) and 90°F (32°C).

A visible mist may be seen coming from the ventilators in hot, humid conditions as the air is cooled rapidly. This does not indicate a malfunction.

#### Heating (A/C off):

- Push the CLIMATE button to change to the Climate Control Mode.
- Push the AUTO button. (The AUTO indicator will be displayed.)

#### 4-24 Heater, air conditioner, audio and phone systems

- 3. If the A/C indicator light illuminates, push the A/C button. (The A/C indicator light will turn off.)
- 4. Turn the temperature control dial to set the preferred temperature. The temperature range is between 60°F (18°C) and 90°F (32°C).
  - Do not set the temperature lower than the outside air temperature. Doing so may cause the temperature to not be controlled properly.
  - If the windows fog up, use dehumidified heating by pushing the A/C button (the A/C indicator light will illuminate).

#### Dehumidified defrosting/defogging:

- 1. Push the front defroster w button, (The indicator light will illuminate.)
- 2. Turn the temperature control dial to set the preferred temperature.
  - · To remove moisture or fog on the front window quickly, set the temperature to the high temperature and the fan speed to their maximum level.
  - After the windshield is cleared, push the front defroster w button again. (The indicator light will turn off.)
  - When the front defroster w button is pushed, the air conditioner will automa-

tically turn on to defog the windshield. The outside air circulation mode will be selected to improve the defogging performance.

• When the position is selected, the air recirculation mode cannot be turned on to prevent the windows from being fogged up.

#### Manual operation

The manual mode can be used to control the heater and air conditioner to your desired settings.

To turn off the heater and air conditioner, push the OFF button.

If the Drive Mode is indicated on the screen. push the CLIMATE button to change to the Climate Control Mode, then push the OFF button.

#### Fan speed control:

Turn the fan speed control 🤰 dial to adjust the fan speed.

#### Air flow control:

Push the air flow control buttons to change the air flow mode:

Air flows from the center and side ventilators.

Air flows from the center and side ventilators and foot outlets.

Air flows mainly from the foot outlets.

Air flows from the defroster outlets and foot outlets.

#### Temperature control:

Turn the temperature control dial to set the preferred temperature.

The temperature range is between 60°F (18°C) and 90°F (32°C).

#### Air recirculation:

Push the air intake button to change the air circulation mode. When the indicator light illuminates, the flowing air is recirculated inside the vehicle.

• When the war or war position is selected, the air recirculation mode cannot be turned on to prevent the windows from being fogged up.

#### Outside air circulation:

Push the air intake button to change the air circulation mode. When the indicator light illuminates, the flowing air is drawn from outside the vehicle.




#### Automatic air intake control:


Push and hold the outside air circulation " ' hair recirculation " button for more than 1.5 seconds to set the automatic control between the outside air circulation and air recirculation modes.

When the " w " or " m position is selected, the air recirculation mode does not activate.

When setting the automatic control mode, the indicator lights ">" and ">" will blink twice indicating that the system is in the automatic control mode.



Air conditioner mode screen



#### Displaying Climate control

When in "Climate Control Mode", the selected temperature and airflow, and automatic mode or manual mode are indicated on the display.

When in "Drive Mode", the same items as above are indicated, but on the bottom of the display.


To switch to "Climate Control Mode", push the CLIMATE control mode select button.


#### Setting climate ECO

When in "Drive Mode", CLIMATE ECO can be switched on or off. When CLIMATE ECO is switched on, the climate control system operates to enhance fuel economy.

See "Setting the climate ECO mode" (P.5-28).







#### OPERATING TIPS (for automatic air conditioner)

- When the engine coolant temperature and outside air temperature are low, the air flow from the foot outlets may not operate. This is not a malfunction. After the coolant temperature warms up, air will flow normally from the foot outlets.
- The automatic air conditioner is equipped with sensors as illustrated. The sensors (A) and (B) on the instrument panel help maintain a constant temperature. Do not put anything on or around these sensors.

#### IN-CABIN MICROFILTER

The air conditioning system is equipped with an in-cabin microfilter which collects dirt, pollen, dust, etc. To make sure the air conditioner heats. defogs, and ventilates efficiently, replace the filter according to the specified maintenance log shown in the NISSAN Service and Maintenance Guide. To replace the filter, contact a NISSAN dealer.

The filter should be replaced if the air flow decreases significantly or if windows fog up easily when operating the heater or air conditioning system.

#### SERVICING AIR CONDITIONER

The air conditioner system in your NISSAN is charged with a refrigerant designed with the environment in mind. This refrigerant will not harm the earth's ozone layer. Special charging equipment and lubricant are required when servicing your NISSAN air conditioner. Using improper refrigerants or lubricants will cause severe damage to your air conditioner system. (See "Capacities and recommended fuel/lubricants" (P.9-2) for air conditioner system refrigerant and lubricant recommendations.)

A NISSAN dealer will be able to service your environmentally friendly air conditioner system.



The system contains refrigerant under high pressure. To avoid personal injury, any air conditioner service should be done only by an experienced technician with the proper equipment.



#### **AUDIO SYSTEM**

#### **AUDIO OPERATION PRECAUTIONS**

#### Radio

Place the ignition switch in the ACC or ON position and push the PWR (power/VOL (volume)) control to turn on the radio. If you listen to the radio with the engine not running, the ignition switch should be placed in the ACC position.

Radio reception is affected by station signal strength, distance from radio transmitter, buildings, bridges, mountains and other external influences. Intermittent changes in reception quality normally are caused by these external influences.

Using a cellular phone in or near the vehicle may influence radio reception quality.

#### Radio reception:


Your NISSAN radio system is equipped with state-of-the-art electronic circuits to enhance radio reception. These circuits are designed to extend reception range, and to enhance the quality of that reception.

However there are some general characteristics of both FM and AM radio signals that can affect radio reception quality in a moving vehicle, even when the finest equipment is used. These characteristics are completely normal in a given reception area, and do not indicate any mal-

function in your NISSAN radio system.

Reception conditions will constantly change because of vehicle movement. Buildings, terrain, signal distance and interference from other vehicles can work against ideal reception. Described below are some of the factors that can affect your radio reception.

Some cellular phones or other devices may cause interference or a buzzing noise to come from the audio system speakers. Storing the device in a different location may reduce or eliminate the noise.



#### FM radio reception:

Range: FM range is normally limited to 25 to 30 miles (40 to 48 km), with monaural (single station) FM having slightly more range than stereo FM. External influences may sometimes interfere with FM station reception even if the FM station is within 25 miles (40 km). The strength of the FM signal is directly related to the distance between the transmitter and receiver. FM signals follow a line-of-sight path, exhibiting many of the same characteristics as light. For example they will reflect off objects.

Fade and drift: As your vehicle moves away from a station transmitter, the signals will tend to fade and/or drift.



4-28 Heater, air conditioner, audio and phone systems

Static and flutter: During signal interference from buildings, large hills or due to antenna position, usually in conjunction with increased distance from the station transmitter, static or flutter can be heard. This can be reduced by lowering the treble setting to reduce the treble response.

Multipath reception: Because of the reflective characteristics of FM signals, direct and reflected signals reach the receiver at the same time. The signals may cancel each other, resulting in momentary flutter or loss of sound.

#### AM radio reception:

AM signals, because of their low frequency, can bend around objects and skip along the ground. In addition, the signals can be bounced off the ionosphere and bent back to earth. Because of these characteristics. AM signals are also subject to interference as they travel from transmitter to receiver.

Fading: Occurs while the vehicle is passing through freeway underpasses or in areas with many tall buildings. It can also occur for several seconds during ionospheric turbulence even in areas where no obstacles exist.

Static: Caused by thunderstorms, electrical power lines, electric signs and even traffic lights.

#### Satellite radio reception (if so equipped):


When the satellite radio is used for the first time or the battery has been replaced, the satellite radio may not work properly. This is not a malfunction. Wait more than 10 minutes with the satellite radio ON and the vehicle away from any metal or large buildings for the satellite radio to receive all of the necessary data.

The satellite radio mode requires an active SiriusXM Satellite Radio subscription. The satellite radio is not available in Alaska, Hawaii and Guam.

Satellite radio performance may be affected if cargo carried on the roof blocks the satellite radio signal.

If possible, do not put cargo near the satellite antenna.

A buildup of ice on the satellite radio antenna can affect satellite radio performance. Remove the ice to restore satellite radio reception.



### Compact Disc (CD) player

- Do not force a compact disc into the CD insert slot. This could damage the CD and/or CD player.
- During cold weather or rainy days, the player may malfunction due to the humidity. If this occurs, remove the CD



Heater, air conditioner, audio and phone systems 4-29

and dehumidify or ventilate the player completely.

- The player may skip while driving on rough roads.
- The CD player sometimes cannot function when the passenger compartment temperature is extremely high. Decrease the temperature before use.
- Only use high quality 4.7 in (12 cm) round discs that have the "COMPACT disc DIGITAL AUDIO" logo on the disc or packaging.
- Do not expose the CD to direct sunlight.
- CDs that are of poor quality, dirty, scratched, covered with fingerprints, or that have pin holes may not work properly.
- The following CDs may not work properly:
  - Copy control compact discs (CCCD)
  - Recordable compact discs (CD-R)
  - Rewritable compact discs (CD-RW)
- Do not use the following CDs as they may cause the CD player to malfunction.
  - 3.1 in (8 cm) discs

- CDs that are not round
- CDs with a paper label
- CDs that are warped, scratched, or have abnormal edges
- This audio system can only play prerecorded CDs. It has no capabilities to record or burn CDs.
- If the CD cannot be played, one of the following messages will be displayed.
   Check Disc:
  - Confirm that the CD is inserted correctly (the label side is facing up, etc.).
  - Confirm that the CD is not bent or warped and it is free of scratches.

#### **Push Eject:**

This is an error due to the temperature inside the player is too high. Remove the CD by pushing the EJECT button, and after a short time reinsert the CD. The CD can be played when the temperature of the player returns to normal.

#### **Unplayable Track:**

The file is unplayable in this audio system (only MP3 or WMA CD).

# Interface System for iPod® (models without USB port)

- Some characters used in other languages (Chinese, Japanese, etc.) are not displayed properly on the vehicle display. We recommend using English language characters with an iPod<sup>®</sup>.
- Large video podcast files cause slow responses in the iPod<sup>®</sup>. The vehicle display may momentarily black out, but it will soon recover.
- If the iPod<sup>®</sup> automatically selects large video podcast files while in the shuffle mode, the vehicle display may momentarily black out, but it will soon recover.
- Improperly plugging in the iPod<sup>®</sup> may cause a checkmark to be displayed on and off (flickering). Always make sure that the iPod<sup>®</sup> is connected properly.
- The iPod nano<sup>®</sup> (2nd Generation) will continue to fast forward or rewind if it is disconnected during a seek operation.
- An incorrect song title may appear when the Play Mode is changed while using the iPod nano<sup>®</sup> (2nd Generation).
- Audiobooks may not play in the same order as they appear on the iPod<sup>®</sup>.



- The iPod nano<sup>®</sup> (1st Generation) may remain in fast forward or rewind mode if it is connected during a seek operation. In this case, please manually reset the iPod<sup>®</sup>.
- If you are using an iPod<sup>®</sup> (3rd Generation with Dock connector), do not use very long names for the song title, album name or artist name to avoid the iPod<sup>®</sup> from resetting itself.
- Be careful not to do the following, or the cable could be damaged and a loss of function may occur.
  - Bend the cable excessively (1.6 in (40 mm) radius minimum).
  - Twist the cable excessively (more than 180 degrees).
  - Pull or drop the cable.
  - Store objects with sharp edges in the storage where the cable is stored.
  - Spill liquids on the cable and connectors.
- Do not connect the cable to the iPod<sup>®</sup> if the cable and/or connectors are wet. It may damage the iPod<sup>®</sup>.
- If the cable and connectors are exposed to water, allow the cable and/or connectors to dry completely before connecting the cable to the iPod<sup>®</sup> (wait 24 hours for it to dry).

- If the connector is exposed to fluids other than water, evaporative residue may cause a short between the connector pins. In this case, replace the cable, otherwise damage to the iPod<sup>®</sup> and a loss of function may occur.
- If the cable is damaged (insulation cut, connectors cracked, contamination such as liquids, dust, dirt, etc. in the connectors), do not use the cable and contact a NISSAN dealer to replace the cable with a new one.
- When not in use for extended periods of time, store the cable in a clean, dust free environment at room temperature and without direct sun exposure.
- Do not use the cable for any other purposes other than its intended use in the vehicle.
- iPod<sup>®</sup> charging is only possible for devices that support charging via a FireWire<sup>®</sup> connection.
- \* 12V-charge iPod<sup>®</sup>s are not chargeable with this system.
- \* iPod<sup>®</sup>, iPhone<sup>®</sup> and FireWire<sup>®</sup> are trademarks of Apple Inc., registered in the U.S. and other countries.

USB (Universal Serial Bus) device (if so equipped)



### WARNING

Do not connect, disconnect or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.

## **A** CAUTION

- Do not force the USB device into the USB port. Inserting the USB device tilted or up-side-down into the port may damage the port. Make sure that the USB device is connected correctly into the USB port.
- Do not grab the USB port cover (if so equipped) when pulling the USB device out of the port. This could damage the port and the cover.
- Do not leave the USB cable in a place where it can be pulled unintentionally. Pulling the cable may damage the port.



The vehicle is not equipped with a USB device. USB devices should be purchased separately as necessary.

This system cannot be used to format USB devices. To format a USB device, use a personal computer.

In some states/area, the USB device for the front seats plays only sound without images for regulatory reasons, even when the vehicle is parked.

This system supports various USB memory devices, USB hard drives and iPod<sup>®</sup> players. Some USB devices may not be supported by this system.

- Partitioned USB devices may not be played correctly.
- Some characters used in other languages (Chinese, Japanese, etc.) are not displayed properly on display. Using English language characters with a USB device is recommended.

#### General notes for USB use:

Refer to your device manufacturer's owner information regarding the proper use and care of the device.

#### Notes for iPod® use:

iPod<sup>®</sup> is a trademark of Apple Inc., registered in the U.S. and other countries.

- Improperly plugging in the iPod<sup>®</sup> may cause a checkmark to be displayed on and off (flickering). Always make sure that the iPod<sup>®</sup> is connected properly.
- An iPod nano<sup>®</sup> (1st Generation) may remain in fast forward or rewind mode if it is connected during a seek operation. In this case, please manually reset the iPod<sup>®</sup>.
- An iPod nano<sup>®</sup> (2nd Generation) will continue to fast-forward or rewind if it is disconnected during a seek operation.
- An incorrect song title may appear when the Play Mode is changed while using an iPod nano<sup>®</sup> (2nd Generation)
- Audiobooks may not play in the same order as they appear on an iPod<sup>®</sup>.
- Large video files cause slow responses in an iPod<sup>®</sup>. The vehicle center display may momentarily black out, but will soon recover.
- If an iPod<sup>®</sup> automatically selects large video files while in the shuffle mode, the vehicle center display may momentarily black out, but will soon recover.


### Compressed Audio Files (MP3/WMA)

#### **Explanation of terms:**

- MP3 MP3 is short for Moving Pictures Experts Group Audio Layer 3. MP3 is the most well known compressed digital audio file format. This format allows for near "CD quality" sound, but at a fraction of the size of normal audio files. MP3 conversion of an audio track can reduce the file size by approximately a 10:1 ratio (Sampling: 44.1 kHz, Bit rate: 128 kbps) with virtually no perceptible loss in quality. The compression reduces certain parts of sound that seem inaudible to most people.
- WMA Windows Media Audio (WMA) is a compressed audio format created by Microsoft as an alternative to MP3. The WMA codec offers greater file compression than the MP3 codec, enabling storage of more digital audio tracks in the same amount of space when compared to MP3s at the same level of quality.
- Bit rate Bit rate denotes the number of bits per second used by a digital music file.
   The size and quality of a compressed digital audio file is determined by the bit rate used when encoding the file.
- Sampling frequency Sampling frequency is the rate at which the samples of a signal



- are converted from analog to digital (A/D conversion) per second.
- Multisession Multisession is one of the methods for writing data to media. Writing data once to the media is called a single session, and writing more than once is called a multisession.
- ID3/WMA Tag The ID3/WMA tag is the part of the encoded MP3 or WMA file that contains information about the digital music file such as song title, artist, album title, encoding bit rate, track time duration, etc. ID3 tag information is displayed on the Album/Artist/Track title line on the display.
- \* Windows® and Windows Media® are registered trademarks or trademarks of Microsoft Corporation in the United States of America and/or other countries.



Playback order chart

#### Playback order:

Music playback order of a CD with MP3 or WMA files is as illustrated.

The names of folders not containing MP3 or WMA files are not shown in the display.



- If there is a file in the top level of the disc, "Root Folder" is displayed.
- The playback order is the order in which the files were written by the writing software. Therefore, the files might not play in the desired order.

#### Specification chart (for FM-AM-SAT Radio with Compact Disc (CD) player (Type A)):

| Supported media                              |                 |                    | CD, CD-R, CD-RW   |
|--|-----------------|--------------------|---|
| Supported file systems                       |                 |                    | CD, CD-R, CD-RW: ISO9660 LEVEL1, ISO9660 LEVEL2, Romeo, Joliet * ISO9660 Level 3 (packet writing) is not supported. * Files saved using the Live File System component (on a Windows Vista-based computer) are not supported. |
|  | МР3             | Version            | MPEG1 Audio Layer 3, MPEG2, MPEG2.5   |
|  |                 | Sampling frequency | 8 kHz - 48 kHz  |
| Supported                                    |                 | Bit rate           | 8 kbps - 320 kbps, VBR*4  |
| versions*1                                   | WMA*2           | Version            | WMA7, WMA8, WMA9  |
|  |                 | Sampling frequency | 32 kHz - 48 kHz   |
|  |                 | Bit rate           | 32 kbps - 192 kbps, VBR (Ver.9)*4   |
| Tag information (Song title and Artist name) |                 |                    | ID3 tag VER1.0, VER1.1, VER2.2, VER2.3, VER2.4 (MP3 only)   |
|  |                 |                    | WMA tag (WMA only)  |
| Folder levels                                | CD, CD-R, CD-RW |                    | Folder levels: 8, Folders and files: 999 (Max. 255 files for one folder)  |
| Displayable character codes*3                |                 |                    | 01: ASCII, 02: ISO-8859-1, 03: UNICODE (UTF-16 BOM Big Endian), 04: UNICODE (UTF-16 Non-BOM Big Endian), 05: UNICODE (UTF-8), 06: UNICODE (Non-UTF-16 BOM Little Endian)  |

<sup>\*1</sup> Files created with a combination of 48 kHz sampling frequency and 64 kbps bit rate cannot be played.



<sup>\*2</sup> Protected WMA files (DRM) cannot be played.

<sup>\*3</sup> Available codes depend on what kind of media, versions and information are going to be displayed.

<sup>\*4</sup> When VBR files are played, the playback time may not be displayed correctly.

### Specification chart (for FM-AM-SAT Radio with Compact Disc (CD) player (Type B)):

| Supported media               |     |                    | CD, CD-R, CD-RW, USB2.0  |
|-------------------------------|-----|--------------------|--|
| Supported file systems        |     |                    | ISO9660 LEVEL1, ISO9660 LEVEL2, Apple ISO, Romeo, Joliet * ISO9660 Level 3 (packet writing) is not supported.  |
| Supported                     |     | Version            | MPEG1, MPEG2, MPEG2.5  |
|                               | MP3 | Sampling frequency | 8 kHz - 48 kHz   |
|                               |     | Bit rate           | 8 kbps - 320 kbps, VBR   |
| versions*1                    | WMA | Version            | WMA7, WMA8, WMA9   |
|                               |     | Sampling frequency | 32 kHz - 48 kHz  |
|                               |     | Bit rate           | 48 kbps - 192 kbps, VBR  |
| Tag information               |     |                    | ID3 tag VER1.0, VER1.1, VER2.2, VER2.3 (MP3 only)  |
| Folder levels                 |     |                    | Folder levels: 8, Max folders: 255 (including root folder), Files: 512 (Max. 255 files for one folder)   |
| Displayable character codes*2 |     |                    | 01: ASCII, 02: ISO-8859-1, 03: UNICODE (UTF-16 BOM Big Endian), 04: UNICODE (UTF-16 Non-BOM Big Endian), 05: UNICODE (UTF-8), 06: UNICODE (Non-UTF-16 BOM Little Endian) |

Files created with a combination of 48 kHz sampling frequency and 64 kbps bit rate cannot be played.



Available codes depend on what kind of media, versions and information are going to be displayed.

### Specification chart (for FM-AM-SAT Radio with Compact Disc (CD) player (Type C)):

| Supported media               |       |                    | CD, CD-R, CD-RW, USB2.0  |
|-------------------------------|-------|--------------------|--|
| Supported file systems        |       |                    | ISO9660 LEVEL1, ISO9660 LEVEL2, Apple ISO, Romeo, Joliet * ISO9660 Level 3 (packet writing) is not supported.  |
| Supported                     |       | Version            | MPEG1, MPEG2, MPEG2.5  |
|                               | MP3   | Sampling frequency | 8 kHz - 48 kHz   |
|                               |       | Bit rate           | 8 kbps - 320 kbps, VBR   |
| versions*1                    | WMA*2 | Version            | WMA7, WMA8, WMA9   |
|                               |       | Sampling frequency | 32 kHz - 48 kHz  |
|                               |       | Bit rate           | 48 kbps - 192 kbps, VBR  |
| Tag information               |       |                    | ID3 tag VER1.0, VER1.1, VER2.2, VER2.3 (MP3 only)  |
| Folder levels                 |       |                    | Folder levels: 8, Max folders: 255 (including root folder), Files: 512 (Max. 255 files for one folder)   |
| Displayable character codes*2 |       |                    | 01: ASCII, 02: ISO-8859-1, 03: UNICODE (UTF-16 BOM Big Endian), 04: UNICODE (UTF-16 Non-BOM Big Endian), 05: UNICODE (UTF-8), 06: UNICODE (Non-UTF-16 BOM Little Endian) |

Files created with a combination of 48 kHz sampling frequency and 64 kbps bit rate cannot be played.



Available codes depend on what kind of media, versions and information are going to be displayed.

### Troubleshooting guide (for FM-AM-SAT Radio with Compact Disc (CD) player (Type A)):

| Symptom  | Cause and Countermeasure   |
|--|--|
|  | Check if the disc or USB device was inserted correctly.  |
|  | Check if the disc is scratched or dirty.   |
|  | Check if there is condensation inside the player, and if there is, wait until the condensation is gone (about 1 hour) before using the player.   |
|  | If there is a temperature increase error, the player will play correctly after it returns to the normal temperature.   |
| Cannot play  | If there is a mixture of music CD files (CD-DA data) and compressed audio files on a CD, only the music CD files (CD-DA data) will be played.  |
|  | Files with extensions other than ".MP3 (.mp3)", ".WMA (.wma)", ".AAC (.aac)" or ".M4A (.m4a)" cannot be played. In addition, the character codes and number of characters for folder names and file names should be in compliance with the specifications. |
|  | Check if the disc or the file is generated in an irregular format. This may occur depending on the variation or the setting of compressed audio writing applications or other text editing applications.   |
|  | Check if the finalization process, such as session close and disc close, is done for the disc.   |
|  | Check if the disc or USB device is protected by copyright.   |
| Poor sound quality   | Check if the disc is scratched or dirty.   |
| It takes a relatively long time before the music starts playing. | If there are many folder or file levels on the disc or USB device, some time may be required before the music starts playing.  |
| Music cuts off or skips  | The writing software and hardware combination might not match, or the writing speed, writing depth, writing width, etc., might not match the specifications. Try using the slowest writing speed.  |
| Skipping with high bit rate files                                | Skipping may occur with large quantities of data, such as for high bit rate data.  |
| Move immediately to the next song when playing.                  | If an unsupported compressed audio file has been given a supported extension like .MP3, or when play is prohibited by copyright protection, the player will skip to the next song.   |
| The songs do not play back in the                                | The playback order is the order in which the files were written by the writing software, so the files might not play in the desired order.   |
| desired order.   | Random/Shuffle may be active on the audio system or on a USB device.   |



### Troubleshooting guide (for FM-AM-SAT Radio with Compact Disc (CD) player (Type B and C)):

| Symptom  | Cause and Countermeasure   |
|--|--|
|  | Check if the disc was inserted correctly.  |
|  | Check if the disc is scratched or dirty.   |
|  | Check if there is condensation inside the player. If there is, wait until the condensation is gone (about 1 hour) before using the player.   |
|  | If there is a temperature increase error, the CD player will play correctly after it returns to the normal temperature.  |
| Cannot play  | If there is a mixture of music CD files (CD-DA data) and MP3/WMA files on a CD, only the music CD files (CD-DA data) will be played.   |
|  | Files with extensions other than ".MP3", ".WMA", ".mp3" or ".wma" cannot be played. In addition, the character codes and number of characters for folder names and file names should be in compliance with the specifications.                 |
|  | Check if the finalization process, such as session close and disc close, is done for the disc.   |
|  | Check if the disc is protected by copyright.   |
| Dear second modific  | Check if the disc is scratched or dirty.   |
| Poor sound quality   | Bit rate may be too low.   |
| It takes a relatively long time before the music starts playing. | If there are many folders or file levels on the MP3/WMA disc, or if it is a multisession disc, some time may be required before the music starts playing.  |
| Music cuts off or skips  | The writing software and hardware combination might not match, or the writing speed, writing depth, writing width, etc., might not match the specifications. Try using the slowest writing speed.  |
| Skipping with high bit rate files                                | Skipping may occur with large quantities of data, such as for high bit rate data.  |
| Move immediately to the next song when playing                   | When a non-MP3/WMA file has been given an extension of ".MP3", ".WMA", ."mp3" or ".wma", or when play is prohibited by copyright protection, there will be approximately 5 seconds of no sound and then the player will skip to the next song. |
| Songs do not play back in the desired order                      | The playback order is the order in which the files were written by the writing software. Therefore, the files might not play in the desired order.   |



### Bluetooth® Audio player (if so equipped)


### Bluetooth

Bluetooth® is a trademark owned by Bluetooth SIG, Inc. and licensed to Bosch.

- Some Bluetooth® audio devices may not be recognized by the in-vehicle audio system.
- It is necessary to set up the wireless connection between a compatible Bluetooth® audio device and the in-vehicle Bluetooth® module before using the Bluetooth® audio player.
- Operating procedure of the Bluetooth® audio player will vary depending on the device. Make sure it is understood how to operate an audio device before using it with this system.
- The Bluetooth® audio player may be stopped under the following conditions:
  - Receiving a hands-free call.
  - Checking the connection to the handsfree phone.
- Do not place a Bluetooth® audio device in an area surrounded by metal or far away from the in-vehicle Bluetooth® module to prevent tone quality degradation and wireless connection disruption.
- While an audio device is connected through a Bluetooth® wireless connection, the battery power of the device may discharge

- quicker than usual.
- This system supports the Bluetooth® Audio Distribution Profile (A2DP, AVRCP).
- Wireless LAN (Wi-Fi) and the Bluetooth® functions share the same frequency band (2.4 GHz). Using the Bluetooth® and the wireless LAN functions at the same time may slow down or disconnect the communication and cause undesired noise. It is recommended that you turn off the wireless LAN (Wi-Fi) when using the Bluetooth® functions.





- MUTE button
- 2. DISP (display)/TEXT button
- 3. FM·AM radio band select button
- 4. CD PLAY button
- 5. Radio station preset buttons
- 6. iPod® button
- 7. AUX (auxiliary)/SAT band select button

- 8. Audio display
- 9. CLOCK button
- 10. CD EJECT button
- 11. iPod® MENU button
- 12. SEEK/TRACK button
- 13. ENTER button
- 14 BACK button

- 15. PWR (power) button/VOL (volume) control knob
- 6 AUX IN jack
- 17. AUDIO button
- 18. TUNE/FF-REW FOLDER button
- 19. SCAN/RPT (repeat) button

For all operation precautions, see "Audio operation precautions" (P.4-28).

The satellite radio mode\* requires an active SiriusXM Satellite Radio subscription. The satellite radio is not available in Alaska, Hawaii and Guam.

It may take some time to receive the activation signal after subscribing to the SiriusXM Satellite Radio. After receiving the activation signal, an available channel list will be automatically updated in the radio. Place the ignition position from LOCK to ACC to update the channel list.

\*: if so equipped

#### 4-40 Heater, air conditioner, audio and phone systems

#### FM-AM-SAT\* RADIO WITH COMPACT DISC (CD) PLAYER (Type A)

Audio main operation

#### Head unit:

The auto loudness circuit enhances the low and high frequency ranges automatically in both radio reception and CD playback.

#### ON-OFF/Volume control:

Place the ignition switch in the ACC or ON position, and then push the PWR button while the system is off to call up the normal mode (radio, CD, AUX and iPod®) which was playing immediately before the system was turned off. While the system is on, pushing the PWR button turns the system off.

Turn the VOL control knob to adjust the volume.


### **MUTE** button:

Push the button to mute the audio sound.

Push the (n) button again to release the mute setting.

#### AUDIO AUDIO button:

Push the AUDIO button to change the selecting mode as follows.



Push the TUNE ( ▲ , ▼ ) or SEEK ( ▼ , ▲ ) button to adjust Bass and Treble to the desired level. Use the TUNE or SEEK button also to adjust Fade or Balance modes. Fade adjusts the sound level between the front and rear speakers and Balance adjusts the sound between the right and left speakers.

To turn the beep sound off or on, push the TUNE or SEEK button until the desired mode is displayed. This turns on or off the beep sound when audio buttons are pushed.

To change the Speed Sensitive Volume (Spd Sen Vol) mode to OFF, LOW, MID or HIGH, push the TUNE or SEEK button until the desired mode is displayed.


Once you have adjusted the sound quality to the desired level, push the AUDIO button repeatedly until the normal mode display reappears. Otherwise, the normal mode display will automatically reappear after approximately 5 seconds.

#### CLOCK CLOCK button:

Push the CLOCK button to turn on or off the CLOCK display.

See "Clock" (P.2-41) for the detailed clock adjustment operation.





#### Radio operation

#### FM·AM Radio (FM/AM) band select:

Pushing the FM-AM radio band select button will change the band as follows:

$$AM \rightarrow FM1 \rightarrow FM2 \rightarrow AM$$

When the stereo broadcast signal is weak, the radio will automatically change from stereo to monaural reception.

When the radio band select button is pushed while the ignition switch is in the ACC or ON position, the radio will come on at the station last played.

#### AUX Radio (SAT) band select:

Pushing the **AUX** button will change the band as follows:

AUX (if connected portable device)  $\rightarrow$  XM1\*  $\rightarrow$  XM2\*  $\rightarrow$  XM3\*  $\rightarrow$  AUX (if connected portable device)

The last channel played will also come on when the ON-OFF button is pushed to ON.

When the stereo broadcast signal is weak, the radio will automatically change from stereo to monaural reception.

When the radio band select button is pushed while the ignition switch is in the ACC or ON position, the radio will come on at the station last played.

\*: if so equipped

## ▼ ▲ TUNE (Tuning):

For AM and FM radio

Push the TUNE button ▼ or ▲ for manual tuning. To move quickly through the stations, push and hold the TUNE button.

For SiriusXM Satellite Radio\*
 Push the TUNE button ▼ or ▲ to seek stations from all of the categories when any CAT is not selected.

\*: if so equipped



### ▼ SEEK tuning CATEGORY:

For AM and FM radio

Push the SEEK button ▼ or ▼ to tune from low to high or high to low frequencies and to stop at the next broadcasting station.

For SiriusXM Satellite Radio\*

Push the  $\mathbf{Y}$  or  $\mathbf{X}$  to tune to the first station of the next or previous category.

\*: if so equipped

During satellite radio reception, the following notices will be displayed under certain conditions.

- NO SIGNAL (No signal is received while the SAT tuner is connected.)
- OFF AIR (Broadcasting signed off)
- CHECK ANTENNA (Antenna connection error)
- LOADING (When the initial setting is performed)
- UPDATING (When the satellite radio subscription is not active)
- INVALID CH (Invalid channel is received.)

### SCAN RPT SCAN tuning:

Push the SCAN button to tune from low to high frequencies and stops at each broadcasting station for 5 seconds. Pushing the button again during this 5 seconds period will stop SCAN tuning and the radio will remain tuned to that station.

If the SCAN tuning button is not pushed within 5 seconds, SCAN tuning moves to the next station.

#### 1 to 6 Station memory operations:

12 stations can be set for the FM band (6 each for FM1 and FM2), 18 for SiriusXM Satellite Radio (6 each for XM1, XM2 and XM3)\* and 6 can be set for the AM band for easy access.

- 1. Choose the radio band using the radio band select button.
- 2. Tune to the desired station using the SEEK, SCAN or TUNE button.
- 3. Push and hold the desired radio station preset button 1 to 6 until a beep sound is heard. (The radio mutes when the radio station preset button is pushed.)
- 4. The station indicator will then come on and the sound will resume. Memorizing is now complete.
- 5. Other buttons can be set in the same manner.

If the battery cable is disconnected, or if the fuse opens, the radio memory will be erased. In that case, reset the desired stations.

\*: if so equipped

#### Radio Data System (RDS):

RDS stands for Radio Data System, and is a data information service transmitted by some radio stations on the FM band (not AM band) encoded within a regular radio broadcast. Currently, most RDS stations are in large cities, but many stations are now considering broadcasting RDS data.

RDS can display:

- Station call sign, such as "WHFR 98.3".
- Station name, such as "The Groove".
- Music or programming type such as "Classical", "Country" or "Rock".
- Traffic reports about delays or construction. If the station broadcasts RDS information, the RDS icon is displayed.

### DISP RADIO DISPLAY change:

When the DISP/TEXT button is pushed during the FM or SAT radio mode, the radio display will change in the following order.


- For FM radio: Frequency ↔ PS (Programme Service)/PTY (Programme type)
- For SiriusXM Satellite Radio\*: Category Name → Channel Name → Artist/

#### Feature → Song/Program

In the FM radio mode, pushing the DISP/TEXT button will switch the frequency display to the PTY display (if available), and if the DISP/TEXT button is not pushed again within 5 seconds, it will automatically switch to the PS display. If PTY is not available, pushing the DISP/TEXT button will only switch between the frequency display and the PS display.

\*: if so equipped





#### Compact Disc (CD) player operation

Place the ignition switch in the ACC or ON position, and insert the CD into the slot with the label side facing up. The CD will be guided automatically into the slot and start playing.

After loading the disc, the number of tracks on the disc will appear on the display.

If the radio is already operating, it will automatically turn off and the CD will play.

If the system has been turned off while the CD was playing, pushing the PWR button will start the CD.

Do not use 3.1 in (8 cm) discs.

#### CD CD PLAY:

When the CD button is pushed with the system off and the CD loaded, the system will turn on and the CD will start to play.

When the CD button is pushed with the CD loaded and the radio playing, the radio will automatically be turned off and the CD will start to play.

#### TEXT CD play information:

When the DISP/TEXT button is pushed for less than 1.5 seconds while the CD is being played, the disc information display will change as follows:

#### CD:



#### CD with MP3 or WMA:





## FF (Fast Forward), REW (Re-

#### CD:

When the ▲ (fast forward) or ▼ (rewind) button is pushed while the CD is being played, the CD will play while fast forwarding or rewinding. When the button is released, the CD will return to normal play speed.

#### CD with MP3 or WMA:

When the ▲ or ▼ button is pushed for less than 1.5 seconds while the CD is being played. the folders in the CD will change.

When the ▲ or ▼ button is pushed for more than 1.5 seconds while the CD is being played, the CD will play while forwarding or rewinding. When the button is released, the CD will return to the normal play speed.

### APS (Automatic Program Search) FF. APS REW:

When the (APS FF) button is pushed while the CD is being played, the program next to the present one will start to play from its beginning. Push several times to skip through programs. The CD will advance the number of times the button is pushed. (When the last program on the CD is skipped through, the first program will be played.)



#### Heater, air conditioner, audio and phone systems

When the \( \mathbb{X} \) (APS REW) button is pushed, the program being played returns to its beginning. Push several times to skip back through programs. The CD will go back the number of times the button is pushed.

### SCAN SCAN tuning:

When the SCAN tuning button is pushed for more than 1.5 seconds while the CD is being played, the beginning of all the tracks of CD will be played for 10 seconds in sequence.


Pushing the button again during this 10 second period will stop SCAN tuning.

If the SCAN tuning button is not pushed within 10 seconds, SCAN tuning moves to the next disc program.

### SCAN RPT RANDOM (RDM)/REPEAT (RPT):

When the RPT button is pushed for less than 1.5 seconds while the CD is being played, the play pattern can be changed as follows:

#### CD:






#### CD EJECT:

When the CD EJECT button is pushed with the CD loaded, the CD will be ejected.

When this button is pushed while the CD is being played, the CD will come out and the system will turn off.

If the CD comes out and is not removed, it will be pulled back into the slot to protect it.



Interface system for iPod® operation Connecting iPod®:

The iPod® outlet connector is in the glove box. Connect the cable (1) as illustrated, and then connect the other end of the cable to your iPod® (2). Your vehicle is equipped with the specialized cable for connecting the iPod® to your vehicle audio unit. The battery of your iPod® is charged while it is connected to the vehicle if the iPod® supports charging via a FireWire® connection.

When the connection is complete, a NISSAN logo will be displayed on the iPod® and an iPod® icon on the audio display illuminates. While



connecting the iPod® to the vehicle, the iPod® can only be operated by the vehicle audio controls.

To disconnect the cable from the vehicle outlet, fully depress the center connector button to unlatch the connector and pull the connector straight out of the outlet. To disconnect the cable from the iPod®, fully depress the side connector buttons and pull the iPod® connector straight out of the iPod®.

\* iPod<sup>®</sup>, iPhone<sup>®</sup> and FireWire<sup>®</sup> are a trademark of Apple Inc., registered in the U.S. and other countries.

#### Compatibility:

The following models are available:

- Third generation iPod<sup>®</sup> (Firmware version 2.3 or later) (Audiobook and Podcast are not available)
- Fourth generation iPod<sup>®</sup> (Firmware version 3.1.1 or later)
- Fifth generation iPod<sup>®</sup> (Firmware version 1.1.2 or later)
- iPod mini® (Firmware version 1.41 or later)
- iPod photo<sup>®</sup> (Firmware version 1.2.1 or later)
- iPod nano<sup>®</sup> (Firmware version 1.2 or later)
  The fourth generation iPod nano<sup>®</sup>, iPod touch<sup>®</sup>,
  the second generation iPod Classic<sup>®</sup> and

iPhone<sup>®</sup> 3G may not work with the system in some cases.

Make sure that your iPod<sup>®</sup> firmware is updated.

\* 12V-charge iPod<sup>®</sup>s are not chargeable with this system.

### iPod iPod® button:

Place the ignition switch in the ACC or ON position. Then, push the iPod® button to switch to the iPod® mode.

If another audio source is playing and the iPod<sup>®</sup> is connected, pushing the iPod<sup>®</sup> button changes to the iPod<sup>®</sup> mode.

If the system has been turned off while the iPod<sup>®</sup> was playing, pushing the PWR button will start the iPod<sup>®</sup>.

### MENU Top menu item selecting:

When the iPod<sup>®</sup> MENU button is pushed while the iPod<sup>®</sup> is connected, the interface for iPod<sup>®</sup> operation is shown on the audio display. The items on the menu list can be scrolled by pushing the SEEK button ▲ or ▼ and the TUNE button ▲ or ▼ while the iPod<sup>®</sup> is operational. To select an item, push ENTER. The display can be changed as follows:




For more information about each item, see the iPod® Owner's Manual.

### ENTER BACK, ENTER button:

- When the ENTER button is pushed while the top menu is displayed, program details are shown on the audio display.
- To select the program, push to search using the SEEK ▲ or ▼ and ENTER button.
- When the BACK button is pushed, it returns to the previous display.

### DISP TEXT iPod® play information:

When the DISP/TEXT button is pushed while a program is being played, the program information display will change as follows:



\* Artist Name will not be displayed for a Podcast.

# FF (Fast Forward), REW (Rewind) button:

When the ▲ or ▼ button is pushed for more than 1.5 seconds while the iPod<sup>®</sup> is playing, the iPod<sup>®</sup> will play while fast forwarding or rewinding. When the button is released, the iPod<sup>®</sup> will return to the normal play speed.

When the ▲ or ▼ button is pushed for less

4-46 Heater, air conditioner, audio and phone systems

than 1.5 seconds while the iPod® is playing, the next track or the beginning of the current track on the iPod® will be played.

### **▼** APS (Automatic Program Search) FF, APS REW button:

When the **▼** or **▼** button is pushed for more than 1.5 seconds while the iPod<sup>®</sup> is playing. numbers of tracks can be skipped through.

When the **▼** or **▼** button is pushed for less than 1.5 seconds while iPod® is playing, the next track or the beginning of the current track on the iPod® will be played.

### SCAN REPEAT (RPT), RANDOM (RDM):

When the RPT button is pushed while a track is being played, the play pattern can be changed as follows:


Except Podcast and Audiobook:

--- ALL REPEAT ---- TRACK REPEAT ----- ALL RANDOM --ALBUM RANDOM -

Podcast:

ALL REPEAT ↔ TRACK REPEAT

Audiobook:



#### AUX (Auxiliary) input

#### **AUX IN iack:**

The AUX IN iack is located on the audio unit. The AUX IN audio input jack accepts any standard analog audio input such as from a portable cassette tape/CD player, MP3 player or laptop computer.


NISSAN strongly recommends using a stereo mini plug cable when connecting your music device to the audio system. Music may not play properly when a monaural cable is used.

### AUX AUX (Auxiliary) button:

With an AUX device plugged in, push the AUX button repeatedly until the display changes to the AUX mode.

When the AUX button is pushed with no device plugged into the jack, the audio system does not change to the AUX mode.





- XM band select button
- CD insert slot
- 3. CD EJECT button
- 4. TUNE/SCROLL knob and AUDIO control button
- 5. Radio station preset buttons
- 6. AUX button
- 7. ON:OFF button/VOLUME control knob

- FF (forward)/REW (rewind) or SEEK/CATE-GORY button
- 9. CD button
- 10. FM·AM band select button

# FM-AM-SAT RADIO WITH COMPACT DISC (CD) PLAYER (Type B)

No satellite radio reception is available unless a SiriusXM Satellite Radio subscription is active.

For all operation precautions, see "Audio operation precautions" (P.4-28).

The satellite radio mode requires an active SiriusXM Satellite Radio subscription. The satellite radio is not available in Alaska, Hawaii and Guam.

It may take some time to receive the activation signal after subscribing the SiriusXM Satellite Radio. After receiving the activation signal, an available channel list will be automatically updated in the radio. Place the ignition switch in LOCK to ACC to update the channel list.

#### Audio main operation

#### Head unit:

The auto loudness circuit enhances the low and high frequency ranges automatically in both radio reception and CD playback.

#### ON-OFF/Volume control:

Place the ignition switch in the ACC or ON position, and then push the ON·OFF button while the system is off to turn on the last audio source, which was playing immediately before the system was turned off. While the system is



on, pushing the ON-OFF button turns the system off.

Turn the VOL control knob to adjust the volume.

#### Adjusting tone quality and speaker balance:

To adjust Bass, Treble, Balance and Fade, push the Audio control knob. When the display shows the setting you want to change (Bass, Treble, Balance and Fade), rotate the Audio control knob to set the desired setting. For the other setting methods, see "How to use touch screen" (P.4-4).

This vehicle has some sound effect functions as follows:

Speed Volume

For more details, see "How to use the SETUP button" (P.4-6).

#### **Adjusting AUX level:**

The volume level of incoming sound can be selected from "Quiet". "Medium" and "Loud" when an auxiliary device is connected to the system. For more details, see "How to use the SETUP button" (P.4-6).

#### Switching the display:

Pushing the AUX button will switch the displays between USB/iPod® and AUX.

#### FM-AM-SAT radio operation

When the radio band select button is pushed while the ignition switch is in the ACC or ON position, the radio will come on at the channel last played.

The last channel played will also come on when the ON-OFF button is pushed to ON.

If another audio source is playing when the radio band select button is turned to ON, the audio source will automatically be turned off and the last radio channel played will come on.

When the stereo broadcast signal is weak, the radio will automatically change from stereo to monaural reception.

#### FM·AM FM·AM radio band select:

Pushing the FM·AM radio band select button will change the band as follows:

 $AM \rightarrow FM1 \rightarrow FM2 \rightarrow AM$ 

#### XM SiriusXM Satellite Radio band select:

Pushing the XM radio band select button will change the band as follows:

 $XM1 \rightarrow XM2 \rightarrow XM3 \rightarrow XM1$ 

The satellite radio is not available in Alaska. Hawaii and Guam.

#### TUNE (Tuning):

- For AM and FM radio Turn the TUNE knob for manual tuning.
- For SiriusXM Satellite Radio Turn the TUNE knob to seek channels from all of the categories when any category is not selected.



#### SEEK tuning:

- For AM and FM radio
  - to tune from low to high or high to low frequencies and to stop at the next broadcasting station.
- For SiriusXM Satellite Radio

Push the SEEK/CATEGORY button ◀ or to tune to the first channel of the next or previous category.

#### Tuning with the touch screen (AM and FM radio):

When in AM or FM mode, the radio can be tuned using the touch screen. To bring up the visual tuner, touch the "Tune" key on the lower right corner of the screen. A screen appears with a bar running from low frequencies on the left to high frequencies on the right. Touch the screen at the location of the frequency you wish to tune and the station will change to that



frequency. To return to the regular radio display screen, touch the "OK" key.

#### 1 to 6 Station memory operations:

12 stations/channels can be set for the FM band (6 each for FM1 and FM2), 18 for SiriusXM Satellite Radio (6 each for XM1, XM2 and XM3) and 6 stations can be set for the AM band.

- Choose the radio band using the radio band select button.
- Tune to the desired station/channel using the SEEK/CATEGORY button or the TUNE knob.
- Push and hold the desired station preset button 1 to 6 until the beep sound is heard.
- The station indicator will then come on and the sound will resume. Memorizing is now complete.
- 5. Other buttons can be set in the same manner.

If the battery cable is disconnected, or if the fuse opens, the radio memory will be erased. In that case, reset the desired stations/channels.

#### Channels (SiriusXM Satellite Radio):

When the SiriusXM Satellite Radio is being played, select "Channels" key to display a list of channels. Select a preferred channel from the

list to change to that channel.

#### Categories (SiriusXM Satellite Radio):

When the SiriusXM Satellite Radio is being played, select "Categories" key to display a list of channels. Select a preferred channel from the list to display options within that category.

#### Compact Disc (CD) player operation

Place the ignition switch in the ACC or ON position and insert the Compact Disc (CD) into the slot with the label side facing up. The CD will be guided automatically into the slot and start playing.

If the radio is already operating, it will automatically turn off and the CD will play.

If the system has been turned off while the CD was playing, pushing the ON-OFF button will start the CD.

Do not use 3.1 in (8 cm) discs.

### CD PLAY:

When the CD button is pushed with the system off and the CD loaded, the system will turn on and the CD will start to play.

When the CD button is pushed with the CD loaded and the radio playing, the radio will automatically be turned off and the CD will start to play.


While listening to a CD or an MP3/WMA CD, certain text may be displayed (when a CD encoded with text is being used). Depending on how the CD or MP3/WMA CD is encoded, the text is displayed listing the artist, album and song title.

# Next/Previous Track and Fast Forward/Rewind:

When the ◀ or ▶ button is pushed for more than 1.5 seconds while the CD is being played, the CD will play while fast forwarding or rewinding. When the button is released, the CD will return to normal play speed.


When the ◀ or ▶ button is pushed for less than 1.5 seconds while the CD is being played, the next track or the beginning of the current track on the CD will be played.

When the rewind button is pushed for less than 1.5 seconds within 3 seconds after the current track starts playing, the previous track will be played.



#### Random:

Touch the "Random" key to apply a random play pattern to the CD. When the random mode is active, the eigen icon will be displayed to the left of the song title. If an MP3 CD is playing, touching "Random" alternates between randomly playing songs within the current folder and songs from the CD as a whole. The icon is displayed to the left of the song title or folder name to denote which pattern is applied. To cancel Random mode, touch the "Random" key until no et icon is displayed.



#### Repeat:

Touch the "Repeat" key to apply a repeat play pattern to the CD. When the repeat mode is active, the () icon will be displayed to the left of the song title. If an MP3 CD is playing, touching "Repeat" alternates between repeating the current song and repeating the current folder. The C icon is displayed to the left of the song title or folder name to denote which pattern is applied. To cancel Repeat mode, touch the "Repeat" key until no O icon is displayed.

#### Browse:


Touch the "Browse" key to display the titles on the CD in list format. Touch the title of a song in the list to begin playing that song. If an MP3 CD is playing, touching the "Browse" key will also list the folders on the disc. Follow the procedure for selecting a song with the touch screen to choose a folder.

#### ▲ CD EJECT:

When the CD EJECT button is pushed with the CD loaded, the CD will be ejected.


When this button is pushed while the CD is being played, the CD will be ejected.

If the CD comes out and is not removed, it will be pulled back into the slot to protect it.



button when a compatible audio device is connected into the AUX IN jack.

When the AUX button is pushed with no device plugged into the jack, the audio system does not change to the AUX mode.



#### AUX (Auxiliary) input

#### **AUX IN jack:**

The AUX IN jack is located on the lower center of the instrument panel. The AUX IN audio input jack accepts any standard analog audio input such as from a portable cassette tape/CD player, MP3 player or laptop computer.

NISSAN strongly recommends using a stereo mini plug cable when connecting your music device to the audio system. Music may not play properly when a monaural cable is used.

### AUX AUX (Auxiliary) button:

To switch to the AUX mode, push the AUX



#### USB memory operation

#### Audio main operation:

The USB outlet connector is on the lower center of the instrument panel. Connect a USB memory as illustrated, and then switch to the USB memory mode automatically.

If the system has been turned off while the USB memory was playing, pushing the ON-OFF/VOL control knob will start the USB memory.

## WARNING

Do not connect, disconnect or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.

## A CAUTION

- Do not force the USB device into the USB port. Inserting the USB device tilted or up-side-down into the port may damage the port. Make sure that the USB device is connected correctly into the USB port.
- Do not grab the USB port cover (if so equipped) when pulling the USB device out of the port. This could damage the port and the cover.
- Do not leave the USB cable in a place where it can be pulled unintentionally. Pulling the cable may damage the port.

Refer to your device manufacturer's owner information regarding the proper use and care of the device.

### AUX PLAY:

When the AUX button is pushed with the system off and the USB memory inserted, the system will turn on.


If another audio source is playing and a USB memory is inserted, push the AUX button repeatedly until the center display changes to the USB memory mode.

### SEEK/CATEGORY button:

Push the SEEK/CATEGORY button ◀ while an audio file on the USB device is playing to return to the beginning of the current track. Push the SEEK/CATEGORY button - several times to skip backward several tracks.

Push the SEEK/CATEGORY button ▶ while an audio file on the USB device is playing to advance one track. Push the SEEK/CATEGORY button > several times to skip forward several tracks. If the last track in a folder on the USB device is skipped, the first track of the next folder is played.

Push and hold the SEEK/CATEGORY button ◆ or ▶ for 1.5 seconds while an audio file on the USB device is playing to reverse or fast forward the track being played. The track plays at an increased speed while reversing or fast forwarding. When the button is released, the audio file returns to normal play speed.



#### Random and repeat play mode:


While files on a USB device are playing, the play pattern can be altered so that songs are repeated or played randomly.

#### Random:

Touch the "Random" key to apply a random play pattern to the USB device. When the random mode is active, the equipment icon is displayed to the left of the song title or album name to denote which random pattern is applied. To cancel Random mode, touch the "Random" key until no ⇒ icon is displayed.

#### Repeat:

Touch the "Repeat" key to apply a repeat play pattern to the USB device. When the repeat mode is active, the O icon is displayed to the left of the song title or album name to denote which repeat pattern is applied. To cancel Repeat mode, touch the "Repeat" key until no icon is displayed.



iPod® player operation

#### Connecting iPod®:

Connect the iPod® cable to the USB connector. If the iPod® supports charging via USB, the battery of the iPod® will be charged while connected to the vehicle.

Depending on the version of the iPod®, the display on the iPod® shows a NISSAN or Accessory Attached screen when the connection is completed. When the iPod® is connected to the vehicle, the iPod® music library can only be operated by the vehicle audio controls.

\* iPod® is a trademark of Apple Inc., registered in the U.S. and other countries.



## **WARNING**

Do not connect, disconnect or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.

### CAUTION

- Do not force the USB device into the USB port. Inserting the USB device tilted or up-side-down into the port may damage the port. Make sure that the USB device is connected correctly into the USB port.
- Do not grab the USB port cover (if so equipped) when pulling the USB device out of the port. This could damage the port and the cover.
- Do not leave the USB cable in a place where it can be pulled unintentionally. Pulling the cable may damage the port.

Refer to your device manufacturer's owner information regarding the proper use and care of the device.

#### Compatibility:

The following models are available:

- Fifth generation iPod® (version 1.2.3 or later)
- iPod Classic® (version 1.1.1 or later)
- First generation iPod touch® (version 2.0.0 or later)
- Second generation iPod touch® (version 1.2.3 or later)
- First generation iPod nano® (version 1.3.1 or later)
- Second generation iPod nano® (version 1.1.3 or later)
- Third generation iPod nano® (version 1.1 or later)
- Fourth generation iPod nano® (version 1.0.2) or later)

This unit may not control/operate correctly when connected to some iPod® versions/firmware and iPhone®.

Make sure that the iPod® version is updated.

#### Audio main operation:

Place the ignition switch in the ACC or ON position. Then, push the aux button repeatedly to switch to the iPod® mode.

If the system has been turned off while the iPod®

was playing, pushing the ON-OFF button will start the iPod®.

### AUX PLAY:

When the Aux button is pushed with the system off and the iPod® connected. the system will turn on. If another audio source is playing and the iPod® is connected, push the aux button repeatedly to switch to the iPod® mode.

#### Interface:

The interface for iPod® operation shown on the vehicle display is similar to the iPod® interface. Use the touch screen. BACK button or the TUNE/SCROLL knob to navigate the menus on the screen.

The following items can be chosen from the menu list screen. For further information about each item, see the iPod® Owner's Manual.

- Playlists
- Artists
- Sonas
- Composers
- Audiobooks
- Podcasts

The following touch-panel buttons shown on the screen are also available:




- were: returns to the previous screen.
- ▶II : plays/pauses the music selected.

#### SEEK/CATEGORY button:

When the ◀ or ▶ button is pushed for more than 1.5 seconds while the iPod<sup>®</sup> is playing, the iPod<sup>®</sup> will play while fast forwarding or rewinding. When the button is released, the iPod<sup>®</sup> will return to the normal play speed.

#### Random and repeat play mode:



While files on a USB device are playing, the play pattern can be altered so that songs are repeated or played randomly.


#### Random:

Touch the "Random" key to apply a random play pattern to the iPod<sup>®</sup>. When the random mode is active, the ∋€ icon is displayed to the left of the song title or album name to denote which random pattern is applied. To cancel Random mode, touch the "Random" key until no ∋€ icon is displayed.

#### Repeat:

Touch the "Repeat" key to apply a repeat play pattern to the iPod<sup>®</sup>. When the repeat mode is active, the O icon is displayed to

the left of the song title or album name to denote which repeat pattern is applied. To cancel Repeat mode, touch the "Repeat" key until no  $\bigcirc$  icon is displayed.



- 1. CD eject button
- 2. FM·AM button
- 3. AUX button
- 4. CD insert slot
- 5. APPS□ button
- i◄■ Backward seek button and ▶▶ Forward seek button

- 7. BACK button
- 8. TUNE knob / AUDIO button
- 9. Display screen
- 10. ON-OFF button / VOL (volume) control knob
- 11. CD button
- 12. SXM button\*

# FM-AM-SAT RADIO WITH COMPACT DISC (CD) PLAYER (Type C)

\*No satellite radio reception is available when the SXM button is pushed to access satellite radio stations unless optional satellite receiver and antenna are installed and a SiriusXM Satellite Radio service subscription is active. Satellite radio is not available in Alaska, Hawaii and Guam.

For all operation precautions, see "Audio operation precautions" (P.4-28).

Audio main operation

# ON-OFF button / VOL (volume) control knob:

Place the ignition switch in the ACC or ON position and push the ON-OFF button while the system is off to call up the available audio source that was playing immediately before the system was turned off.

To turn the system off, push the ON-OFF button.

Turn the VOL (volume) control knob to adjust the volume.

This vehicle may be equipped with Speed Sensitive Volume. When this feature is active, the audio volume changes as the driving speed changes.



#### Audio settings:

- 1. push the APPS button.
- 2. Touch the "Settings" key.
- 3. Touch the "Audio" key.

Use the touch-screen to adjust the following items to the desired setting:

Bass:

Adjusts the bass to the desired level.

• Treble:

Adjusts the treble to the desired level.

· Balance:

Adjusts the balance to the desired level. Balance adjusts the sound level between the left and right speakers.

Fade:

Adjusts the fade to the desired level. Fade adjusts the sound level between the front and rear speakers.

• Speed Sensitive Vol.:

Adjusts the speed sensitive volume function, which increases the volume of the audio system as the speed of the vehicle increases. Set to "OFF" to disable the feature. The higher the setting, the more the volume increases in relation to vehicle speed.

AUX Volume Level:

Controls the volume level of incoming sound when an auxiliary device is con-

nected to the system. Available options are Low (Quiet), Medium, and High (Loud).

Bass, treble, balance and fade can also be adjusted by pushing the AUDIO control knob and turning it to select the item to adjust. When the desired item is shown on the display, turn the tuning to adjust and then push the AUDIO button until the display returns to the main audio screen. If the button is not pushed for approximately 10 seconds, the radio or CD display will automatically reappear.

#### SXM settings:

To view the SXM settings:

- 1. Push the APPS button.
- 2. Touch the "Settings" key.
- 3. Touch the "SXM" key.

The signal strength, activation status and other information are displayed on the screen.

FM/AM/SAT radio operation

#### FM-AM button:

Push the FM·AM button to change the band as follows:

 $AM \rightarrow FM1 \rightarrow FM2 \rightarrow AM$ 

If another audio source is playing when the FM-AM button is pushed, the audio source playing will automatically be turned off and the last radio station played will begin playing.

The FM stereo indicator (ST) is shown on the screen during FM stereo reception. When the stereo broadcast signal is weak, the radio automatically changes from stereo to monaural reception.

#### SXM band select:

Pushing the SXM button will change the band as follows:

 $SXM1^* \rightarrow SXM2^* \rightarrow SXM3^* \rightarrow SXM1^*$  (satellite, if so equipped)

When the SXM button is pushed while the ignition switch is in the ACC or ON position, the radio will come on at the last station played.

The last station played will also come on when the ON-OFF button is pushed.

\*When the SXM button is pushed, the satellite radio mode will be skipped unless an optional satellite receiver and antenna are installed and a



SiriusXM Satellite Radio service subscription is active. Satellite radio is not available in Alaska, Hawaii and Guam.

If a compact disc is playing when the SXM button is pushed, the compact disc will automatically be turned off and the last radio station played will come on.

While the radio is in SXM mode, the operation can be controlled through the touch-screen. Touch the "Channels" key to display a list of channels. Touch a channel displayed on the list to change to that channel. Touch the "Categories" key to display a list of categories. Touch a category displayed on the list to display options within that category.

#### Tuning with the touch-screen:

When in AM or FM mode, the radio can be tuned using the touch-screen. To bring up the visual tuner, touch the "Tune" key on the lower right corner of the screen. A screen appears with a bar running from low frequencies on the left to high frequencies on the right. Touch the screen at the location of the frequency you wish to tune and the station will change to that frequency. To return to the regular radio display screen, touch the "OK" key.


#### Tuning with the TUNE knob:

The radio can also be manually tuned using the

TUNE knob. When in FM or AM mode, turn the TUNE knob to the left for lower frequencies or to the right for higher frequencies. When in SXM mode, turn the TUNE knob to change the channel.

### I◀◀ ▶▶ SEEK tuning:

When in SXM mode, push the seek buttons or ▶▶ to change the category.



#### 1 to 6 Station memory operations:

Twelve stations can be set for the FM band (6 for FM1, 6 for FM2) and six stations can be set for the AM band. Twelve stations can be set for the SXM band (6 for SXM1, 6 for SXM2, 6 for SXM3).

- Choose the radio band AM, FM1 or FM2 using the FM-AM select button or choose the radio band SXM1, SXM2, SXM3 using the SXM button.
- Tune to the desired station using manual or seek tuning. Touch and hold any of the desired station memory keys (1 - 6) until a beep sound is heard.



- The channel indicator will then come on and the sound will resume. Programming is now complete.
- 4. Other keys can be set in the same manner. If the battery cable is disconnected or if the fuse opens, the radio memory will be canceled. In that case, reset the desired stations.

Presets can also be selected by touching the desired preset number on the screen.

Compact Disc (CD) player operation If the radio is already operating, it automatically turns off and the compact disc begins to play.

#### CD button:

When the CD button is pushed with the system off and the compact disc loaded, the system will turn on and the compact disc will start to play.

When the CD button is pushed with a compact disc loaded and the radio playing, the radio will automatically be turned off and the compact disc will start to play.

#### CD/MP3/WMA display mode:

| Menu item           |        |   |
|---------------------|--------|---|
| CD/MP3 display mode |        | While listening to a CD or an MP3/WMA CD, certain text may be displayed (when a CD encoded with text is being used). Depending on how the CD or MP3/WMA CD is encoded, the text is displayed listing the artist, album and song title. There are other keys displayed on the screen when a CD is playing:               |
|                     | Random | Touch the "Random" key to apply a random play pattern to the CD. If an MP3 CD is playing, touching "Random" or alternates between Random Folder, and Random All. This text will appear on the display. To cancel Random mode, touch the "Random" key until the key is no longer highlighted.                            |
|                     | Repeat | Touch the "Repeat" key to apply a repeat play pattern to the CD. If an MP3 CD is playing, touching "Repeat" alternates between repeating the current song and repeating the current folder. This text will appear on the display. To cancel Repeat mode, touch the "Repeat" key until the key is no longer highlighted. |
|                     | Browse | Touch the "Browse" key to display the titles on the CD in list format. Touch the title of a song in the list to begin playing that song. If an MP3 CD is playing, touching the "Browse" key will also list the folders on the disc. Follow the procedure for selecting a song with the touch-screen to choose a folder. |



▶► SEEK (Fast Forward/Rewind) buttons:

Push and hold the seek buttons use or but for 1.5 seconds while the compact disc is playing to reverse or fast forward the track being played. The compact disc plays at an increased speed while reversing or fast forwarding. When the button is released, the compact disc returns to normal play speed.

►► SEEK (Previous/Next Track) buttons:


Push the seek button → while a CD or MP3/ WMA CD is playing to return to the beginning of the current track. Push the seek button several times to skip backward several tracks.

Push the seek button ▶▶ while a CD or MP3/ WMA CD is playing to advance one track. Push the seek button by several times to skip forward several tracks. If the last track on a CD is skipped, the first track on the disc is played. If the last track in a folder of an MP3/ WMA CD is skipped, the first track of the next folder is played.

#### CD eject button:

When the button is pushed with a compact disc loaded, the compact disc will eject and the last source will be played.

If the disc is not removed within 10 seconds, the disc will reload.




### AUX (Auxiliary) input

The AUX IN jack is located on the lower center of the instrument panel. The AUX IN jack accepts any standard analog audio input such as from a portable cassette tape/CD player, MP3 player or a laptop computer. Push the AUX button to play a compatible device plugged into the AUX IN jack.

NISSAN strongly recommends using a stereo mini plug cable when connecting your music device to the audio system. Music may not play properly when a monaural cable is used.





#### USB interface

#### Connecting a device to the USB port:



# **WARNING**

Do not connect, disconnect, or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.



# **A** CAUTION

- Do not force the USB device into the USB port. Inserting the USB device tilted or up-side-down into the port may damage the port. Make sure that the USB device is connected correctly into the USB port.
- Do not grab the USB port cover (if so equipped) when pulling the USB device out of the port. This could damage the port and the cover.
- Do not leave the USB cable in a place where it can be pulled unintentionally. Pulling the cable may damage the port

Refer to your device manufacturer's owner information regarding the proper use and care of the device.

The USB port is located on the lower center of the instrument panel. Insert the USB device into the port.

When a compatible storage device is plugged into the port, compatible audio files on the storage device can be played through the vehicle's audio system.


#### Audio file operation:

#### AUX button:

Place the ignition switch in the ON or ACC position and push the AUX button to switch to the USB input mode. If another audio source is playing and a USB memory device is inserted. push the AUX button until the center display changes to the USB memory mode.

If the system has been turned off while the USB memory was playing, push the ON-OFF button to restart the USB memory.





#### Play information:

Information about the audio files being played is shown on the display screen of the vehicle's audio system. Touch "Browse" to display the list of categories that can be used to narrow the search. Touch the name of a song on the screen to begin playing that song.

# ▶► Seek button:

Push the ◄ button while an audio file on the USB device is playing to return to the beginning of the current track. Push the | d button several times to skip backward several tracks.

Push the ▶▶ button while an audio file on the USB device is playing to advance one track. Push the ▶ button several times to skip forward several tracks. If the last track in a folder on the USB device is skipped, the first track of the next folder is played.

## Random and repeat play mode:


While files on a USB device are playing, the play pattern can be altered so that songs are repeated or played randomly.

#### Random:

Touch the "Random" key to apply a random play pattern to the USB device. To cancel Random mode, touch the "Random" key again.

#### Repeat:

Touch the "Repeat" key to apply a repeat play pattern to the USB device. To cancel Repeat mode, touch the "Repeat" key again.



iPod® player operation (if so equipped) Connecting iPod®:



Do not connect, disconnect or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.



# **A** CAUTION

- Do not force the USB device into the USB port. Inserting the USB device tilted or up-side-down into the port may damage the port. Make sure that the USB device is connected correctly into the USB port.
- Do not grab the USB port cover (if so equipped) when pulling the USB device out of the port. This could damage the port and the cover.
- Do not leave the USB cable in a place where it can be pulled unintentionally. Pulling the cable may damage the port.

Refer to your device manufacturer's owner information regarding the proper use and care of the device.

To connect an iPod<sup>®</sup> to the vehicle so that the iPod<sup>®</sup> can be controlled with the audio system controls and display screen, use the USB port located on the lower center of the instrument panel. Connect the iPod<sup>®</sup>-specific end of the cable to the iPod<sup>®</sup> and the USB end of the cable to the USB port on the vehicle. If your iPod<sup>®</sup> supports charging via a USB connection, its

battery will be charged while connected to the vehicle with the ignition switch in the ACC or ON position.

While connected to the vehicle, the iPod® may only be able to be operated by the vehicle audio controls.

To disconnect the iPod® from the vehicle, remove the USB end of the cable from the USB port on the vehicle, then remove the cable from the iPod®.

iPod<sup>®</sup> is a trademark of Apple Inc., registered in the U.S. and other countries.

#### Compatibility:


The following models are compatible:

- iPod<sup>®</sup> Classic 5th generation (firmware version 1.3.0 or later)
- iPod<sup>®</sup> Classic 6th generation (firmware version 2.0.1 or later)
- iPod<sup>®</sup> Classic 7th generation (firmware version 2.0.4 or later)
- iPod<sup>®</sup> Touch 2nd generation (firmware version 4.2.1 or later)\*
- iPod<sup>®</sup> Touch 3rd generation (firmware version 5.1 or later)
- iPod<sup>®</sup> Touch 4th generation (firmware version 5.1 or later)

- iPod<sup>®</sup> nano 1st generation (firmware version 1.3.1 or later)
- iPod<sup>®</sup> nano 2nd generation (firmware version 1.1.3 or later)
- iPod<sup>®</sup> nano 3rd generation (firmware version 1.1.3 or later)
- iPod<sup>®</sup> nano 4th generation (firmware version 1.0.4 or later)
- iPod<sup>®</sup> nano 5th generation (firmware version 1.0.2 or later)
- iPod<sup>®</sup> nano 6th generation (firmware version 1.1 or later)
- iPhone® 3G (firmware version 4.2.1 or later)
- iPhone® 3GS (firmware version 5.1 or later)
- iPhone<sup>®</sup> 4 (firmware version 5.1 or later)
- iPhone<sup>®</sup> 4S (firmware version 5.1 or later)
- \* Some features of this iPod® may not be fully functional.

Make sure that your iPod<sup>®</sup> firmware is updated to the version indicated above.






#### Audio main operation:

Place the ignition switch in the ACC or ON position. Push the AUX button repeatedly to switch to the iPod<sup>®</sup> mode.

If the system has been turned off while the iPod<sup>®</sup> was playing, pushing the ON·OFF button will start the iPod<sup>®</sup>.

#### AUX button:

When the AUX button is pushed with the system off and the iPod® connected, the system will turn on. If another audio source is playing and the iPod® is connected, push the AUX button repeatedly until the center display changes to the iPod® mode.



#### Interface:

The interface for iPod® operation shown on the vehicle's audio system display screen is similar to the iPod® interface. Use the touch-screen, BACK button or the TUNE knob to navigate the menus on the screen.

When the iPod<sup>®</sup> is playing, touch the "Menu" key to bring up the iPod<sup>®</sup> interface.

Depending on the iPod<sup>®</sup> model, the following items may be available on the menu list screen. For further information about each item, see the iPod<sup>®</sup> Owner's Manual.

Playlists



- Artists
- Albums
- Genres
- Songs
- Composers
- Audiobooks
- Podcasts

#### Shuffle and repeat play mode:

While the iPod<sup>®</sup> is playing, the play pattern can be altered so that songs are repeated or played randomly.

#### Shuffle:

Touch the "Shuffle" key to apply a random play pattern to the iPod<sup>®</sup>. When the Shuffle mode is active, the text is highlighted. To cancel Shuffle mode, touch the "Shuffle" key again until the text is no longer highlighted.

#### Repeat:


Touch the "Repeat" key to apply a repeat play pattern to the iPod<sup>®</sup>. When the repeat mode is active, the text is highlighted. To cancel Repeat mode, touch the "Repeat" key again until the text is no longer highlighted.



Push the seek button I◄ or ►►I to skip backward or forward one track.

Heater, air conditioner, audio and phone systems 4-65

Push and hold the seek button I◄ or ►►I for 1.5 seconds while a track is playing to reverse or fast forward the track being played. The track plays at an increased speed while reversing or fast forwarding. When the button is released, the track returns to normal play speed.



#### Scrolling menus:

While navigating long lists of artists, albums or songs in the music menu, it is possible to scroll the list by the first character in the name. To activate character indexing, touch the "A-Z" key in the upper right corner of the screen. Turn the TUNE knob to choose the number or letter to jump to in the list and then push the AUDIO button.

# Pandora® audio (if so equipped)

The vehicle's audio system is capable of playing audio streaming through a compatible, USB connected audio device using the Pandora<sup>®</sup> music service.

# Connecting a device for use with Pandora® audio:

Devices capable of streaming Pandora® audio can be connected to the vehicle's audio system via the USB port. The USB port is located on the lower center of the instrument panel.

Launch the Pandora<sup>®</sup> application on the phone and then connect with the USB port. Once connected, the Pandora<sup>®</sup> controls will be displayed on the control panel display screen.


#### Compatibility:

The following iPhone<sup>®</sup> models are compatible with the system:

- iPhone<sup>®</sup> 3GS
- iPhone® 4
- iPhone<sup>®</sup> 4S
- iPhone® 5

The latest Pandora® application should be installed on the phone.





#### Audio main operation:

To switch to the Pandora® audio mode, push the AUX button repeatedly until the Pandora® audio mode is displayed on the screen.

The controls for the Pandora® audio mode are displayed on the screen. Push the audio preset 3 button to pause or play the music.

Push the audio preset 5 button to select " • " (thumbs up) key. Push the audio preset 4 button to select " - " (thumbs down) key


#### NOTE:

There is a limit of six skips per station per hour. If a " ₹ " (thumbs down) key is given after the skip limit has been reached, the

#### current track will continue to play but the feedback will be saved.

Bluetooth® streaming audio

If you have a compatible Bluetooth® audio device that is capable of playing audio files, the device can be connected to the vehicle's audio system so that the audio files on the device play through the vehicle's speakers.




# Connecting Bluetooth® audio:

To connect your Bluetooth® audio device to the vehicle, follow the procedure below:

- Push the APPS□ button.
- 2. Touch the "Settings" key.
- 3. Touch the "Phone & Bluetooth" kev.





The controls for the Bluetooth® audio are displayed on the screen.

- 4. Touch the "Connect New Device" key.
- 5. The system acknowledges the command and asks you to initiate connecting from the phone handset. The connecting procedure of the cellular phone varies according to each cellular phone model. See the cellular phone Owner's Manual for details. You can also visit www.nissanusa.com/bluetooth for instructions on connecting NISSAN recommended cellular phones.

#### Audio main operation:

To switch to the Bluetooth<sup>®</sup> audio mode, push the AUX button repeatedly until the Bluetooth<sup>®</sup> audio mode is displayed on the screen.





# CD/USB MEMORY CARE AND CLEANING

#### CD

- Handle a CD by its edges. Never touch the surface of the disc. Do not bend the disc.
- Always place the discs in the storage case when they are not being used.
- To clean a disc, wipe the surface from the center to the outer edge using a clean, soft cloth. Do not wipe the disc using a circular motion.


Do not use a conventional record cleaner or alcohol intended for industrial use.

4-68 Heater, air conditioner, audio and phone systems

 A new disc may be rough on the inner and outer edges. Remove the rough edges by rubbing the inner and outer edges with the side of a pen or pencil as illustrated.

#### **USB** memory

- Do not touch the terminal portion of the USB memory.
- Do not place heavy objects on the USB memory.
- Do not store the USB memory in very humid locations.
- Do not expose the USB memory to direct sunlight.
- Do not spill any liquids on the USB memory.
   Refer to the USB memory Owner's Manual for the details.



- SOURCE select switch
- 2. Tuning switch
- 3. VOLUME control switch

# STEERING WHEEL SWITCH FOR AUDIO CONTROL

The audio system can be operated using the controls on the steering wheel.

#### SOURCE select switch

Push the SOURCE select switch to change the mode to available audio source.

#### VOLUME control switch

Push up or down the VOLUME control switch to increase or decrease the volume.

#### Memory change (FM/AM):

Push the tuning switch for less than 1.5 seconds to change the next or previous radio preset.

#### SEEK tuning (FM/AM):

Push the tuning switch for more than 1.5 seconds to seek the next or previous radio station.

#### XM/SXM operation (if so equipped):

Tilt up/down for less than 1.5 seconds to increase or decrease the preset station.

Tilt up/down for more than 1.5 seconds to go to the next or previous category.

# APS (Automatic Program Search) FF, APS REW (CD, iPod<sup>®</sup> and USB (if so equipped)):

Push the tuning switch for less than 1.5 seconds to return to the beginning of the present program or skip to the next program. Push several times to skip back or skip through programs.

This system searches for the blank intervals between selections. If there is a blank interval within one program or there is no interval



between programs, the system may not stop in the desired or expected location.

#### FOLDER change (CD with MP3 or WMA):

Push the tuning switch for more than 1.5 seconds to change the folders (if there are any folders).

# Bluetooth<sup>®</sup> Audio operation (if so equipped):

Tilt up/down for less than 1.5 seconds to skip ahead or back to the next song.


Tilt up/down for more than 1.5 seconds to reverse or fast forward the current track.

# Pandora® Audio operation (if so equipped):

Tilt up for less than 1.5 seconds to input "thumbs up" for the current song.

Tilt down for less than 1.5 seconds to input "thumbs down" for the current song.

Tilt up for more than 1.5 seconds to skip to the next song (if the maximum of six skips per station per hour has not been exceeded)



#### **ANTENNA**

To remove the antenna, hold the bottom of the antenna and turn it counterclockwise.

To install the antenna, turn the antenna clockwise and tighten.

# **A** CAUTION

- To avoid damaging or deforming the antenna, be sure to fold down (if so equipped) or remove the antenna under the following conditions.
  - The vehicle enters a garage with a low ceiling.

- The vehicle is covered with a car cover.
- Be sure that antenna is removed before the vehicle enters an automatic car wash.
- Always properly tighten the antenna rod during installation. Otherwise, the antenna rod may break during vehicle operation.

# NISSANCONNECT<sup>TM</sup> APP **SMARTPHONE INTEGRATION (if so** equipped)

This vehicle is equipped with Smartphone Integration technology. This allows many compatible Smartphone applications to be displayed and easily controlled through the vehicle's touchscreen.

#### NOTE:

A compatible smartphone and registration is required to use mobile applications or to access connected features of certain vehicle applications.

# REGISTERING WITH NISSANCON-NFCT<sup>TM</sup> APP

To use the Smartphone Integration feature, it is necessary for the user to register. In order to register, visit the NissanConnect<sup>TM</sup> website, www.nissanusa.com/connect/ and sign up or create an account through the prompts on the NissanConnect<sup>TM</sup> App. Once registered, download the NissanConnect<sup>TM</sup> App from your compatible phone's application download source and then log into the application. If you already have an account created through the App, please log in.

#### CONNECT PHONE

To use this feature, a compatible smartphone must be connected via Bluetooth® or USB to the vehicle. For more information on connecting your phone, see "Bluetooth ® Hands-Free Phone System (Type B)" (P.4-85).

#### NOTE:

- For Apple iPhones, NissanConnect<sup>TM</sup> Apps REQUIRES the phone to be plugged in via USB.
- For Android phones, NissanConnect<sup>™</sup> Apps REQUIRES the phone to be paired via Bluetooth.

#### APPLICATION DOWNLOAD

Once connected, the NissanConnect<sup>TM</sup> App will search your phone to determine which compatible applications are currently installed. The user will then choose which apps they want to bring into their vehicle from the list of apps within the "Manage My Apps" section of the NissanConnect TM App on their smartphone. The vehicle will then download the in-vehicle interface for each of these compatible applications. Once downloaded, the user can access their selected smartphone applications through the vehicle touchscreen. For more information on application availability see www.nissanusa. com/connect/

#### CAR PHONE OR CB RADIO

When installing a car phone or a CB radio in vour vehicle, be sure to observe the following precautions, otherwise the new equipment may adversely affect the electronic control modules and electronic control system harness.



- A cellular phone should not be used for any purpose while driving so full attention may be given to vehicle operation. Some jurisdictions prohibit the use of cellular phones while driving.
- If you must make a call while your vehicle is in motion, the hands-free cellular phone operational mode (if so equipped) is highly recommended. Exercise extreme caution at all times so full attention may be given to vehicle operation.
- If a conversation in a moving vehicle requires you to take notes, pull off the road to a safe location and stop your vehicle before doing so.



# Bluetooth® HANDS-FREE PHONE SYSTEM (Type A)

# **A** CAUTION


- Keep the antenna as far away as possible from the electronic control modules.
- Keep the antenna wire more than 8 in (20 cm) away from the electronic control system harness. Do not route the antenna wire next to any harness.
- Adjust the antenna standing-wave ratio as recommended by the manufacturer.
- Connect the ground wire from the CB radio chassis to the body.
- For details, consult a NISSAN dealer.

# **WARNING**

- Use a phone after stopping your vehicle in a safe location. If you have to use a phone while driving, exercise extreme caution at all times so full attention may be given to vehicle operation.
- If you find yourself unable to devote full attention to vehicle operation while talking on the phone, pull off the road to a safe location and stop your vehicle before doing so.

# A CAUTION

To avoid draining the vehicle battery, use a phone after starting the engine.



- Volume control switch -/+
- 2. PHONE SEND ( button
- PHONE END button
- . Microphone

Your NISSAN is equipped with the Bluetooth<sup>®</sup> Hands-Free Phone System. If you have a compatible Bluetooth<sup>®</sup> enabled cellular phone, you can set up the wireless connection between your cellular phone and the in-vehicle phone module. With Bluetooth<sup>®</sup> wireless technology, you can make or receive a hands-free telephone call in your vehicle.

Once your cellular phone is connected to the invehicle phone module, no other phone connecting procedure is required. Your phone is



automatically connected with the in-vehicle phone module when the ignition switch is placed in the ON position with the connected cellular phone turned on and carried in the vehicle.

You can connect up to 5 different Bluetooth® cellular phones in the in-vehicle phone module. However, you can talk on only one cellular phone at a time.

Before using the Bluetooth® Hands-Free Phone System, refer to the following notes.

- Wireless LAN (Wi-Fi) and the Bluetooth® functions share the same frequency band (2.4 GHz). Using the Bluetooth® and the wireless LAN functions at the same time may slow down or disconnect the communication and cause undesired noise. It is recommended that you turn off the wireless LAN (Wi-Fi) when using the Bluetooth® functions.
- Set up the wireless connection between a compatible cellular phone and the in-vehicle phone module before using the Bluetooth® Hands-Free Phone System.
- Some Bluetooth® enabled cellular phones may not be recognized by the in-vehicle phone module. Please visit www.nissanusa. com/bluetooth for a recommended phone list and instructions for connecting your

phone.

- You will not be able to use a hands-free phone under the following conditions:
  - Your vehicle is outside of the telephone service area.
  - Your vehicle is in an area where it is difficult to receive radio waves: such as in a tunnel, in an underground parking garage, near a tall building or in a mountainous area.
  - Your cellular phone is locked to prevent it from being dialed.
- When the radio wave condition is not ideal or ambient sound is too loud, it may be difficult to hear the other person's voice during a call.
- Immediately after the ignition switch is placed in the ON position, it may be impossible to receive a call for a short period of time.
- Do not place the cellular phone in an area surrounded by metal or far away from the invehicle phone module to prevent tone quality degradation and wireless connection disruption.
- While a cellular phone is connected through the Bluetooth® wireless connection, the battery power of the cellular phone may discharge quicker than usual. The Blue-

- tooth® Hands-Free Phone System cannot charge cellular phones.
- If the Bluetooth® Hands-Free Phone System seems to be malfunctioning, see "Troubleshooting guide" (P.4-84). You can also visit www.nissanusa.com/bluetooth for troubleshooting help.
- Some cellular phones or other devices may cause interference or a buzzing noise to come from the audio system speakers. Storing the device in a different location may reduce or eliminate the noise.
- Refer to the cellular phone Owner's Manual regarding battery charging, cellular phone antenna, etc.

This wireless hands-free car kit is based on Bluetooth technology.

- Frequency: 2402 MHz 2480 MHz
- Output power: 4.14 dBm E.I.R.P
- Modulation: FHSS GFSK 8DPSK, π/ 4DQPSK
- Number of channels: 79
- This wireless equipment cannot be used for any services related to life safety because there is the possibility of radio interference.



#### REGULATORY INFORMATION

Bluetooth trademark:



Bluetooth® is a trademark owned by Bluetooth SIG, Inc., and licensed to Visteon Corporation.

## FCC Regulatory information

- CAUTION: To maintain compliance with FCC's RF exposure guidelines, use only the supplied antenna. Unauthorized antenna, modification, or attachments could damage the transmitter and may violate FCC regulations.
- Operation is subject to the following two conditions:
  - this device may not cause interference and
  - this device must accept any interference, including interference that may cause undesired operation of the device

# IC Regulatory information

 Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

#### USING THE SYSTEM

The NISSAN Voice Recognition system allows hands-free operation of the Bluetooth® Hands-Free Phone System.

If the vehicle is in motion, some commands may not be available so full attention may be given to vehicle operation.

#### Initialization

When the ignition switch is placed in the ON position, NISSAN Voice Recognition is initialized, which takes a few seconds. If the fix button is pushed before the initialization completes, the system will not accept any command.

# Operating tips

To get the best performance out of the NISSAN Voice Recognition system, observe the following:

- Keep the interior of the vehicle as quiet as possible. Close the windows to eliminate surrounding noises (traffic noises, vibration sounds, etc.), which may prevent the system from recognizing voice commands correctly.
- Wait until the tone sounds before speaking a command. Otherwise, the command will not


- be received properly.
- Start speaking a command within 5 seconds after the tone sounds.
- Speak in a natural voice without pausing between words.

# Giving voice command

To operate NISSAN Voice Recognition, push and release the the button located on the steering wheel. After the tone sounds, speak a command.

The command given is picked up by the microphone, and voice feedback is given when the command is accepted.

- If you need to hear the available commands for the current menu again, say "Help" and the system will repeat them.
- If a command is not recognized, the system announces, "Command not recognized. Please say again." Repeat the command in a clear voice.
- If you want to go back to the previous command, you can say "Go back" or "Correction" anytime the system is waiting for a response.
- You can cancel a command when the system is waiting for a response by saying, "Cancel" or "Quit." The system announces "Cancel" and ends the VR session. You can



also push and hold the button for 5 seconds on the steering wheel at any time to cancel the VR session. Whenever the VR session is cancelled, a double beep is played to indicate you have exited the system.

 If you want to adjust the volume of the voice feedback, push the volume control switch (+ or -) on the steering wheel while being provided with feedback. You can also use the radio volume control knob.

#### **Voice Prompt Interrupt:**

In most cases you can interrupt the voice feedback to speak the next command by pushing the representation on the steering wheel.

#### One Shot Call:

To use the system faster, you may speak the second level commands with the main menu command on the main menu. For example, push the row button and after the tone say, "Call Redial." Note: The combined command of Call and (Speak Name) cannot be used.

## How to say numbers

NISSAN Voice Recognition requires a certain way to speak numbers in voice commands. Refer to the rules and examples below.

- Either "zero" or "oh" can be used for "0".
   Example: 1-800-662-6200
  - "One eight oh oh six six two six two oh oh", or
  - "One eight zero zero six six two six two oh oh"
- Words can be used for the first 4 digits places only.

Example: 1-800-662-6200

- "One eight hundred six six two six two oh oh",
- NOT "One eight hundred six six two sixty two hundred, and
- NOT "One eight oh oh six six two sixty two hundred.
- Numbers can be spoken in small groups.
   The system will prompt you to continuing entering digits, if desired.

Example: 1-800-662-6200

- "One eight zero zero"
   The system repeats the numbers and prompts you to enter more.
- "six six two"

The system repeats the numbers and

prompts you to enter more.

- "six two zero zero"
- You can say "Star" for "\*" and "Pound" for "#" at any time in any position of the phone number. (Available only when using the "Special Dialing" command.)

Example: 1-555-1212 \*123

- "One five five one two one two star one two three"
- Say "pound" for "#". Say "star" for "\*"
   (available when using the "Special Dialing"
   command and the "Send" command during
   a call).
- Say "plus" for "+" (available only when using the "Special Dialing" command).
- Say "pause" for a 2 second pause (available only when storing a phone book number).
   See "Making a call by entering a phone number" (P.4-77) and "List of voice commands" (P.4-78) for more information.

#### NOTE:

# For best results, say phone numbers as single digits.

The voice command "Help" is available at any time. Please say the "Help" command to get information about how to use the system.




#### INFO

- If you are controlling the telephone system by voice command for the first time or do not know the appropriate voice command, speak "Help". The system announces the available commands.
- When you speak numbers, you can speak both "zero" or "oh" for "0".

#### Manual command selection

Commands can be selected manually. While the commands are displayed on the audio screen, select a command by operating the audio tuning switch, and then push the switch. Once a command is manually selected, the voice command function is cancelled. To return to voice command mode, push the switch to cancel the current operation, and then perform the first procedure of voice command.



## **CONTROL BUTTONS**

The control buttons for the Bluetooth<sup>®</sup> Hands-Free Phone System are located on the steering wheel.

#### **CILL PHONE SEND**

Push the **C** button to initiate a VR session or answer an incoming call.

You can also use the button to interrupt system feedback and give a command at once.

#### → PHONE END

While the voice recognition system is active, push the button to go back one step. Push and hold the button for 5 seconds to quit the voice recognition system at any time.

#### **GETTING STARTED**

The following procedures will help you get started using the Bluetooth® Hands-Free Phone System with NISSAN Voice Recognition. For additional command options, refer to "List of voice commands" (P.4-78).

# Choosing a language

You can interact with the Bluetooth® Hands-Free Phone System using English, Spanish or French.

To change the language, perform the following.

- Push and hold the button for more than 5 seconds.
- 2. The system announces: "Push the PHONE SEND (一处) button for the hands-free phone system to enter the speaker adaptation mode or push the PHONE END (一) button to select a different language."
- 3. Push the button.

For information on speaker adaptation, see "Speaker Adaptation (SA) mode" (P.4-82).

The system announces the current language and gives you the option to change the language to Spanish (in Spanish) or French (in French). To select the current language, push the ← button. To select a different language, tilt the tuning switch ( or up or down.

#### NOTE:

You must push the M button within 5 seconds to change the language.

 If you decide not to change the language, do not push either button. After 5 seconds, the VR session will end, and the language will not be changed.

## Connecting procedure

#### NOTE:

The connecting procedure must be performed when the vehicle is stationary. If the vehicle starts moving during the procedure, the procedure will be cancelled.

Main menu
"Connect Phone" (A)
"Add Phone" (B)
Initiate from handset (C)
Name phone (D)

- Push the button on the steering wheel.
   The system announces the available commands.
- Say: "Connect Phone" (A). The system acknowledges the command and announces the next set of available commands.

3. Say: "Add phone" (B) . The system acknowledges the command and asks you to initiate pairing from the phone handset (C) .

The connecting procedure of the cellular phone varies according to each cellular phone. See the cellular phone Owner's Manual for details. You can also visit www. nissanusa.com/bluetooth for instructions on connecting NISSAN recommended cellular phones.

When prompted for a Passkey code, enter "1234" from the handset. The Passkey code "1234" has been assigned by NISSAN and cannot be changed.

4. The system asks you to say a name for the phone (b).

If the name is too long or too short, the system tells you, then prompts you for a name again.

Also, if more than one phone is connected and the name sounds too much like a name already used, the system tells you, then prompts you for a name again. Making a call by entering a phone number

```
Main menu
"Call" (A)
"Phone Number" (speak digits) (B)
"Dial" (C)
```

- Push the button on steering wheel. A tone will sound.
- Say: "Call" (A) . The system acknowledges the command and announces the next set of available commands.
- Say: "Phone Number" (B). The system acknowledges the command and announces the next set of available commands. Say: "Special Dialing" to dial more than 10 digits or any special characters.
- 4. Say the number you wish to call starting with the area code in single digit format. If the system has trouble recognizing the correct phone number, try entering the number in the following groups: 3-digit area code, 3digit prefix and the last 4-digits. For example, 555-121-3354 can be said as "five five five" as the 1st group, then "one two one" as the 2nd group, and "three three five four" as the 3rd group. For dialing more than 10 digits or any special characters, say "Special Dial-



- ing". See "How to say numbers" (P.4-75) for more information.
- When you have finished speaking the phone number, the system repeats it back and announces the available commands.
- 6. Say: "Dial" © . The system acknowledges the command and makes the call.

For additional command options, see "List of voice commands" (P.4-78).

# Receiving a call

When you hear the ring tone, push the Kebutton on the steering wheel.

Once the call has ended, push the button on the steering wheel.

#### NOTE:

If you do not wish to take the call when you hear the ring tone, push the button on the steering wheel to reject the call.

#### LIST OF VOICE COMMANDS

# Main menu "Call" "Phonebook" "Recent Calls" "Connect Phone"

When you push and release the button on the steering wheel, you can choose from the commands on the Main Menu. The following pages describe these commands and the commands in each sub-menu.

# Remember to wait for the tone before speaking.

You can say "Help" to hear the list of commands currently available anytime the system is waiting for a response.


A menu item can also be selected by scrolling the display with the SEEK switch and entering by pushing the 🖟 button.

If you want to end an action without completing it, you can say "Cancel" or "Quit" at anytime the system is waiting for a response. The system will end the VR session. Whenever the VR session is cancelled, a double beep is played to indicate you have exited the system.

If you want to go back to the previous command, you can say "Go back" or "Correction" anytime

the system is waiting for a response.

#### Call



## (Speak Name) (A)

If there are entries stored in the phonebook, a number associated with a name and location can be dialed.

See "Phonebook (phones without automatic phonebook download function)" (P.4-79) to learn how to store entries.

When prompted by the system, say the name of the phonebook entry to call. The system acknowledges the name.

If there are multiple locations associated with the name, the system asks the user to choose the location.

Once the name and location are confirmed, the system begins the call.

# "Phone Number" (speak digits) (B)

When prompted by the system, say the number

to call. Refer to "Making a call by entering a phone number" (P.4-77) for more details.

## "Redial" (C)

Use the Redial command to call the last number that was dialed.

The system acknowledges the command, repeats the number and begins dialing.

If a redial number does not exist, the system announces, "There is no number to redial" and ends the VR session.

## "Call back" (D)

Use the Call Back command to dial the number of the last incoming call within the vehicle.

The system acknowledges the command, repeats the number and begins dialing.

If a call back number does not exist, the system announces, "There is no number to call back" and ends the VR session.

#### "Special Number"

To dial more than 10 digits or any special characters, please say "Special Number". When the system acknowledges the command, the system will prompt you to speak the number.

#### "During a call"

During a call there are several command options available. Push the receiving voice and enter wheel to mute the receiving voice and enter

commands.

- "Help" The system announces the available commands.
- "Go back/Correction" The system announces "Go back," ends the VR session and returns to the call.
- "Cancel/Quit" The system announces "Cancel," ends the VR session and returns to the call.
- "Send/Enter/Call/Dial" Use the Send command to enter numbers, "\*" or "#" during a call. For example, if you were directed to dial an extension by an automated system:

Say: "Send one two three four."

The system acknowledges the command and sends the tones associated with the numbers. The system then ends the VR session and returns to the call. Say "star" for "\*", say "pound" for "#".


"Transfer call" — Use the Transfer Call command to transfer the call from the Bluetooth® Hands-Free Phone System to the cellular phone when privacy is desired. The system announces, "Transfer call. Call transferred to privacy mode." The system then ends the VR session.

To reconnect a call from the cellular phone to the Bluetooth® Hands-Free Phone sys-

- tem, push the 🀔 button.
- "Mute" Use the Mute command to mute your voice so the other party cannot hear it.
   Use the mute command again to unmute your voice.

#### NOTE:

If a call is ended or the cellular phone network connection is lost while the Mute feature is on, the Mute feature will be reset to "off" for the next call so the other party can hear your voice.



Phonebook (phones without automatic phonebook download function)

## "Transfer Entry" (A)

Use the Transfer Entry command to store a new name in the system.

Say: "Transfer entry." The system acknowledges the command and asks you to initiate the transfer from the phone handset. The new contact phone number will be transferred from the cellular phone via the Bluetooth® commu-

nication link.

The transfer procedure varies according to each cellular phone. See the cellular phone Owner's Manual for details. You can also visit www. nissanusa.com/bluetooth for instructions on transferring phone numbers from NISSAN recommended cellular phones.

The system confirms the name, location and number.

## "Delete Entry" (B)

Use the Delete Entry command to delete one entry from the phonebook. After the system acknowledges a command, say the name to delete or say "List Names" to choose an entry.

#### "List Names" (c)

Use the List Names command to hear all the names in the phonebook. The system recites the phonebook entries but does not include the actual phone numbers. When playback of the list is complete, the system returns to the main menu.

Playback of the list can be stopped at any time by pushing the button on the steering wheel. The system ends the VR session.

Phonebook (phones with automatic phonebook download function)

#### NOTE:

Phonebook commands are not available when the vehicle is moving.



For phones that support automatic download of the phonebook (PBAP Bluetooth® profile), the "Phonebook" command is used to manage entries to the vehicle phonebook. You can say the name of an entry at this menu to initiate dialing of that entry.

The phonebook stores up to 1000 names for each phone paired with the system. Each name can have up to 4 locations/phone numbers associated with it.

When a phone is connected to the system, the phonebook is automatically downloaded to the vehicle. This feature allows you to access your phonebook from the Bluetooth system and call contacts by name. You can record a custom voice tag for contact names that the system has difficulty recognizing. For more information see

"Record Name" in this section.

#### NOTE:

Each phone has its own separate phonebook. You cannot access Phone A's phonebook if you are currently connected with Phone B.

# "List names" (A)

Use the List Names command to hear all the names and locations in the phone book.

The system recites the phone book entries but does not include the actual phone numbers. When the playback of the list is complete, the system goes back to the main menu.

You can stop the playback of the list at any time by pushing the button on the steering wheel. The system ends the VR session. See the "Record Name" command in this section for information about recording custom voice tags for list entries that the system has difficulty pronouncing.

# "Record name" (B)

The system allows you to record custom voice tags for contact names in the phonebook that the vehicle has difficulty recognizing. This feature can also be used to record voice tags to directly dial an entry with multiple numbers. Up to 40 voice tags can be recorded to the

system.


# "Next Name" (C)

Use the Next Name command to move the next name of list

# "Previous Name" (D)

Use the Previous Name command to move the previous name of list.

#### Recent Calls



Use the Recent Calls command to access outgoing, incoming or missed calls.

# "Outgoing" (A)

Use the Outgoing command to list the outgoing calls made from the vehicle.

# "Incoming" (B)

Use the Incoming command to list the incoming calls made from the vehicle.

# "Missed" (C)

Use the Missed command to list the missed

calls made to the vehicle that were not answered.


# "Call Back" (D)

Use the Call Back command to dial the number of the most recently received call.

Connect Phone

#### NOTE:

Add Phone command is not available when the vehicle is moving.



Use the Connect Phone commands to manage the phones connecting to the vehicle or to enable the Bluetooth® function on the vehicle.

## "Add Phone" (A)

Use the Add Phone command to add a phone to the vehicle. See "Connecting procedure" (P.4-77) for more information.

# "Select Phone" (B)

Use the Select Phone command to select from a

list of phones connected to the vehicle. The system will list the names assigned to each phone and then prompt you for the phone you wish to select. Only one phone can be active at a time.

# "Delete Phone" (C)

Use the Delete Phone command to delete a phone that is connected to the vehicle. The system will list the names assigned to each phone and then prompt you for the phone you wish to delete. Deleting a phone from the vehicle will also delete that phonebook for that phone.

# "Bluetooth Off" (D)

Use the Bluetooth Off command to prevent a wireless connection to your phone.

# "Replace phone" (E)

This can be used to reconnect a new phone with the vehicle you have changed your cellular phone.

## SPEAKER ADAPTATION (SA) MODE

Speaker Adaptation allows up to two out-of dialect users to train the system to improve recognition accuracy. By repeating a number of commands, the users can create a voice model of their own voice that is stored in the system. The system is capable of storing a different speaker adaptation model for each connected phone.

#### Training procedure

- Position the vehicle in a reasonably quiet outdoor location.
- Sit in the driver's seat with the engine running, the parking brake on, and the transmission in Park.
- Push and hold the button for more than 5 seconds.
- 4. The system announces: "Push the PHONE SEND ( ) button for the hands-free phone system to enter the speaker adaptation mode or push the PHONE END ( ) button to select a different language."
- 5. Push the 🌾 button.

For information on selecting a different language, see "Choosing a language" (P.4-76).

- If the connected phone is already in use, the system will prompt you to overwrite. Follow the instructions provided by the system.
- When preparation is complete and you are ready to begin, push the button.
- 8. The SA mode will be explained. Follow the instructions provided by the system.
- When training is finished, the system will tell you an adequate number of phrases have been recorded.
- The system will announce that speaker adaptation has been completed and the system is ready.

The SA mode will stop if:

- The button is pushed for more than 5 seconds in SA mode.
- The vehicle is driven during SA mode.
- The ignition switch is turned to the OFF or LOCK position.

#### Training phrases

During the SA mode, the system instructs you to say the following phrases.

(The system will prompt you for each phrase.)

- phonebook transfer entry
- dial 3 0 4 2 9

- delete call back number
- incoming
- transfer entry
- 8 pause 9 3 2 pause 7
- delete all entries
- call 7 2 4 0 9
- phonebook delete entry
- next entry
- dial star 2 1 7 0
- yes
- no
- select
- missed
- dial 8 5 6 9 2
- Bluetooth on
- Outgoing
- call 3 1 9 0 2
- 9 7 pause pause 3 0 8
- cancel
- call back number
- call star 2 0 9 5
- delete phone
- dial 8 3 0 5 1
- Record name
- 4 3 pause 2 9 pause 0



- delete redial number
- phonebook list names
- call 8 0 5 4 1
- correction
- setup main menu
- dial 7 4 0 1 8
- memo pad delete
- delete
- dial 9 7 2 6 6
- call 7 6 3 0 1
- go back
- call 5 6 2 8 0
- dial 6 6 4 3 7



# TROUBLESHOOTING GUIDE

The system should respond correctly to all voice commands without difficulty. If problems are encountered, try the following solutions.

Where the solutions are listed by number, try each solution in turn, starting with number 1, until the problem is resolved.

| Symptom  | Solution  |
|--|---|
| The system fails to interpret the command correctly.                 | 1. Ensure that the command format is valid. (See "List of voice commands" (P.4-78).)  |
|  | 2. Ensure that the command is spoken after the tone.  |
|  | 3. Speak clearly without pausing between words and at a level appropriate to the ambient noise level in the vehicle.  |
|  | 4. Ensure that the ambient noise level is not excessive (for example, windows open or defroster on). NOTE: If it is too noisy to use the phone, it is likely that the voice commands will not be recognized.      |
|  | 5. If more than one command was said at a time, try saying the commands separately.   |
|  | 6. If the system consistently fails to recognize commands, the voice training procedure should be carried out to improve the recognition response for the speaker. (See "Speaker Adaptation (SA) mode" (P.4-82).) |
| The system consistently selects the wrong entry from the phone book. | 1. Ensure that the phone book entry name requested matches what was originally stored. This can be confirmed by using the "List Names" command. (See "List of voice commands" (P.4-78).)                          |
|  | 2. Replace one of the names being confused with a new name.   |




# Bluetooth <sup>®</sup> HANDS-FREE PHONE SYSTEM (Type B)

# **A** WARNING

- Use a phone after stopping your vehicle in a safe location. If you have to use a phone while driving, exercise extreme caution at all times so full attention may be given to vehicle operation.
- If you are unable to devote full attention to vehicle operation while talking on the phone, pull off the road to a safe location and stop your vehicle.

# **A** CAUTION

To avoid discharging the vehicle battery, use a phone after starting the engine.



- Volume control switch -/+
- 2. PHONE SEND button
- PHONE END button
- Microphone

The phone ← button is located on the control panel can also use to control the Bluetooth <sup>®</sup> Hands-Free Phone System. (See "Control panel buttons — color screen (Type B)" (P.4-10).)

Your NISSAN is equipped with the Bluetooth<sup>®</sup> Hands-Free Phone System. If you have a compatible Bluetooth<sup>®</sup> enabled cellular phone, you can set up the wireless connection between your cellular phone and the in-vehicle phone module. With Bluetooth<sup>®</sup> wireless technology, you can make or receive a hands-free telephone

call with your cellular phone in the vehicle.

Once your cellular phone is connected to the invehicle phone module, no other phone connecting procedure is required. Your phone is automatically connected with the in-vehicle phone module when the ignition switch is placed in the ON position with the connected cellular phone turned on and carried in the vehicle.

You can register up to 5 different Bluetooth<sup>®</sup> cellular phones to the in-vehicle phone module. However, you can talk on only one cellular phone at a time.

NISSAN Voice Recognition system supports the phone commands, so dialing a phone number using your voice is possible. For more details, see "NISSAN voice recognition system" (P.4-92).

Before using the Bluetooth® Hands-Free Phone System, refer to the following notes.

- Set up the wireless connection between a cellular phone and the in-vehicle phone module before using the hands-free phone system.
- Some Bluetooth<sup>®</sup> enabled cellular phones may not be recognized by the in-vehicle phone module. Please visit www.nissanusa. com/bluetooth for a recommended phone list and connecting.

- You will not be able to use a hands-free phone under the following conditions:
  - Your vehicle is outside of the cellular service area.
  - Your vehicle is in an area where it is difficult to receive cellular signal; such as in a tunnel, in an underground parking garage, near a tall building or in a mountainous area.
  - Your cellular phone is locked to prevent it from being dialed.
- When the radio wave condition is not ideal or ambient sound is too loud, it may be difficult to hear the other person's voice during a call.
- Immediately after the ignition switch is placed in the ON position, it may be impossible to receive a call for a short period of time.
- Do not place the cellular phone in an area surrounded by metal or far away from the invehicle phone module to prevent tone quality degradation and wireless connection disruption.
- While a cellular phone is connected through the Bluetooth<sup>®</sup> wireless connection, the battery power of the cellular phone may discharge quicker than usual. The Bluetooth<sup>®</sup> Hands-Free Phone System cannot

- charge cellular phones.
- If the hands-free phone system seems to be malfunctioning, visit www.nissanusa.com/ bluetooth for troubleshooting help or contact your NISSAN dealer.
- Some cellular phones or other devices may cause interference or a buzzing noise to come from the audio system speakers.
   Storing the device in a different location may reduce or eliminate the noise.
- Refer to the cellular phone owner's manual regarding the telephone charges, cellular phone antenna and body, etc.
- The signal strength display on the monitor will not coincide with the signal strength display of some cellular phones.

## REGULATORY INFORMATION

#### FCC Regulatory information

- CAUTION: To maintain compliance with FCC's RF exposure guidelines, use only the supplied antenna. Unauthorized antenna, modification, or attachments could damage the transmitter and may violate FCC regulations.
- Operation is subject to the following two conditions:
- 1. This device may not cause interference and
- 2. This device may not cause interference and

# IC Regulatory information

- Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.



Bluetooth<sup>®</sup> is a trademark owned by Bluetooth SIG, Inc. and licensed to Bosch.

#### VOICE COMMAND

You can use voice commands to operate various Bluetooth® Hands-Free Phone System features using the NISSAN Voice Recognition system. For more details, see "NISSAN voice recognition system" (P.4-92).


## Voice Prompt Interrupt

While using the voice recognition system, the system voice can be interrupted to allow the user to speak commands. While the system is speaking, push the following button on the steering wheel. The system voice will stop and a tone will be heard. After the tone, speak desired command (displayed on the touch-screen).



#### One Shot Call

To use the system faster, you may speak the second level commands with the main menu command on the main menu. For example, push the for button and after the tone say, "Call Redial".



#### CONNECTING PROCEDURE

#### NOTE:

The connecting procedure must be performed when the vehicle is stationary. If the vehicle starts moving during the procedure, the procedure will be cancelled.

- 1. Push the APPS button on the control panel.
- 2. Touch the "Settings" key.
- 3. Touch the "Phone & Bluetooth" key.
- 4. Touch the "Connect New Device" key.
- Initiate the connecting process from the handset. The system will display the message: "Is PIN XXXXXX displayed on your Bluetooth device?". If the PIN is displayed

on your Bluetooth<sup>®</sup> device, select "Yes" to complete the pairing process.

For more information, see the Bluetooth® device's Owner's Manual.

#### VEHICLE PHONEBOOK

To access the vehicle phonebook:

- 1. Push the r button on the control panel.
- 2. Touch the "Phonebook" key.
- Choose the desired entry from the displayed list.
- The number of the entry will be displayed on the screen. Touch the number to initiate dialing.

#### NOTE:

To scroll quickly through the list, touch the "A-Z" key in the upper right corner of the screen. Turn the TUNE knob to choose a letter or number and then push AUDIO button. The list will move to the first entry that begins with that number or letter.

#### MAKING A CALL

To make a call, follow the procedure below:

Push the button on the control panel.
 The "Phone" screen will appear on the display.

- Select one of the following options to make a call:
- "Phonebook": Select the name from an entry stored in the vehicle phonebook.
- "Call Lists": Select the name from the incoming, outgoing or missed.
- "Redial": Dial the last outgoing call from the vehicle.
- "Image: Input the phone number manually using a keypad displayed on the screen. For information on how to use the touch-screen, see "How to use touch screen" (P.4-10).

#### RECEIVING A CALL

When a call is placed to the connected phone, the display will change to phone mode.

To accept the incoming call, either:

- Push the As button on the steering wheel.
- Touch the green phone icon on the screen. To reject the incoming call, either:

To reject the incoming call, either:

- Push the button on the steering wheel, or
- Touch the red phone icon on the screen.

#### **DURING A CALL**

While a call is active, the following options are available on the screen:

- "Handset"
   Select this option to switch control of the phone call over to the handset.
  - "Mute Mic."

    Select this option to mute the microphone.

    Select again to unmute the microphone.
- Red phone ( ) icon
   Select to end the phone call.

#### **ENDING A CALL**

To end a phone call, select the red phone ( ) icon on the screen or push the button on the steering wheel.

#### TEXT MESSAGING

# **A** WARNING


- Laws in some jurisdictions may restrict the use of some of the applications and features, such as social networking and texting.
- Laws in some jurisdictions may restrict the use of "Text-to-Speech".
   Check local regulations before using this feature.

- Use the text messaging feature after stopping your vehicle in a safe location. If you have to use the feature while driving, exercise extreme caution at all times so full attention may be given to vehicle operation.
- If you are unable to devote full attention to vehicle operation while using the text messaging feature, pull off the road to a safe location and stop your vehicle.

The system allows for the sending and receiving of text messages through the vehicle interface.

## Sending a text message

- 1. Push the 🚜 button on the steering wheel.
- 2. Say "Phone" after the tone.
- Say "Send Text" after the tone.
- The system will provide a list of available commands in order to determine the recipient of the text message. Choose from the following:
  - To (a name)
  - Enter Number
  - Missed Calls





- · Incoming Calls
- Outgoing Calls

For more information about these options, see "Voice command" (P.4-86).

- 5. Once a recipient is chosen, the system prompts for which message to send. Nine predefined messages are available as well as three custom messages. To choose one of the predefined messages, speak one of the following after the tone:
  - "Driving, can't text"
  - "Call me"
  - "On my way"
  - · "Running late"
  - · "Okay"
  - "Yes"
  - "No"
  - · "Where are you?"
  - "When?"

To send one of the custom messages, say "Custom Messages". If more than one custom message is stored, the system will prompt for the number of the desired custom message. For more information on setting and managing custom text messages, see "Bluetooth" settings" (P.4-90).

# Reading a received text message

- 1. Push the 🎉 button on the steering wheel.
- 2. Say "Phone" after the tone.
- 3. Say "Read Text" after the tone.

The text message, sender and delivery time are shown on the screen. Use the tuning switch to scroll through all text messages if more than one are available. Push the button to exit the text message screen. Push the button to access the following options for replying to the text message:

Call Back

Speak this command to call the sender of the text message using the Bluetooth<sup>®</sup> Hands-Free Phone System.

Send Text

Speak this command to send a text message response to the sender of the text message.

Read Text

Speak this command to read the text message again.

Previous Text


Speak this command to move to the previous text message (if available).

Next Text

Speak this command to move to the next text message (if available).

#### NOTE:

Text messages are only displayed if the vehicle speed is less than 5 MPH (8 km/h).



# Bluetooth® SETTINGS

To access the phone settings:

- 1. Push the APPS button.
- 2. Touch the "Settings" key.
- 3. Touch the "Phone & Bluetooth" key.



| Menu Item                | Result   |
|--------------------------|--|
| Phone Settings           | For detailed information, see "Phone settings" (P.4-92).   |
| Connect New Device       | Touch to connect a new Bluetooth® device to the Bluetooth® Hands-Free Phone System.                                    |
| Select Connected Device  | Touch to choose a Bluetooth® device from a list of those devices connected to the Bluetooth® Hands-Free Phone System.  |
| Replace Connected Device | Touch to replace a Bluetooth® device from a list of those devices connected to the Bluetooth® Hands-Free Phone System. |
| Delete Connected Device  | Touch to delete a Bluetooth® device from a list of those devices connected to the Bluetooth® Hands-Free Phone System.  |
| Bluetooth                | Touch to toggle Bluetooth® on and off.   |



#### PHONE SETTINGS

To access the phone settings:

- 1. Push the APPS button.
- 2. Touch the "Settings" key.
- 3. Touch the "Phone & Bluetooth" key.
- 4. Touch the "Phone Settings" key and adjust the following settings as desired:
- Sort Phonebook By:

Touch "First Name" or "Last Name" to choose how phonebook entries are alphabetically displayed on the screen.

Use Phonebook From:

Touch "Handset" to use the phone's phonebook. Select "SIM" to use the phonebook on the SIM card. Touch "Both" to use both sources.

• Download Phonebook Now:

Touch to download the phonebook to the vehicle from the chosen source.

• Record Name for Phonebook Entry:

Touch to record a name for a phonebook entry for use with the NISSAN Voice Recognition System.

Phone Notifications for:

Touch "Driver" to have phone notifications shown in the vehicle information display. Touch "Both" to have phone notifications shown in both the vehicle information display and the center display screen.

Text Messaging:

Touch to toggle the text message functionality on or off.

Show Incoming Text for:

Touch "Driver" to have incoming text notifications shown in the vehicle information display. Touch "Both" to have text notifications shown in both the vehicle information display and the center display screen. Touch "Off" to turn off all text notifications.

• Auto Reply:

Touch to toggle the auto reply functionality on or off.

• Auto Reply Message:

Touch to indicate preferred message to be sent when "Auto Reply" function is activated.

• Use Vehicle's Signature:

Touch to toggle on or off the addition of the vehicle signature to outgoing messages

Custom Text Messages:

Touch this option to select a custom message to edit. There are 4 customer message slots available.

# NISSAN VOICE RECOGNITION SYSTEM (if so equipped)


The NISSAN Voice Recognition system allows hands-free operation of the systems equipped on this vehicle, such as the phone and navigation systems.



#### USING THE SYSTEM

#### Initialization

When the ignition switch is in the ON position, NISSAN Voice Recognition is initialized, which takes a few seconds. When completed, the system is ready to accept voice commands. If the fig. button is pushed before the initialization completes, the system will announce: "Voice Recognition System not ready. Please wait."



## Giving voice commands

- 1. Push the Co. button.
- The system announces: "Please say a category like phone or a command like points of interest followed by a brand name".
   A list of available commands is then spoken by the system.
- After the tone sounds and the face icon on the display changes, speak a command. Available commands are discussed in this section.
- Voice and display feedback are provided when the command is accepted.
  - DEALER E-PROCESS


- If the command is not recognized, the system announces: "Command not recognized". Repeat the command in a clear voice.
- If you want to cancel the command or go back to the previous menu of commands, push the button. The system will announce: "Cancelling voice recognition" or "Go back" depending on the current menu level.
- Push the BACK button on the control panel to move back through the menus displayed on the screen.
- If you want to adjust the volume of the voice feedback, use the volume control switches on the steering wheel or the volume knob on the control panel.
- The voice command screen can also be accessed using the control panel display:
- 1. Push the APPS button.
- 2. Touch the "Voice Commands" key.

# Operating tips

To get the best performance out of NISSAN Voice Recognition, observe the following:

 Keep the interior of the vehicle as quiet as possible. Close the windows to eliminate the surrounding noises (traffic noises, vibration sounds, etc.), which may prevent the system from recognizing the voice commands correctly.

- Wait until a tone sounds before speaking a command. Otherwise, the command will not be received properly.
- Start speaking a command within 3.5 seconds after the tone sounds.
- Speak in a natural voice without pausing between words.



JVH0756X

#### SYSTEM FEATURES

NISSAN Voice Recognition can activate the following systems:

- Bluetooth® Hands-Free Phone System
- Navigation
- Audio
- Information
- My Apps

For additional information on the navigation system, see the separate Navigation System Owner's Manual.

#### How to say numbers

NISSAN Voice Recognition requires a certain way to speak numbers in voice commands. Refer to the following examples.

General rule: Either "zero" or "oh" can be used for "0".

#### Phone numbers:

Speak phone numbers according to the following example. For 1-800-662-6200, say dial number and then speak the phone number in any of the following formats:

- "one eight oh oh six six two six two oh oh"
- "one eight hundred six six two six two oh oh"
- "one eight zero zero six six two six two oh oh"

For the best voice recognition phone dialing results, say phone numbers as single digits. Also, full numbers can only be spoken for "800". For example, you cannot say 555-6000 as "five five five six thousand".

# Bluetooth® HANDS-FREE PHONE SYSTEM VOICE COMMANDS

To access the Bluetooth® Hands-Free Phone System voice commands:

- 1. Push the button.
- 2. Say "Call" and then a name in the vehicle phonebook to call that entry. Otherwise, say



"Phone" to access various phone commands.

If the Bluetooth® has been set to "Off", the system announces: "Bluetooth® is off. Would you like to turn Bluetooth® on?"

If no phone is connected to the system and the vehicle is stationary, the system announces: "There is no phone connected. Would you like to connect a phone now?" Say "Yes" to connect a phone. All further Bluetooth® Hands-Free Phone System voice commands are only available if a phone is connected.

If a phone is connected and Bluetooth® is set to "On", the following voice commands are available:

#### Call (a name)

Speak the name of the contact in which you are trying to call. System will confirm correct contact. Say "Dial" to initiate dialing.

#### Dial Number

Allows for up to 24 digits to be dialed. After the number is entered, say "Dial" to initiate dialing. Say "Correction" to correct the number entered. Say "Go Back" to return to the main menu.

#### List Phonebook

Starting with the first alphabetical entry in the vehicle phonebook, the system prompts for an additional command. Say "Dial" to call the number of the phonebook entry. Say "Send Text" to send a text message to the number of the phonebook entry. Say "Next Entry" to skip to the next alphabetical entry in the vehicle phonebook, where the same options will then be available.

#### Recent Calls

The system prompts for an additional command. Say "Missed Calls", "Incoming Calls" or "Outgoing Calls" to display a list of such calls on the screen.

Speak the number of the entry displayed on the screen to dial that number or say "Next Page" to view entries on the next page (if available).

#### Redial

Redials the last called number.

#### Read Text

Reads an incoming text message. For more information about text messaging with the Bluetooth® Hands-Free Phone System, see "Bluetooth ® Hands-Free Phone System (Type B)" (P.4-85).

#### Send Text

Sends a text message. For more information about text messaging with the Bluetooth® Hands-Free Phone System, see "Bluetooth ® Hands-Free Phone System (Type B)" (P.485).

#### Select Phone

The system replies "Please use manual controls to continue". Use manual controls to change the active phone from among the listed phones connected to the vehicle.

For more information about the Bluetooth® Hands-Free Phone System, see "Bluetooth ® Hands-Free Phone System (Type B)" (P.4-85).

## NAVIGATION SYSTEM VOICE COM-MANDS

The following voice commands are available for the Navigation System:

- Street Address (address)
- Points of Interest (name)
- POI by Category
- Home
- Address Book
- Previous Destinations
- Enter Address in Steps
- Cancel Route

For more information about these commands. see the separate Navigation System Owner's Manual.



#### AUDIO SYSTEM VOICE COMMANDS

To access the audio system voice commands:

- Push the button.
- 2. Say "Audio".
- Speak a command from the following available commands:
- Play (AM, FM, etc.)

Allows user to select radio band

• Tune AM (number)

Allows user to tune directly to a desired AM frequency

• Tune FM (number)

Allows user to tune directly to a desired FM frequency

• SXM channel (number)

Allows user to tune directly to a desired SXM station (if so equipped)

CD Track (number)

Allows user to select track to be played

Play Song (name)

Allows user to select song name to be played

Play Artist (name)

Allows user to select artist to be played

Play Album (name)

Allows user to select album name to be played

For more information about the audio system, see "FM-AM-SAT radio with Compact Disc (CD) player (Type C)" (P.4-57).

#### INFORMATION VOICE COMMANDS

The following voice commands are available for the information functions of the Navigation System:

- Traffic
- Fuel Prices
- Stocks
- Movie Listings
- Current Weather
- Weather Map
- 5 day Forecast
- 6 hour Forecast

For more information about these commands, see the separate Navigation System Owner's Manual.

#### MY APPS VOICE COMMANDS

Many Apps can be accessed using this voice command. See "NissanConnect<sup>TM</sup> App smartphone integration" (P.4-71).

#### HELP VOICE COMMANDS

The following voice commands can be spoken to have the system provide instructions and tips for using the NISSAN Voice Recognition system.

- List Commands
- What Can I Say?
- General Help
- Quit
- Exit



#### TROUBLESHOOTING GUIDE

The system should respond correctly to all voice commands without difficulty. If problems are encountered, follow the solutions given in this guide for the appropriate error. Where the solutions are listed by number, try each solution in turn, starting with number one, until the problem is resolved.

| Symptom/error message               | Solution  |
|-------------------------------------|---|
| to recognize the command correctly. | 1. Ensure that the command format is valid. Use the "List Commands" or "What Can I Say?" command under the "Help" menu.   |
|                                     | 2. Speak clearly without pausing between words and at a level appropriate to the ambient noise level.   |
|                                     | 3. Ensure that the ambient noise level is not excessive (for example, with the windows open or the defroster on).  NOTE:  If it is too noisy to use the phone, it is likely that voice commands will not be recognized. |
|                                     | 4. If optional words of the command have been omitted, then the command should be tried with these in place.  |



# **MEMO**



# 5 Starting and driving

| Precautions when starting and driving                | . 5-3 |
|--|-------|
| Exhaust gas (carbon monoxide)                        |       |
| Three-way catalyst                                   |       |
| Tire Pressure Monitoring System (TPMS)               | . 5-4 |
| Avoiding collision and rollover                      |       |
| Off-road recovery                                    |       |
| Rapid air pressure loss                              |       |
| Drinking alcohol/drugs and driving                   |       |
| Driving safety precautions                           |       |
| Ignition switch (models without Intelligent          |       |
| Key system)  | 5-10  |
| Continuously Variable Transmission (CVT)             | 5-11  |
| Manual Transmission (MT)                             | 5-11  |
| Key positions  | 5-12  |
| Push-button ignition switch (models with Intelligent |       |
| Key system)  | 5-12  |
| Operating range for engine start function            | 5-12  |
| Push-button ignition switch operation                | 5-13  |
| Push-button ignition switch positions                | 5-14  |
| Emergency engine shut off                            | 5-14  |
| Intelligent Key battery discharge                    | 5-14  |
| Before starting the engine                           | 5-15  |
| Starting the engine                                  | 5-15  |
| Models without Intelligent Key system                | 5-15  |
| Models with Intelligent Key system                   | 5-16  |

| Driving the vehicle                        | 5-17 |
|--|------|
| Continuously Variable Transmission (CVT)   | 5-17 |
| Manual Transmission (MT)                   | 5-23 |
| Integrated control system (if so equipped) | 5-25 |
| Drive mode                                 | 5-25 |
| Parking brake                              | 5-29 |
| Cruise control                             | 5-30 |
| Precautions on cruise control              | 5-30 |
| Cruise control operations                  | 5-30 |
| Break-in schedule                          | 5-31 |
| Fuel Efficient Driving Tips                | 5-32 |
| Increasing fuel economy                    | 5-33 |
| All-Wheel Drive (AWD) (if so equipped)     | 5-33 |
| All-Wheel Drive (AWD) mode                 |      |
| switch operations                          | 5-33 |
| AWD warning light                          | 5-35 |
| Parking/parking on hills                   | 5-37 |
| Electric power steering system             | 5-38 |
| Brake system                               | 5-39 |
| Braking precautions                        | 5-39 |
| Brake assist                               | 5-40 |
| Brake assist                               | 5-40 |
| Anti-lock Braking System (ABS)             | 5-40 |
| Vehicle Dynamic Control (VDC) system       | 5-41 |
| Cold weather driving                       | 5-43 |

| Freeing a frozen door lock | 5-43 | Tire equipment                       | 5-43 |
|----------------------------|------|--------------------------------------|------|
| Anti-freeze                | 5-43 | Special winter equipment             | 5-43 |
| Battery                    | 5-43 | Driving on snow or ice               | 5-43 |
| Draining of coolant water  | 5-43 | Engine block heater (if so equipped) | 5-44 |



# PRECAUTIONS WHEN STARTING AND DRIVING



# WARNING

- Do not leave children or adults who would normally require the support of others alone in your vehicle. Pets should not be left alone either. They could accidentally injure themselves or others through inadvertent operation of the vehicle. Also, on hot, sunny days, temperatures in a closed vehicle could quickly become high enough to cause severe or possibly fatal injuries to people or animals.
- Properly secure all cargo with ropes or straps to help prevent it from sliding or shifting. Do not place cargo higher than the seatbacks. In a sudden stop or collision, unsecured cargo could cause personal injury.

EXHAUST GAS (carbon monoxide)



# WARNING

- Do not breathe exhaust gases; they contain colorless and odorless carbon monoxide. Carbon monoxide is dangerous. It can cause unconsciousness or death.
- If you suspect that exhaust fumes are entering the vehicle, drive with all windows fully open, and have the vehicle inspected immediately.
- Do not run the engine in closed spaces such as a garage.
- Do not park the vehicle with the engine running for any extended length of time.
- Keep the lift gate closed while driving, otherwise exhaust gases could be drawn into the passenger compartment. If you must drive with the lift gate open, follow these precautions:
  - 1. Open all the windows.
  - 2. Set the ( air recirculation to off and the fan control to high to

circulate the air.

- If electrical wiring or other cable connections must pass to a trailer through the seal on the lift gate or the body, follow the manufacturer's recommendation to prevent carbon monoxide entry into the vehicle.
- If a special body, camper or other equipment is added for recreational or other usage, follow the manufacturer's recommendation to prevent carbon monoxide entry into the vehicle. (Some recreational vehicle appliances such as stoves, refrigerators, heaters, etc. may also generate carbon monoxide.)
- The exhaust system and body should be inspected by a qualified mechanic whenever:
  - The vehicle is raised for service.
  - You suspect that exhaust fumes are entering into the passenger compartment.
  - You notice a change in the sound of the exhaust system.
  - You have had an accident involving damage to the exhaust



system, underbody, or rear of the vehicle.

#### THREE-WAY CATALYST

The three-way catalyst is an emission control device installed in the exhaust system. Exhaust gases in the three-way catalyst are burned at high temperatures to help reduce pollutants.

# **A** WARNING

- The exhaust gas and the exhaust system are very hot. Keep people, animals or flammable materials away from the exhaust system components.
- Do not stop or park the vehicle over flammable materials such as dry grass, waste paper or rags. They may ignite and cause a fire.

# **A** CAUTION

Do not use leaded gasoline. Deposits from leaded gasoline will seriously reduce the three-way catalyst's ability to help reduce ex-

### haust pollutants.

- Keep your engine tuned up. Malfunctions in the ignition, fuel injection, or electrical systems can cause overrich fuel flow into the three-way catalyst, causing it to overheat. Do not keep driving if the engine misfires, or if noticeable loss of performance or other unusual operating conditions are detected. Have the vehicle inspected promptly by a NISSAN dealer.
- Avoid driving with an extremely low fuel level. Running out of fuel could cause the engine to misfire, damaging the three-way catalyst.
- Do not race the engine while warming it up.
- Do not push or tow your vehicle to start the engine.

# TIRE PRESSURE MONITORING SYSTEM (TPMS)

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a Tire Pressure Monitoring System (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire



pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

#### Additional information

- The TPMS does not monitor the tire pressure of the spare tire.
- The TPMS will activate only when the vehicle is driven at speeds above 16 MPH (25 km/h). Also, this system may not detect a sudden drop in tire pressure (for example a

flat tire while driving).

- The low tire pressure warning light does not automatically turn off when the tire pressure is adjusted. After the tire is inflated to the recommended pressure, the vehicle must be driven at speeds above 16 MPH (25 km/h) to activate the TPMS and turn off the low tire pressure warning light. Use a tire pressure gauge to check the tire pressure.
- The CHECK TIRE PRES (pressure) warning message is displayed in the vehicle information display when the low tire pressure warning light is illuminated and low tire pressure is detected. The CHECK TIRE PRES warning message turns off when the low tire pressure warning light turns off. The low tire pressure warning light remains illuminated until the tires are inflated to the recommended COLD tire pressure. The CHECK TIRE PRES warning message is displayed each time the ignition switch is placed in the ON position as long as the low tire pressure warning light remains illuminated. "Check tire pressure warning message" (P.2-7).
- The CHECK TIRE PRES warning message is not displayed if the low tire pressure warning light illuminates to indicate a TPMS malfunction.

Tire pressure rises and falls depending on the heat caused by the vehicle's operation and the outside temperature. Low outside temperature can lower the temperature of the air inside the tire which can cause a lower tire inflation pressure. This may cause the low tire pressure warning light to illuminate. If the warning light illuminates in low ambient temperature, check the tire pressure for all four tires.

For additional information, see "Low tire pressure warning light" (P.2-15) and "Tire Pressure Monitoring System (TPMS)" (P.6-3).

# **WARNING**

If the low tire pressure warning light illuminates while driving, avoid sudden steering maneuvers or abrupt braking, reduce vehicle speed, pull off the road to a safe location and stop the vehicle as soon as possible. Driving with under-inflated tires may permanently damage the tires and increase the likelihood of tire failure. Serious vehicle damage could occur and may lead to an accident and could result in serious personal injury. Check the tire pres-



sure for all four tires. Adjust the tire pressure to the recommended COLD tire pressure shown on the Tire and Loading Information label to turn the low tire pressure warning light OFF. If you have a flat tire, replace it with a spare tire as soon as possible. (See "Flat tire" (P.6-3) for changing a flat tire.)

- When a spare tire is mounted or a wheel is replaced, the TPMS will not function and the low tire pressure warning light will flash for approximately 1 minute. The light will remain on after 1 minute. Contact your NISSAN dealer as soon as possible for tire replacement and/ or system resetting.
- Replacing tires with those not originally specified by NISSAN could affect the proper operation of the TPMS.
- Do not inject any tire liquid or aerosol tire sealant into the tires, as this may cause a malfunction of the tire pressure sensors.

# **A** CAUTION

- The TPMS may not function properly when the wheels are equipped with tire chains or the wheels are buried in snow.
- Do not place metalized film or any metal parts (antenna, etc.) on the windows. This may cause poor reception of the signals from the tire pressure sensors, and the TPMS will not function properly.

Some devices and transmitters may temporarily interfere with the operation of the TPMS and cause the low tire pressure warning light to illuminate. Some examples are:

- Facilities or electric devices using similar radio frequencies are near the vehicle.
- If a transmitter set to similar frequencies is being used in or near the vehicle.
- If a computer (or similar equipment) or a DC/ AC converter is being used in or near the vehicle.

#### **FCC Notice:**

#### For USA:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### For Canada:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



## AVOIDING COLLISION AND ROLL-**OVER**

# **WARNING**

Failure to operate this vehicle in a safe and prudent manner may result in loss of control or an accident.

Be alert and drive defensively at all times. Obey all traffic regulations. Avoid excessive speed, high speed cornering, or sudden steering maneuvers, because these driving practices could cause you to lose control of your vehicle. As with any vehicle, a loss of control could result in a collision with other vehicles or objects, or cause the vehicle to rollover, particularly if the loss of control causes the vehicle to slide sideways. Be attentive at all times, and avoid driving when tired. Never drive when under the influence of alcohol or drugs (including prescription or over-the-counter drugs which may cause drowsiness). Always wear your seat belt as outlined in "Seat belts" (P.1-10) of this manual, and also instruct your passengers to do so.

Seat belts help reduce the risk of injury in collisions and rollovers. In a rollover crash, an unbelted or improperly belted person is significantly more likely to be injured or killed than a person properly wearing a seat belt.

#### OFF-ROAD RECOVERY

If the right side or left side wheels leave the road surface, maintain control of the vehicle by following the procedure below. Please note that this procedure is only a general guide. The vehicle must be driven as appropriate based on the conditions of the vehicle, road and traffic.

- 1. Remain calm and do not overreact.
- 2. Do not apply the brakes.
- 3. Maintain a firm grip on the steering wheel with both hands and try to hold a straight course.
- 4. When appropriate, slowly release the accelerator pedal to gradually slow the vehicle.
- 5. If there is nothing in the way, steer the vehicle to follow the road while the vehicle speed is reduced. Do not attempt to drive the vehicle back onto the road surface until vehicle speed is reduced.
- 6. When it is safe to do so, gradually turn the steering wheel until both tires return to the road surface. When all tires are on the road surface, steer the vehicle to stay in the appropriate driving lane.

 If you decide that it is not safe to return the vehicle to the road surface based on vehicle, road or traffic conditions, gradually slow the vehicle to a stop in a safe place off the road.

### RAPID AIR PRESSURE LOSS

Rapid air pressure loss or a "blow-out" can occur if the tire is punctured or is damaged due to hitting a curb or pothole. Rapid air pressure loss can also be caused by driving on underinflated tires.

Rapid air pressure loss can affect the handling and stability of the vehicle, especially at highway speeds.

Help prevent rapid air pressure loss by maintaining the correct air pressure and visually inspect the tires for wear and damage. See "Wheels and tires" (P.8-30) of this manual.

If a tire rapidly loses air pressure or "blows-out" while driving maintain control of the vehicle by following the procedure below. Please note that this procedure is only a general guide. The vehicle must be driven as appropriate based on the conditions of the vehicle, road and traffic.



# WARNING

The following actions can increase the chance of losing control of the vehicle if there is a sudden loss of tire air pressure. Losing control of the vehicle may cause a collision and result in personal injury.

- The vehicle generally moves or pulls in the direction of the flat tire.
- Do not rapidly apply the brakes.
- Do not rapidly release the accelerator pedal.
- Do not rapidly turn the steering wheel.
- 1. Remain calm and do not overreact.
- 2. Maintain a firm grip on the steering wheel with both hands and try to hold a straight course.
- 3. When appropriate, slowly release the accelerator pedal to gradually slow the vehicle.
- 4. Gradually steer the vehicle to a safe location off the road and away from traffic if possible.
- 5. Lightly apply the brake pedal to gradually stop the vehicle.

6. Turn on the hazard warning flashers and either contact a roadside emergency service to change the tire or see "Changing a flat tire" (P.6-3) of this Owner's Manual.

DRINKING ALCOHOL/DRUGS AND DRIVING



# WARNING

Never drive under the influence of alcohol or drugs. Alcohol in the bloodstream reduces coordination, delays reaction time and impairs judgement. Driving after drinking alcohol increases the likelihood of being involved in an accident injuring yourself and others. Additionally, if you are injured in an accident, alcohol can increase the severity of the injury.

NISSAN is committed to safe driving. However, you must choose not to drive under the influence of alcohol. Every year thousands of people are injured or killed in alcohol-related accidents. Although the local laws vary on what is considered to be legally intoxicated, the fact is that alcohol affects all people differently and most people underestimate the effects of alcohol.

Remember, drinking and driving don't mix! And that is true for drugs, too (over-the-counter, prescription, and illegal drugs). Don't drive if your ability to operate your vehicle is impaired by alcohol, drugs, or some other physical condition.

#### DRIVING SAFETY PRECAUTIONS

Your NISSAN is designed for both normal and off-road use. However, avoid driving in deep water or mud as your NISSAN is mainly designed for leisure use, unlike a conventional off-road vehicle.

Remember that Two-Wheel Drive (2WD) models are less capable than All-Wheel Drive (AWD) models for rough road driving and extrication when stuck in deep snow, mud, or the like.

Please observe the following precautions:



# **WARNING**

Drive carefully when off the road and avoid dangerous areas. Every person who drives or rides in this vehicle should be seated with their seat belt fastened. This will keep you and your passengers in position when driving over rough terrain.

- Do not drive across steep slopes. Instead drive either straight up or straight down the slopes. Off-road vehicles can tip over sideways much more easily than they can forward or backward.
- Many hills are too steep for any vehicle. If you drive up them, you may stall. If you drive down them, vou may not be able to control your speed. If you drive across them, you may roll over.
- . Do not shift ranges while driving on downhill grades as this could cause loss of control of the vehicle.
- . Stay alert when driving to the top of a hill. At the top there could be a drop-off or other hazard that could cause an accident.
- If your engine stalls or you cannot make it to the top of a steep hill, never attempt to turn around. Your vehicle could tip or roll over. Always back straight down in R (Reverse) range. Never back down in N (Neutral), using only the brake, as this could cause loss of control.

- Heavy braking going down a hill could cause your brakes to overheat and fade, resulting in loss of control and an accident. Apply brakes lightly and use a low range to control your speed.
- Unsecured cargo can be thrown around when driving over rough terrain. Properly secure all cargo so it will not be thrown forward and cause injury to you or your passengers.
- To avoid raising the center of gravity excessively, do not exceed the rated capacity of the roof rack (if so equipped) and evenly distribute the load. Secure heavy loads in the cargo area as far forward and as low as possible. Do not equip the vehicle with tires larger than specified in this manual. This could cause vour vehicle to roll over.
- Do not grip the inside or spokes of the steering wheel when driving offroad. The steering wheel could move suddenly and injure your hands. Instead drive with your fingers and thumbs on the outside of the rim.

- Before operating the vehicle, ensure that the driver and all passengers have their seat belts fastened.
- Always drive with the floor mats in place as the floor may became hot.
- Lower your speed when encountering strong crosswinds. With a higher center of gravity, your NISSAN is more affected by strong side winds. Slower speeds ensure better vehicle control.
- Do not drive beyond the performance capability of the tires, even with AWD engaged.
- For AWD equipped vehicles, do not attempt to raise two wheels off the ground and shift the transmission to any drive or reverse position with the engine running. Doing so may result in drivetrain damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.
- Do not attempt to test an AWD equipped vehicle on a 2-wheel dynamometer (such as the dynamometers used by some states for emissions testing), or similar equip-

ment even if the other two wheels are raised off the ground. Make sure you inform test facility personnel that your vehicle is equipped with AWD before it is placed on a dynamometer. Using the wrong test equipment may result in drivetrain damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.

- When a wheel is off the ground due to an unlevel surface, do not spin the wheel excessively (AWD model).
- Accelerating quickly, sharp steering maneuvers or sudden braking may cause loss of control.
- If at all possible, avoid sharp turning maneuvers, particularly at high speeds. Your vehicle has a higher center of gravity than a conventional passenger car. The vehicle is not designed for cornering at the same speeds as conventional passenger cars. Failure to operate this vehicle correctly could result in loss of control and/or a rollover accident.
- Always use tires of the same type, size, brand, construction (bias, bias-

belted or radial), and tread pattern on all four wheels. Install traction devices on the front wheels when driving on slippery roads and drive carefully.


- Be sure to check the brakes immediately after driving in mud or water. See "Brake system" (P.5-39) for wet brakes.
- Avoid parking your vehicle on steep hills. If you get out of the vehicle and it rolls forward, backward or sideways, you could be injured.
- Whenever you drive off-road through sand, mud or water as deep as the wheel hub, more frequent maintenance may be required. See the maintenance information in the "NISSAN Service and Maintenance Guide".
- Spinning the front wheels on slippery surfaces may cause the AWD warning light to flash and the AWD system to automatically switch from the AWD mode to the 2WD mode. This could reduce traction. Be especially careful when towing a trailer (AWD model).

# IGNITION SWITCH (models without Intelligent Key system)



# **WARNING**

Never remove or turn the key to the LOCK position while driving. This may cause the driver to lose control of the vehicle and could result in serious vehicle damage or personal injury.



# CONTINUOUSLY VARIABLE TRANS-MISSION (CVT)

The ignition lock is designed so that the ignition switch cannot be turned to the LOCK position until the shift lever is moved to the P (Park) position.


- When turning the ignition switch to the LOCK position, make sure that the shift lever is in the P (Park) position.
- When removing the key from the ignition switch, make sure that the shift lever is in the P (Park) position.

When the ignition switch cannot be turned to the LOCK position:

- 1. Move the shift lever to the P (Park) position.
- Turn the ignition switch slightly in the ON direction.
- 3. Turn the ignition switch to the LOCK position.
- 4. Remove the key.

If the ignition switch is turned to the LOCK position, the shift lever cannot be moved from the P (Park) position. The shift lever can be moved if the ignition switch is in the ON position with the foot brake pedal depressed.

There is an OFF position ① between the LOCK and ACC positions, although it is not marked on the ignition switch.



# MANUAL TRANSMISSION (MT)

The ignition switch includes a device that helps prevent accidental removal of the key while driving.

The key can only be removed when the ignition switch is in the LOCK position.

To turn the ignition switch to the LOCK position from the ACC or ON position, turn the key to the OFF position, push the key in, then turn the key to the LOCK position.

There is an OFF position (1) in between the LOCK and ACC positions. The OFF position is indicated by a "1" on the key cylinder.



# **PUSH-BUTTON IGNITION SWITCH** (models with Intelligent Key system)

### **KEY POSITIONS**

# LOCK (0)

The key can only be removed from the ignition switch at this position.

# OFF (1)

The engine is turned off. The power supply is turned off.

# ACC (2)

The electrical accessory power activates without the engine turned on.

# ON (3)

The ignition system and the electrical accessory power activate without the engine turned on.

## START (4)

The engine starter activates and the engine will start. The ignition switch, when released, will automatically turn to the ON position.




As soon as the engine has started, release the ignition switch immediately.

# **WARNING**

Do not operate the push-button ignition switch while driving the vehicle except in an emergency. (The engine will stop when the ignition switch is pushed 3 consecutive times or the ignition switch is pushed and held for more than 2 seconds.) If the engine stops while the vehicle is being driven, this could lead to a crash and serious injury.

Before operating the push-button ignition switch, be sure to move the shift lever to the P (Park) position (for Continuously Variable Transmission models) or the shift lever to the N (Neutral) position (for manual transmission models).



## OPERATING RANGE FOR ENGINE START FUNCTION


The Intelligent Key can only be used for starting the engine when the Intelligent Key is within the specified operating range (1).

When the Intelligent Key battery is almost discharged or strong radio waves are present near the operating location, the Intelligent Key system's operating range becomes narrower and may not function properly.

If the Intelligent Key is within the operating range, it is possible for anyone, even someone who does not carry the Intelligent Key, to push the ignition switch to start the engine.



- The cargo room area is not included in the operating range but the Intelligent Key may function.
- If the Intelligent Key is placed on the instrument panel, inside the glove box or door pocket, the Intelligent Key may not function.
- If the Intelligent Key is placed near the door or window outside the vehicle, the Intelligent Key may function.



## **PUSH-BUTTON IGNITION SWITCH OPERATION**

When the ignition switch is pushed without depressing the brake pedal (Continuously Variable Transmission models) or the clutch pedal (manual transmission models), the ignition switch position will change as follows:

- Push once to change to ACC.
- Push two times to change to ON.
- Push three times to change to OFF.
- Push four times to return to ACC.
- Open or close any door to return to LOCK during the OFF position.

The indicator light (A) on the ignition switch

illuminates when the ignition switch is in the ACC or ON position.

Some indicators and warnings for operation are displayed on the meter. (See "Warning/indicator lights and audible reminders" (P.2-12).)

## Continuously Variable Transmission models

The ignition lock is designed so that the ignition switch position cannot be switched to LOCK until the shift lever is moved to the P (Park) position.

When the ignition switch cannot be pushed toward the LOCK position, proceed as follows:

- 1. Move the shift lever into the P (Park) position.
- 2. Push the ignition switch to the OFF position.
- 3. Open the door. The ignition switch will change to the LOCK position.

The shift lever can be moved from the P (Park) position if the ignition switch is in the ON position and the brake pedal is depressed.

# PUSH-BUTTON IGNITION SWITCH POSITIONS

# LOCK (Normal parking position)

The ignition switch can only be locked in this position.

The ignition switch will be unlocked when it is pushed to the ACC position while carrying the Intelligent Key.

# ACC (Accessories)

This position activates electrical accessories such as the radio, when the engine is not running.

# ON (Normal operating position)

This position turns on the ignition system and electrical accessories.

## OFF

The engine can be turned off in this position.

Continuously Variable Transmission models: The ignition lock is designed so that the ignition switch cannot be switched to the LOCK position until the shift lever is moved to the P (Park) position.




Do not leave the vehicle with the pushbutton ignition switch in ACC or ON position when the engine is not running for an extended period. This can discharge the battery.

### **EMERGENCY ENGINE SHUT OFF**

To shut off the engine in an emergency situation while driving, perform the following procedure:

- Rapidly push the push-button ignition switch
   3 consecutive times in less than 1.5 seconds, or
- Push and hold the push-button ignition switch for more than 2 seconds.



# INTELLIGENT KEY BATTERY DIS-CHARGE

If the battery of the Intelligent Key is discharged, or environmental conditions interfere with the Intelligent Key operation, start the engine according to the following procedure:

- Move the shift lever to the P (Park) position (for Continuously Variable Transmission models) or the shift lever to the N (Neutral) position (for manual transmission models).
- 2. Firmly apply the foot brake.
- 3. Touch the ignition switch with the Intelligent Key as illustrated. (A chime will sound.)



## Push the ignition switch while depressing the brake pedal within 10 seconds after the chime sounds. The engine will start.

After step 3 is performed, when the ignition switch is pushed without depressing the brake pedal, the ignition switch position will change to ACC.

#### NOTE:

- When the ignition switch is pushed to the ACC or ON position or the engine is started by the above procedures, the Intelligent Key system warning light may blink in yellow even if the Intelligent Key is inside the vehicle. This is not a malfunction. To stop the warning light from blinking, touch the ignition switch with the Intelligent Key again.
- If the Intelligent Key system warning light in the meter is blinking in green, replace the battery as soon as possible. (See "Key battery replacement" (P.8-22).)

### **BEFORE STARTING THE ENGINE**

- Make sure the area around the vehicle is clear.
- Check fluid levels such as engine oil, coolant, brake fluid, and window washer fluid as frequently as possible, or at least whenever you refuel.
- Check that all windows and lights are clean.
- Visually inspect tires for their appearance and condition. Also check tires for proper inflation.
- Lock all doors.
- Position seat and adjust head restraints.
- · Adjust inside and outside mirrors.
- Fasten seat belts and ask all passengers to do likewise.
- Check the operation of warning lights when the ignition switch is placed in the ON position. (See "Warning/indicator lights and audible reminders" (P.2-12).)

### STARTING THE ENGINE

# MODELS WITHOUT INTELLIGENT KEY SYSTEM

- 1. Apply the parking brake.
- 2. Continuously Variable Transmission (CVT) models:

Move the shift lever to the P (Park) or N (Neutral) position. (P is recommended.)

The starter is designed so that it does not operate unless the shift lever is in either of the above positions.

#### Manual Transmission (MT) models:

Move the shift lever to the N (Neutral) position. Depress the clutch pedal fully to the floor.

The starter is designed not to operate unless the clutch pedal is fully depressed.

- Crank the engine with your foot off the accelerator pedal by turning the ignition switch to START. Release the switch when the engine starts. If the engine starts, but fails to run, repeat the above procedure.
  - If the engine is very hard to start in extremely cold weather or when restarting, depress the accelerator pedal a little (approximately 1/3 to the floor) and hold it and then crank the engine. Release the accelerator pedal when the engine starts.



• If the engine is very hard to start because it is flooded, depress the accelerator pedal all the way to the floor and hold it. Crank the engine for 5 - 6 seconds. After cranking the engine, release the accelerator pedal. Crank the engine with your foot off the accelerator pedal by turning the ignition switch to START. Release the ignition switch when the engine starts. If the engine starts, but fails to run, repeat the above procedure.



Do not operate the starter for more than 15 seconds at a time. If the engine does not start, turn the ignition switch off and wait 10 seconds before cranking again, otherwise the starter could be damaged.

#### 4. Warm-up

Allow the engine to idle for at least 30 seconds after starting. Do not race the engine while warming it up. Drive at moderate speed for a short distance first, especially in cold weather. In cold weather, keep the engine running for a minimum of 2 - 3 minutes before shutting it off. Starting and

- stopping the engine over a short period of time may make the vehicle more difficult to start.
- To stop the engine, move the shift lever to the P (Park) position (CVT model) or move the shift lever to the N (Neutral) position (MT model), and turn the ignition switch to the OFF position.

#### NOTE:

Care should be taken to avoid situations that can lead to potential battery discharge and potential no-start conditions such as:

- Installation or extended use of electronic accessories that consume battery power when the engine is not running (Phone chargers, GPS, DVD players, etc.)
- Vehicle is not driven regularly and/or only driven short distances.

In these cases, the battery may need to be charged to maintain battery health.

MODELS WITH INTELLIGENT KEY SYSTEM

- 1. Apply the parking brake.
- 2. Move the shift lever to the P (Park) or N (Neutral) position. (P is recommended.)

The starter is designed not to operate unless

the shift lever is in either of the above positions.

#### **Manual Transmission (MT) models:**

Move the shift lever to the N (Neutral) position. Depress the clutch pedal fully to the floor.

The starter is designed not to operate unless the clutch pedal is fully depressed.

# The Intelligent Key must be carried when operating the ignition switch.

Push the ignition switch to the ON position.
 Depress the brake pedal (CVT models) or
 the clutch pedal (MT models) and push the
 ignition switch to start the engine.

To start the engine immediately, push and release the ignition switch while depressing the brake pedal with the ignition switch in any position.

- If the engine is very hard to start in extremely cold weather or when restarting, depress the accelerator pedal a little (approximately 1/3 to the floor) and while holding, crank the engine. Release the accelerator pedal when the engine starts.
- If the engine is very hard to start because it is flooded, depress the accelerator pedal all the way to the floor and hold it.
   Push the ignition switch to the ON

position to start cranking the engine. After 5 or 6 seconds, stop cranking by pushing the ignition switch to OFF. After cranking the engine, release the accelerator pedal. Crank the engine with your foot off the accelerator pedal by depressing the brake pedal and pushing the push-button ignition switch to start the engine. If the engine starts, but fails to run, repeat the above procedure.

# **A** CAUTION

Do not operate the starter for more than 15 seconds at a time. If the engine does not start, push the ignition switch to OFF and wait 10 seconds before cranking again, otherwise the starter could be damaged.

#### 4. Warm-up

Allow the engine to idle for at least 30 seconds after starting. Do not race the engine while warming it up. Drive at moderate speed for a short distance first, especially in cold weather. In cold weather, keep the engine running for a minimum of 2 - 3 minutes before shutting it off. Starting and stopping the engine over a short period of

time may make the vehicle more difficult to start.

When racing the engine up to 4,000 rpm or more under no load condition, the engine will enter the fuel cut mode.

 To stop the engine, move the shift lever to the P (Park) position (CVT models) or move the shift lever to the N (Neutral) position (MT models), and push the ignition switch to the OFF position.

#### NOTE:

Care should be taken to avoid situations that can lead to potential battery discharge and potential no-start conditions such as:

- Installation or extended use of electronic accessories that consume battery power when the engine is not running (Phone chargers, GPS, DVD players, etc.)
- Vehicle is not driven regularly and/or only driven short distances.

In these cases, the battery may need to be charged to maintain battery health.



### **DRIVING THE VEHICLE**

## CONTINUOUSLY VARIABLE TRANS-MISSION (CVT)

The Continuously Variable Transmission (CVT) in your vehicle is electronically controlled to produce maximum power and smooth operation.

The recommended operating procedures for this transmission are shown on the following pages. Follow these procedures for maximum vehicle performance and driving enjoyment.

Engine power may be automatically reduced to protect the CVT if the engine speed increases quickly when driving on slippery roads or while being tested on some dynamometers.

Starting the vehicle

 After starting the engine, fully depress the foot brake pedal before moving the shift lever out of the P (Park) position.

This CVT is designed so that the foot brake pedal must be depressed before shifting from P (Park) to any driving position while the ignition switch is in the ON position.

The shift lever cannot be moved out of the P (Park) position and into any of the other positions if the ignition switch is placed in the LOCK, OFF or ACC position or if the key is removed.

Starting and driving 5-17


- Keep the foot brake pedal depressed, push the shift lever button and move the shift lever to a driving position.
- Release the parking brake and foot brake pedal, and then gradually start the vehicle in motion.

# **A** WARNING

- Do not depress the accelerator pedal while shifting from P (Park) or N (Neutral) to R (Reverse) or D (Drive). Always depress the brake pedal until shifting is completed. Failure to do so could cause you to lose control and have an accident.
- Cold engine idle speed is high, so use caution when shifting into a forward or reverse gear before the engine has warmed up.
- Never shift to P (Park) or R (Reverse) while vehicle is moving. Failure to do so could cause you to lose control and have an accident.

# **A** CAUTION

- Except in an emergency, do not shift to the N (Neutral) position while driving. Coasting with the transmission in the N (Neutral) position may cause serious damage to the transmission.
- When stopping the vehicle on an uphill grade, do not hold the vehicle by depressing the accelerator pedal.
   The foot brake should be used for this purpose.
- Do not downshift abruptly on slippery roads. This may cause a loss of control.



To move the shift lever,

Push the button (A) while depressing the brake pedal.

Push the button (A).

: Just move the shift lever.

# Shifting

After starting the engine, fully depress the brake pedal, push the shift lever button and move the shift lever from the P (Park) position to any of the desired shift positions.



# **A** WARNING

Apply the parking brake if the shift lever is in any position while the engine is not running. Failure to do so could cause the vehicle to move unexpectedly or roll away and result in serious personal injury or property damage.

If the ignition switch is placed in the OFF or ACC position for any reason while the shift lever is in any positions other than the P (Park), the ignition switch cannot be placed in the LOCK position.

If the ignition switch cannot be placed in the LOCK position, perform the following steps:

- 1. Apply the parking brake when the vehicle is stopped.
- 2. Place the ignition switch in the ON position while depressing the foot brake pedal.
- 3. Move the shift lever to the P (Park) position.
- Models with Intelligent Key system:
   Place the ignition switch in the OFF position.

   Models without Intelligent Key system:
   Place the ignition switch in the LOCK position.



To prevent transmission damage, move the shift lever to the P (Park) or R (Reverse) position only when the vehicle is completely stopped.

### P (Park):


Use this position when the vehicle is parked or when starting the engine. Make sure the vehicle is completely stopped. The brake pedal must be depressed and the shift lever button pushed in to move the shift lever from N (Neutral) or any drive position to P (Park). Apply the parking brake. When parking on a hill, apply the parking brake first, then move the shift lever to the P (Park) position.

### R (Reverse):

Use this position to back up. Make sure the vehicle is completely stopped before selecting the R (Reverse) position. The brake pedal must be depressed and the shift lever button pushed in to move the shift lever from P (Park), N (Neutral) or any driving position to R (Reverse).

### N (Neutral):


Neither forward nor reverse gear is engaged.



#### D (Drive):

Use this position for all normal forward driving.





Paddle shifter (if so equipped)

Manual shift mode (if so equipped)

When the shift lever is shifted from the D position to the manual shift gate, the transmission enters the manual shift mode. Shift ranges can be selected manually by moving the shift lever up or down, or pulling the right-side or left-side paddle shifter (if so equipped).

In the manual shift mode, the shift range is displayed on the position indicator in the meter. Shift ranges up or down one by one as follows: Except for NISMO and NISMO RS models:

 $M1 \xrightarrow{\rightarrow} M2 \xrightarrow{\leftarrow} M3 \xrightarrow{\leftarrow} M4 \xrightarrow{\rightarrow} M5 \xrightarrow{\leftarrow} M6$ 

NISMO models:

NISMO RS models:

 $M1 \begin{array}{c} \rightarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \end{array} M2 \begin{array}{c} \rightarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \end{array} M3 \begin{array}{c} \rightarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \end{array} M4 \begin{array}{c} \rightarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \end{array} M5 \begin{array}{c} \rightarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \end{array} M6 \begin{array}{c} \rightarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \leftarrow \\ \end{array} M8$ 

- When shifting up, move the shift lever to the + (up) side or pull the right-side paddle shifter (+) (A) (if so equipped). The transmission shifts to a higher range.
- When shifting down, move the shift lever to the - (down) side or pull the left-side paddle shifter (-) (B) (if so equipped). The transmission shifts to a lower range.
- Moving the shift lever to the same side twice will shift the ranges in succession. However, if this motion is rapidly done, the second shifting may not be completed properly.
- When canceling the manual shift mode, return the shift lever to the D (Drive) position.
   The transmission returns to the normal driving mode.
- When you pull the paddle shifter (if so equipped) while in the D (Drive) position, the

transmission will shift to the upper or lower range temporarily. The transmission will automatically return to the D (Drive) position after a short period of time. If you want to return to the D (Drive) position manually, pull and hold the paddle shifter for about 1.5 seconds.

M6 (6th) (except for NISMO and NISMO RS models):

M7 (7th) (NISMO models):

M8 (8th) (NISMO RS models):

Use this position for all normal forward driving at highway speeds.

M5 (5th) (except for NISMO and NISMO RS models):

M6 (6th) and M5 (5th) (NISMO models):

M7 (7th) and M6 (6th) (NISMO RS models):

Use these positions when driving up long slopes, or for engine braking when driving down long slopes.

M4 (4th), M3 (3rd) and M2 (2nd) (except for NISMO RS models):

M5 (5th), M4 (4th), M3 (3rd) and M2 (2nd) (NISMO RS models):

Use these positions for hill climbing or engine braking on downhill grades.

#### M1 (1st):

Use this position when climbing steep hills slowly or driving slowly through deep snow, sand or mud, or for maximum engine braking on steep downhill grades.

- Remember not to drive at high speeds for extended periods of time in lower than M6 (except for NISMO and NISMO RS models), M7 (NISMO models) or M8 (NISMO RS models) range. This reduces fuel economy.
- In the manual shift mode, the transmission may not shift to the selected range. This helps maintain driving performance and reduces the chance of vehicle damage or loss of control. When this situation occurs, the Continuously Variable Transmission (CVT) position indicator light will blink and the chime will sound.
- In the manual shift mode, the transmission automatically shifts down to 1st gear before the vehicle comes to a stop. When accelerating again, it is necessary to shift up to the desired range.
- When the CVT fluid temperature is extremely low, the manual shift mode may not work and automatically shift as a drive mode.
   This is not a malfunction. In this case, return

- the shift lever to the D position and drive for a while and then shift to the manual shift mode.
- When the CVT fluid temperature is high, the shift range may upshift at a lower engine speed than usual. This is not a malfunction.

Accelerator downshift — In D position — For passing or hill climbing, fully depress the accelerator pedal to the floor. This shifts the transmission down into a lower gear, depending on the vehicle speed.

High fluid temperature protection mode
This transmission has a high fluid temperature
protection mode. If the fluid temperature becomes too high (for example, when climbing
steep grades in high temperature with heavy
loads), engine power and, under some conditions, vehicle speed will be decreased automatically to reduce the chance of transmission
damage. Vehicle speed can be controlled with
the accelerator pedal, but the engine and vehicle
speed may be limited.

#### Fail-safe


If the vehicle is driven under extreme conditions, such as excessive wheel spinning and subsequent hard braking, the fail-safe system may be activated. The MIL may illuminate to indicate the fail-safe mode is activated. (See "Malfunction Indicator Light (MIL)" (P.2-18).) This will occur even if all electrical circuits are functioning properly. In this case, place the ignition switch in the OFF position and wait for 10 seconds. Then turn the switch back to the ON position. The vehicle should return to its normal operating condition. If it does not return to its normal operating condition, have a NISSAN dealer check the transmission and repair if necessary.



When the high fluid temperature protection mode or fail-safe operation occurs, vehicle speed may be gradually reduced. The reduced speed may be lower than other traffic, which could increase the chance of a collision. Be especially careful when driving. If necessary, pull to the side of the road at a



safe place and allow the transmission to return to normal operation, or have it repaired if necessary.



#### Shift lock release

If the battery charge is low or discharged, the shift lever may not be moved from the P (Park) position even with the brake pedal depressed and the shift lever button pushed.

To move the shift lever, perform the following procedure:

### 1. Models with Intelligent Key system:

Place the ignition switch in the OFF or LOCK position.

### Models without Intelligent Key system:

Place the ignition switch in the LOCK position, and remove the key if it is inserted.



- 3. Remove the shift lock release cover (A) using a suitable tool.
- Push down the shift lock release using a suitable tool.
- Push the shift lever button and move the shift lever to the N (Neutral) position while holding down the shift lock release.

Place the ignition switch in the ON position. The vehicle may be moved to the desired location.

Replace the removed shift lock release cover after the operation.

For models with Intelligent Key system: If the battery is discharged completely, the steering wheel cannot be unlocked. Do not move the vehicle with the steering wheel locked.

If the shift lever cannot be moved out of the P (Park) position, have a NISSAN dealer check the CVT system as soon as possible.

# **A** WARNING

If the shift lever cannot be moved from the P (Park) position while the engine is running and the brake pedal is depressed, the stop lights may not work. Malfunctioning stop lights could cause an accident injuring yourself and

#### others.


### MANUAL TRANSMISSION (MT)

# **WARNING**

- Do not downshift abruptly on slipperv roads. This may cause a loss of control.
- Do not over-rev the engine when shifting to a lower gear. This may cause a loss of control or engine damage.
- When the high fluid temperature protection mode or fail-safe operation occurs, vehicle speed may be gradually reduced. The reduced speed may be lower than other traffic, which could increase the chance of a collision. Be especially careful when driving. If necessary, pull to the side of the road at a safe place and allow the transmission to return to normal operation, or have it repaired if necessary.

# **A** CAUTION

- Do not rest your foot on the clutch pedal while driving. This may damage the clutch.
- Fully depress the clutch pedal before shifting to help prevent transmission damage.
- Stop your vehicle completely before shifting into R (Reverse).
- When the vehicle is stopped for a period of time, for example at a stop light, shift to N (Neutral) and release the clutch pedal with the foot brake applied.



# Shiftina

To change gears, or when upshifting or downshifting, fully depress the clutch pedal, shift into the appropriate gear, then slowly and smoothly release the clutch pedal.

To ensure smooth gear changes, be sure to fully depress the clutch pedal before operating the shift lever. If the clutch pedal is not fully depressed before the transmission is shifted, a gear noise may be heard. Transmission damage could occur.

Start the vehicle in 1st gear and shift to 2nd, 3rd, 4th, 5th and 6th gear in sequence according to vehicle speed.



To back up, pull the shift lever ring ① upward and then move it to the R (Reverse) gear after stopping the vehicle completely.

The shift lever ring returns to its original position when the shift lever is moved to the N (Neutral) position.

If it is difficult to move the shift lever into the R (Reverse) or 1st gear, shift to the N (Neutral) position, and then release the clutch pedal once. Fully depress the clutch pedal again and shift into the R (Reverse) or 1st gear.

# Suggested upshift speeds

The following are suggested vehicle speeds for shifting into a higher gear. These suggestions relate to fuel economy and vehicle performance. Actual upshift speeds will vary according to road conditions, the weather and individual driving habits.

| Gear change | MPH (km/h) |
|-------------|------------|
| 1st to 2nd  | 15 (24)    |
| 2nd to 3rd  | 25 (40)    |
| 3rd to 4th  | 40 (64)    |
| 4th to 5th  | 45 (72)    |
| 5th to 6th  | 50 (80)    |

Suggested maximum speed in each gear Downshift to a lower gear if the engine is not running smoothly, or if you need to accelerate.

Do not exceed the maximum suggested speed (shown below) in any gear. For level road driving, use the highest gear suggested for that speed. Always observe posted speed limits, and drive according to the road conditions, which will ensure safe operation. Do not over-rev the engine when shifting to a lower gear as it may cause engine damage or loss of vehicle control.

### **Except for NISMO RS models:**

| Gear | MPH (km/h) |
|------|------------|
| 1st  | 33 (53)    |
| 2nd  | 57 (92)    |
| 3rd  | 79 (127)   |
| 4th  | _          |
| 5th  | _          |
| 6th  | _          |

#### For NISMO RS models:

| Gear | MPH (km/h) |
|------|------------|
| 1st  | 27 (44)    |
| 2nd  | 50 (80)    |
| 3rd  | 73 (118)   |
| 4th  | _          |
| 5th  | _          |
| 6th  | _          |



## INTEGRATED CONTROL SYSTEM (if so equipped)

The Integrated Control System is located below the audio system or navigation system (if so equipped). Two Integrated Control System modes can be selected: Drive mode and Climate Control mode.


Depending on which Integrated Control System mode selected (Drive mode or Climate Control mode), the screen display and some button functions will change.

### Drive mode

In the Drive mode, three types of driving modes can be selected: NORMAL, SPORT and ECO. See "Drive mode" (P.5-25). In addition, while in the Drive mode, SETUP. Drive information and ECO information can be displayed and adjusted. See "Integrated control system" (P.2-21).

#### Climate Control mode

In the Climate Control mode, the climate control can be set and adjusted. See "Automatic air conditioner (with Integrated Control System)" (P.4-24).




### DRIVE MODE

- NORMAL drive mode button
- 2. Climate control mode select button
- Drive mode select button
- SETUP button
- SPORT drive mode button
- ECO drive mode button

- Display screen
- Enter button/Selection dial






Example

Three drive modes (NORMAL, SPORT and ECO) can be selected depending on the driving condition. When each mode is selected, the control state of the engine, CVT (if so equipped), steering and climate appears on the display briefly.

Each selected Drive mode (NORMAL, SPORT or ECO) is displayed at the top of the display screen.

#### NOTE:

 The display values of torque, boost and current fuel economy may differ depending on driving conditions. Use the display values as reference only.  The vehicle will be set to the NORMAL drive mode when restarting the engine.



#### NORMAL drive mode

The NORMAL drive mode is recommended for normal driving. To set the NORMAL drive mode, press the Drive mode select button and then press the NORMAL drive mode button. The control state of the engine, CVT (if so equipped) steering and climate is displayed briefly.


When the NORMAL drive mode is selected, a voltage meter and an engine torque meter appear on the display screen.

#### NOTE:

 The voltage meter may change according to the driving condition. This is not a malfunction.



. At start up, the vehicle is automatically set to the NORMAL drive mode.



# SPORT drive mode


The SPORT drive mode is recommended for an enhanced performance feel. To set the SPORT drive mode, press the drive mode select button. The control state of the engine, CVT (if so equipped), steering and climate control is displayed briefly. In the SPORT mode, the engine, CVT (if so equipped) and steering are set to SPORT. Climate control is set to NORMAL.

When the SPORT drive mode is selected, a boost meter appears on the display screen.

#### NOTE:

In the SPORT mode, fuel economy may be reduced.





### ECO drive mode

The ECO drive mode is recommended for maximum fuel economy. In the ECO drive mode, the engine and CVT (if so equipped) are adjusted to enhance fuel economy.

To set the ECO drive mode, press the drive mode select button and then press the ECO drive mode button. The control state of the engine, CVT (if so equipped), steering and climate control is displayed briefly.

When the ECO drive mode is selected, the current fuel economy appears on the display screen.


When the climate ECO mode is also switched

on, the climate control system is adjusted to further enhance fuel economy.

The climate ECO mode can be switched on or off in the SETUP mode. See "Setting the climate ECO mode" (P.5-28).

#### NOTE:

- Many driving factors influence fuel economy. Selecting the ECO drive mode may not improve fuel economy.
- In the ECO drive mode, performance may be reduced.



### Setting the climate ECO mode:

When the climate ECO mode is switched on, the climate control system operates to enhance fuel economy.

To turn the climate ECO mode on or off

- Press the drive mode select button to select the drive mode.
- 2. Press the SETUP button.
- Turn the selection dial until "CLIMATE ECO" is selected.
- Press the ENTER button to switch climate ECO on or off. When the CLIMATE ECO mode is turned on, the CLIMATE ECO indicator (A) turns red on the display




### **PARKING BRAKE**

screen.



- Be sure the parking brake is fully released before driving. Failure to do so can cause brake failure and lead to an accident.
- Do not release the parking brake from outside the vehicle.
- Do not use the shift lever in place of the parking brake. When parking, be sure the parking brake is fully engaged.
- Do not leave children unattended in a vehicle. They could release the parking brake and cause an accident.



To apply: Pull the parking brake lever up (1). To release:

- 1. Firmly apply the foot brake.
- 2. While pulling up on the parking brake lever slightly, push the button (2) and lower the lever completely (3).
- 3. Before driving, be sure the brake warning light goes out.



#### **CRUISE CONTROL**

# PRECAUTIONS ON CRUISE CONTROL

- If the cruise control system malfunctions, it will cancel automatically. The CRUISE indicator light on the meter panel will then blink to warn the driver.
- If the engine coolant temperature becomes excessively high, the cruise control system will cancel automatically.
- If the CRUISE indicator light blinks, turn the cruise control MAIN switch off and have the system checked by a NISSAN dealer.
- The CRUISE indicator light may blink when the cruise control MAIN switch is turned ON while pushing the ACCEL/RES, COAST/ SET or CANCEL switch. To properly set the cruise control system, perform the following procedures.

# **WARNING**

Do not use the cruise control when driving under the following conditions:


- when it is not possible to keep the vehicle at a set speed
- in heavy traffic or in traffic that varies in speed

- on winding or hilly roads
- on slippery roads (rain, snow, ice, etc.)
- in very windy areas

Doing so could cause a loss of vehicle control and result in an accident.

# **A** CAUTION

On Manual Transmission (MT) models, do not shift into N (Neutral) without depressing the clutch pedal when the cruise control is set. Should this occur, depress the clutch pedal and turn the MAIN switch off immediately. Failure to do so may cause engine damage.



- ACCEL/RES switch
- COAST/SET switch
- 3. CANCEL switch
- 4. MAIN (ON-OFF) switch

### CRUISE CONTROL OPERATIONS

The cruise control allows driving at a speed between 25 to 89 MPH (40 to 144 km/h) without keeping your foot on the accelerator pedal.

**To turn on the cruise control,** push the MAIN switch on. The CRUISE indicator light will illuminate.

**To set cruising speed,** accelerate the vehicle to the desired speed, push the COAST/SET switch and release it. Take your foot off the



accelerator pedal. Your vehicle will maintain the set speed.

- To pass another vehicle, depress the accelerator pedal. When you release the pedal, the vehicle will return to the previously set speed.
- The vehicle may not maintain the set speed on winding or hilly roads. If this happens, drive without the cruise control.

To cancel the preset speed, use one of the following methods:

- Push the CANCEL switch.
- Tap the brake pedal.
- Turn the MAIN switch off. The CRUISE indicator light will turn off.
- If you depress the brake pedal while pushing the ACCFL/RES or COAST/SET switch and reset at the cruising speed, the cruise control will disengage. Turn the MAIN switch off once and then turn it on again.
- The cruise control will automatically cancel if the vehicle slows more than 8 MPH (13 km/h) below the set speed.
- If you move the shift lever to the N (Neutral) position (Continuously Variable Transmission models) or depressing the clutch pedal (Manual Transmission models), the cruise control will be canceled.

To reset at a faster cruising speed, use one

of the following methods:

- Depress the accelerator pedal. When the vehicle attains the desired speed, push and release the COAST/SET switch.
- Push and hold the ACCEL/RES switch. When the vehicle attains the desired speed, release the switch.
- Push, then quickly release the ACCEL/RES switch. Each time you do this, the set speed will increase by about 1 MPH (1.6 km/h).

To reset at a slower cruising speed, use one of the following methods:

- Lightly tap the brake pedal. When the vehicle attains the desired speed, push the COAST/SET switch and release it.
- Push and hold the COAST/SFT switch. Release the switch when the vehicle slows down to the desired speed.
- Push, then guickly release the COAST/SET switch. Each time you do this, the set speed will decrease by about 1 MPH (1.6 km/h).

To resume the preset speed, push and release the ACCEL/RES switch. The vehicle will resume the last set cruising speed when the vehicle speed is over 25 MPH (40 km/h).

### **BREAK-IN SCHEDULE**



# A CAUTION

During the first 1,200 miles (2,000 km), follow these recommendations to obtain maximum engine performance and ensure the future reliability and economy of your new vehicle. Failure to follow these recommendations may result in shortened engine life and reduced engine performance.

- · Avoid driving for long periods at constant speed, either fast or slow. Do not run the engine over 4,000 rpm.
- Do not accelerate at full throttle in any gear.
  - Avoid guick starts.
- Avoid hard braking as much as possible.



#### **FUEL EFFICIENT DRIVING TIPS**

Follow these easy-to-use Fuel Efficient Driving Tips to help you achieve the most fuel economy from your vehicle.

- Use smooth accelerator and brake pedal application.
  - · Avoid rapid starts and stops.
  - Use smooth, gentle accelerator and brake application whenever possible.
  - Maintain constant speed while commuting and coast whenever possible.
- 2. Maintain constant speed.
  - Look ahead to try and anticipate and minimize stops.
  - Synchronizing your speed with traffic lights allows you to reduce your number of stops.
  - Maintaining a steady speed can minimize red light stops and improve fuel efficiency.
- Use air conditioning (A/C) at higher vehicle speeds.
  - Below 40 MPH (64 km/h), it is more efficient to open windows to cool the vehicle due to reduced engine load.
  - Above 40 MPH (64 km/h), it is more efficient to use A/C to cool the vehicle due to increased aerodynamic drag.

- Recirculating the cool air in the cabin when the A/C is on reduces cooling load.
- 4. Drive at economical speeds and distances.
  - Observing the speed limit and not exceeding 60 MPH (97 km/h) (where legally allowed) can improve fuel efficiency due to reduced aerodynamic drag.
  - Maintaining a safe following distance behind other vehicles reduces unnecessary braking.
  - Safely monitoring traffic to anticipate changes in speed permits reduced braking and smooth acceleration changes.
  - Select a gear range suitable to road conditions.
- 5. Use cruise control.
  - Using cruise control during highway driving helps maintain a steady speed.
  - Cruise control is particularly effective in providing fuel savings when driving on flat terrains.
- 6. Plan for the shortest route.
  - Utilize a map or navigation system to determine the best route to save time.
- 7. Avoid idling.
  - Shutting off your engine when safe for stops exceeding 30-60 seconds saves

fuel and reduces emissions.

- 3. Buy an automated pass for toll roads.
  - Automated passes permit drivers to use special lanes to maintain cruising speed through the toll and avoid stopping and starting.
- Winter warm up.
  - Limit idling time to minimize impact to fuel economy.
  - Vehicles typically need no more than 30 seconds of idling at start-up to effectively circulate the engine oil before driving.
  - Your vehicle will reach its ideal operating temperature more quickly while driving versus idling.
- 10. Keeping your vehicle cool.
  - Park your vehicle in a covered parking area or in the shade whenever possible.
  - When entering a hot vehicle, opening the windows will help to reduce the inside temperature faster, resulting in reduced demand on your A/C system.

### **INCREASING FUEL ECONOMY**

- Keep your engine tuned up.
- Follow the recommended scheduled maintenance.
- Keep the tires inflated to the correct pressure. Low tire pressure increases tire wear and lowers fuel economy.
- Keep the wheels in correct alignment.
   Improper alignment increases tire wear and lowers fuel economy.
- Use the recommended viscosity engine oil. (See "Engine oil and oil filter recommendation" (P.9-6).)


# ALL-WHEEL DRIVE (AWD) (if so equipped)



# WARNING

- For AWD equipped vehicles, do not attempt to raise two wheels off the ground and shift the transmission to any drive or reverse position with the engine running. Doing so may result in drivetrain damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.
- Do not attempt to test an AWD equipped vehicle on a 2-wheel dynamometer (such as the dynamometers used by some states for emissions testing) or similar equipment even if the other two wheels are raised off the ground. Make sure that you inform the test facility personnel that your vehicle is equipped with AWD before it is placed on a dynamometer. Using the wrong test equipment may result in drivetrain damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.





AWD mode switch

# ALL-WHEEL DRIVE (AWD) MODE SWITCH OPERATIONS

The All-Wheel Drive (AWD) system is used to select the 2WD (Two-Wheel Drive), AWD-V or AWD mode depending on the driving conditions.

The AWD mode indicator lights (AWD (green), 😭 ) are located in the instrument panel.

The AWD mode indicator lights AWD (green) illuminate when the ignition switch is turned to the ON position. The indicator lights turn off within 1 second.

The AWD mode indicator lights will display the mode selected by the AWD mode switch while

engine is running.

If the AWD warning light AWD (yellow) illuminates, the AWD mode indicator lights will turn off.

Push the AWD mode switch, located on the instrument panel, to select 2WD, AWD-V or AWD.

AWD-V: Push the AWD mode switch to the neutral (AWD-V) position. The All-Wheel Drive (AWD) AWD-V indicator light 😭 in the meter illuminates.

2WD: Push the AWD mode switch to the 2WD position.


AWD: Push the AWD mode switch to the AWD position. The AWD indicator light AWD (green) in the meter illuminates.

| AWD mode | Wheels driven  | AWD mode indicator light ( AWD (green)) | Use conditions                         |
|----------|--|---|--|
| 2WD      | Front wheels: The wheel drive mode is in Two-Wheel Drive (2WD) when driving on a normal road.  |   | For driving on dry, paved roads        |
| AWD-V    | Distribution of torque to the front and rear wheels changes automatically [ratio; 100 : 0 (2WD) → 50 : 50 (AWD)] and distribution of torque between left and right wheel of rear wheels changes automatically depending on road conditions encountered [ratio; 100 : 0 (2WD) → 50 : 50 (AWD)]. | Illuminates                             | For driving on paved or slippery roads |
| AWD      | Distribution of torque to the front and rear wheels changes automatically [ratio; 100 : 0 (2WD) → 50 : 50 (AWD)] and the distribution of torque between the left and right rear wheels changes automatically depending on the slippery road conditions encountered.                            | Illuminates (green) AWD                 | For driving on slippery roads          |



### AWD shift tips

- If the AWD mode switch is operated while making a turn, accelerating or decelerating, or if the ignition switch is turned off while in the AWD-V or AWD mode, you may feel a iolt. This is normal.
- The oil temperature of power train parts will increase if the vehicle is continuously operated under conditions where the difference in rotation between the front and rear wheels is large (wheel slip), such as when driving the vehicle on rough roads through sand or mud or when freeing a stuck vehicle. In these cases, the AWD warning light blinks rapidly and the AWD mode changes to the 2WD mode to protect the power train parts. If you stop driving with the engine idling and wait until the warning light stops blinking, the AWD returns to the AWD-V or AWD mode.
- Brake distance in the AWD mode is the same as 2WD.



Do not start the engine with the AWD mode switch in any mode in the following cases:

- when the vehicle is placed on a free-roller or jacking up the vehicle with the front tires raised and the rear tires on the ground.
- when towing the vehicle with the rear tires raised from the around.
- Operate the AWD mode switch only when driving straight. Do not operate the AWD mode switch when making a turn or backing up.
- Do not operate the AWD mode switch with the front wheel spinning.
- Engine idling speed is high while warming up the engine. Be especially careful when starting or driving on slippery surfaces with the AWD mode switch set in the AWD-V or AWD mode.

| Warning light<br>(yellow) | Comes on or blinks when                                     |
|---------------------------|---|
| - AWD - Comes or          | There is a malfunction in the All-Whool Drive (AWD) system. |
| (AWD)                     | The power-train oil temperature riscs abnormally.           |
| - (AWD)                   | The difference in wheel rotation is large.                  |
|                           | SSD0336-D   |

#### AWD WARNING LIGHT

The AWD warning light located in the instrument panel illuminates when the ignition switch is turned to the ON position. It turns off soon after the engine is started.

If any malfunction occurs in the AWD system while the engine is running, or while driving, the



warning light will either remain illuminated or blink.

High-temperature power train oil due to continuous operation of the vehicle to free a stuck vehicle makes the warning light blink rapidly (about twice per second). The driving mode may change to the 2WD mode. If the warning light blinks rapidly during operation, stop the vehicle with the engine idling in a safe place immediately. Then if the light goes off after a while, you can continue driving.


A large difference between the diameters of front and rear wheels will make the warning light blink slowly (about once per 2 seconds). Pull off the road in a safe area, and idle the engine. Check that all tire sizes are the same, tire pressure is correct and tires are not worn. Change the AWD mode switch to the 2WD mode and do not drive fast.

## **A** CAUTION

 If the warning light illuminates while driving, AWD mode will be changed to 2WD mode. Reduce the vehicle speed and have your vehicle checked by a NISSAN dealer as soon as possible. Be especially careful when driving.  The power train may be damaged if you continue driving with the AWD warning light blinking rapidly.



### PARKING/PARKING ON HILLS



### **A** WARNING

- Do not stop or park the vehicle over flammable materials such as dry grass, waste paper or rags. They may ignite and cause a fire.
- Never leave the engine running while the vehicle is unattended.
- Do not leave children unattended inside the vehicle. They could unknowingly activate switches or controls. Unattended children could become involved in serious acci-

#### dents.

- Safe parking procedures require that both the parking brake be applied and the transmission placed into P (Park) for Continuously Variable Transmission (CVT) model or in an appropriate gear for Manual Transmission (MT) model. Failure to do so could cause the vehicle to move unexpectedly or roll away and result in an accident.
- Make sure the continuously variable transmission shift lever has been pushed as far forward as it can go

## and cannot be moved without depressing the foot brake pedal.

- 1. Firmly apply the parking brake.
- 2. Continuously Variable Transmission (CVT) models:

Move the shift lever to the P (Park) position.

### Manual Transmission (MT) models:

Move the shift lever to the R (Reverse) gear. When parking on an uphill grade, place the shift lever in the 1st gear.

- To help prevent the vehicle from rolling into the street when parked on a sloping drive way, it is a good practice to turn the wheels as illustrated.
  - HEADED DOWNHILL WITH CURB: 1

     Turn the wheels into the curb and move the vehicle forward until the curb side wheel gently touches the curb.
  - HEADED UPHILL WITH CURB: ②
     Turn the wheels away from the curb and move the vehicle back until the curb side wheel gently touches the curb.
  - HEADED UPHILL OR DOWNHILL, NO CURB: (3)

Turn the wheels toward the side of the road so the vehicle will move away from the center of the road if it moves.



## ELECTRIC POWER STEERING SYSTEM

### 4. Models with Intelligent Key system:

Place the ignition switch in the OFF position.

Models without Intelligent Key system:

Place the ignition switch in the LOCK position and remove the key.



- If the engine is not running or is turned off while driving, the power assist for the steering will not work.
   Steering will be harder to operate.
- When the electric power steering warning light illuminates with the engine running, the power assist for the steering will cease operation. You will still have control of the vehicle but the steering will be harder to operate.

The electric power steering system is designed to provide power assist while driving to operate the steering wheel with light force.

When the steering wheel is operated repeatedly or continuously while parking or driving at a very low speed, the power assist for the steering wheel will be reduced. This is to prevent overheating of the electric power steering system and protect it from getting damaged. While the power assist is reduced, steering wheel operation will become heavy. When the temperature of the electric power steering system goes down, the power assist level will return to normal. Avoid repeating such steering

wheel operations that could cause the electric power steering system to overheat.

You may hear a sound when the steering wheel is operated quickly. However, this is not a malfunction.

If the electric power steering warning light **PS** illuminates while the engine is running, it may indicate the electric power steering system is not functioning properly and may need servicing. Have the electric power steering system checked by a NISSAN dealer. (See "Electric power steering warning light" (P.2-14).)

When the electric power steering warning light illuminates with the engine running, the power assist for the steering will cease operation. You will still have control of the vehicle. However, greater steering effort is needed, especially in sharp turns and at low speeds.



### **BRAKE SYSTEM**

#### **BRAKING PRECAUTIONS**

The brake system has two separate hydraulic circuits. If one circuit malfunctions, you will still have braking at two wheels.

You may feel a small click and hear a sound when the brake pedal is fully depressed slowly. This is not a malfunction and indicates that the brake assist mechanism is operating properly.

### Vacuum assisted brakes

The brake booster aids braking by using engine vacuum. If the engine stops, you can stop the vehicle by depressing the brake pedal. However, greater foot pressure on the brake pedal will be required to stop the vehicle and the stopping distance will be longer.

When the brake pedal is depressed slowly and firmly, you may hear a clicking noise and feel a slight pulsation. This is normal and indicates that the Brake Assist System is operating.

### Using the brakes

Avoid resting your foot on the brake pedal while driving. This will cause overheating of the brakes, wearing out the brake pads and shoes faster and reduce gas mileage.

To help reduce brake wear and to prevent the brakes from overheating, reduce speed and downshift to a lower gear before going down a slope or long grade. Overheated brakes may reduce braking performance and could result in loss of vehicle control.



### WARNING

- . While driving on a slippery surface, be careful when braking, accelerating or downshifting. Abrupt braking or accelerating could cause the wheels to skid and result in an accident.
- If the engine is not running or is turned off while driving, the power assist for the brakes will not work. Braking will be harder.

### Wet brakes

When the vehicle is washed or driven through water, the brakes may get wet. As a result, your braking distance will be longer and the vehicle may pull to one side during braking.

To dry brakes, drive the vehicle at a safe speed while lightly tapping the brake pedal to heat-up the brakes. Do this until the brakes return to normal. Avoid driving the vehicle at high speeds until the brakes function correctly.



### Parking brake break-in

Break in the parking brake shoes whenever the stopping effect of the parking brake is weakened or whenever the parking brake shoes and/or drums/rotors are replaced, in order to assure the best braking performance.

This procedure is described in the vehicle service manual and can be performed by a NISSAN dealer.

### **BRAKE ASSIST**

#### BRAKE ASSIST

When the force applied to the brake pedal exceeds a certain level, the Brake Assist is activated generating greater braking force than a conventional brake booster even with light pedal force.



### WARNING

The Brake Assist is only an aid to assist braking operation and is not a collision warning or avoidance device. It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times.

ANTI-LOCK BRAKING SYSTEM (ABS)



### **WARNING**

The Anti-lock Braking System (ABS) is a sophisticated device, but it cannot prevent accidents resulting from careless or dangerous driving techniques. It can help maintain vehicle control during braking on slippery surfaces. Remember that stopping distances on slippery surfaces will be longer than on normal

surfaces even with ABS. Stopping distances may also be longer on rough, gravel or snow covered roads, or if you are using tire chains. Always maintain a safe distance from the vehicle in front of you. Ultimately, the driver is responsible for safety.

- Tire type and condition may also affect braking effectiveness.
  - When replacing tires, install the specified size of tires on all four wheels.
  - When installing a spare tire, make sure that it is the proper size and type as specified on the Tire and Loading Information label. See "Tire and Loading Information label" (P.9-11) of this manual.
  - For detailed information, see "Wheels and tires" (P.8-30) of this manual.

The Anti-lock Braking System (ABS) controls the brakes so the wheels do not lock during hard braking or when braking on slippery surfaces. The system detects the rotation speed at each wheel and varies the brake fluid pressure to prevent each wheel from locking and sliding. By preventing each wheel from locking, the system helps the driver maintain steering control and helps to minimize swerving and spinning on slippery surfaces.

### Using the system

Depress the brake pedal and hold it down. Depress the brake pedal with firm steady pressure, but do not pump the brakes. The ABS will operate to prevent the wheels from locking up. Steer the vehicle to avoid obstacles.



### WARNING

Do not pump the brake pedal. Doing so may result in increased stopping distances.

### Self-test feature

The ABS includes electronic sensors, electric pumps, hydraulic solenoids and a computer. The computer has a built-in diagnostic feature that tests the system each time you start the engine and move the vehicle at a low speed in forward or reverse. When the self-test occurs, you may hear a "clunk" noise and/or feel a pulsation in the brake pedal. This is normal and does not

5-40 Starting and driving

# VEHICLE DYNAMIC CONTROL (VDC) SYSTEM

indicate a malfunction. If the computer senses a malfunction, it switches the ABS off and illuminates the ABS warning light on the instrument panel. The brake system then operates normally, but without anti-lock assistance.

If the ABS warning light illuminates during the self-test or while driving, have the vehicle checked by a NISSAN dealer.

### Normal operation

The ABS operates at speeds above 3 to 6 MPH (5 to 10 km/h). The speed varies according to road conditions.

When the ABS senses that one or more wheels are close to locking up, the actuator rapidly applies and releases hydraulic pressure. This action is similar to pumping the brakes very quickly. You may feel a pulsation in the brake pedal and hear a noise from under the hood or feel a vibration from the actuator when it is operating. This is normal and indicates that the ABS is operating properly. However, the pulsation may indicate that road conditions are hazardous and extra care is required while driving.

The Vehicle Dynamic Control (VDC) system uses various sensors to monitor driver inputs and vehicle motion. Under certain driving conditions, the VDC system helps to perform the following functions.

- Controls brake pressure to reduce wheel slip on one slipping drive wheel so power is transferred to a non slipping drive wheel on the same axle.
- Controls brake pressure and engine output to reduce drive wheel slip based on vehicle speed (traction control function).
- Controls brake pressure at individual wheels and engine output to help the driver maintain control of the vehicle in the following conditions:
  - understeer (vehicle tends to not follow the steered path despite increased steering input)
  - oversteer (vehicle tends to spin due to certain road or driving conditions).

The VDC system can help the driver to maintain control of the vehicle, but it cannot prevent loss of vehicle control in all driving situations.

When the VDC system operates, the VDC warning light  $\gtrsim$  in the instrument panel flashes so note the following:

 The road may be slippery or the system may determine some action is required to help

- keep the vehicle on the steered path.
- You may feel a pulsation in the brake pedal and hear a noise or vibration from under the hood. This is normal and indicates that the VDC system is working properly.
- Adjust your speed and driving to the road conditions.

If a malfunction occurs in the system, the VDC warning light  $\mbox{\ensuremath{\beta}}$  illuminates in the instrument panel. The VDC system automatically turns off.

The VDC OFF switch is used to turn off the VDC system. The VDC off indicator  $\begin{tabular}{l}{c}$  illuminates to indicate the VDC system is off. When the VDC switch is used to turn off the system, the VDC system still operates to prevent one drive wheel from slipping by transferring power to a non slipping drive wheel. The VDC warning light  $\begin{tabular}{l}{c}$  flashes if this occurs. All other VDC functions are off, and the VDC warning light  $\begin{tabular}{l}{c}$  will not flash. The VDC system is automatically reset to on when the ignition switch is placed in the off position then back to the on position.

See "Vehicle Dynamic Control (VDC) warning light" (P.2-17) and "Vehicle Dynamic Control (VDC) off indicator light" (P.2-19).

The computer has a built-in diagnostic feature that tests the system each time you start the engine and move the vehicle forward or in reverse at a slow speed. When the self-test occurs, you may hear a "clunk" noise and/or feel a pulsation in the brake pedal. This is normal and is not an indication of a malfunction.

## A

### WARNING

- The VDC system is designed to help improve driving stability but does not prevent accidents due to abrupt steering operation at high speeds or by careless or dangerous driving techniques. Reduce vehicle speed and be especially careful when driving and cornering on slippery surfaces and always drive carefully.
- Do not modify the vehicle's suspension. If suspension parts such as shock absorbers, struts, springs, stabilizer bars, bushings and wheels are not NISSAN recommended for your vehicle or are extremely deteriorated, the VDC system may not operate properly. This could adversely affect vehicle handling performance, and the VDC warning light \$\mathcal{D}\$ may illuminate.

- If brake related parts such as brake pads, rotors and calipers are not NISSAN recommended or are extremely deteriorated, the VDC system may not operate properly and the VDC warning light may illuminate.
- If engine control related parts are not NISSAN recommended or are extremely deteriorated, the VDC warning light \$\mathcal{S}\$ may illuminate.
- When driving on extremely inclined surfaces such as higher banked corners, the VDC system may not operate properly and the VDC warning light \$\mathcal{D}\$ may illuminate. Do not drive on these types of roads.
- When driving on an unstable surface such as a turntable, ferry, elevator or ramp, the VDC warning light \$\mathcal{B}\$ may illuminate. This is not a malfunction. Restart the engine after driving onto a stable surface.
- If wheels or tires other than the NISSAN recommended ones are used, the VDC system may not operate properly and the VDC warning light \$\mathcal{D}\$ may illuminate.

 The VDC system is not a substitute for winter tires or tire chains on a snow covered road.



### **COLD WEATHER DRIVING**

#### FREEING A FROZEN DOOR LOCK

To prevent a door lock from freezing, apply deicer through the key hole. If the lock becomes frozen, heat the key before inserting it into the key hole or use the remote keyless entry keyfob.

#### **ANTI-FREEZE**

In the winter when it is anticipated that the outside temperature will drop below 32°F (0°C), check the anti-freeze to assure proper winter protection. For additional information, see "Engine cooling system" (P.8-7).

### **BATTERY**

If the battery is not fully charged during extremely cold weather conditions, the battery fluid may freeze and damage the battery. To maintain maximum efficiency, the battery should be checked regularly. For additional information, see "Battery" (P.8-13).

### DRAINING OF COOLANT WATER

If the vehicle is to be left outside without antifreeze, drain the cooling system, including the engine block. Refill before operating the vehicle. For details, see "Engine cooling system" (P.8-7).

#### TIRE EQUIPMENT

SUMMER tires have a tread designed to provide superior performance on dry pavement. However, the performance of these tires will be substantially reduced in snowy and icy conditions. If you operate your vehicle on snowy or icy roads, NISSAN recommends the use of MUD & SNOW or ALL SEASON tires on all four wheels. Consult a NISSAN dealer for the tire type, size, speed rating and availability information.

For additional traction on icy roads, studded tires may be used. However, some U.S. states and Canadian provinces prohibit their use. Check local, state and provincial laws before installing studded tires.

Skid and traction capabilities of studded snow tires, on wet or dry surfaces, may be poorer than that of non-studded snow tires.

Tire chains may be used. For details, see "Tire chains" (P.8-38) of this manual.

### All-Wheel Drive (AWD) model

If you install snow tires, they must also be the same size, brand, construction and tread pattern on all four wheels.

#### SPECIAL WINTER EQUIPMENT

It is recommended that the following items be carried in the vehicle during winter:

- A scraper and stiff-bristled brush to remove ice and snow from the windows and wiper blades.
- A sturdy, flat board to be placed under the jack to give it firm support.
- A shovel to dig the vehicle out of snowdrifts.
- Extra window washer fluid to refill the reservoir tank.

### DRIVING ON SNOW OR ICE

## **A** WARNING

- Wet ice (32°F, 0°C and freezing rain), very cold snow or ice can be slick and very hard to drive on. The vehicle will have much less traction or "grip" under these conditions. Try to avoid driving on wet ice until the road is salted or sanded.
- Whatever the condition, drive with caution. Accelerate and slow down with care. If accelerating or downshifting too fast, the drive wheels will lose even more traction.



- Allow more stopping distance under these conditions. Braking should be started sooner than on dry pavement.
- Allow greater following distances on slippery roads.
- Watch for slippery spots (glare ice).
   These may appear on an otherwise clear road in shaded areas. If a patch of ice is seen ahead, brake before reaching it. Try not to brake while on the ice, and avoid any sudden steering maneuvers.
- Do not use cruise control on slippery roads.
- Snow can trap dangerous exhaust gases under your vehicle. Keep snow clear of the exhaust pipe and from around your vehicle.

## ENGINE BLOCK HEATER (if so equipped)

Engine block heaters are used to assist in cold temperature starting.

The engine block heater should be used when the outside temperature is 20°F (-7°C) or lower.

To use the engine block heater

- 1. Turn the engine off.
- Open the hood and unwrap the engine block heater cord.
- 3. Plug the engine block heater cord into a grounded 3-wire, 3-pronged extension cord.
- Plug the extension cord into a Ground Fault Interrupt (GFI) protected, grounded 110volt AC (VAC) outlet.
- The engine block heater must be plugged in for at least 2 - 4 hours, depending on outside temperatures, to properly warm the engine coolant. Use an appropriate timer to turn the engine block heater on.
- Before starting the engine, unplug and properly store the cord to keep it away from moving parts.



- Do not use your engine block heater with an ungrounded electrical system or a 2-pronged adapter. You can be seriously injured by an electrical shock if you use an ungrounded connection.
- Disconnect and properly store the engine block heater cord before starting the engine. Damage to the cord could result in an electrical shock and can cause serious injury.
- Use a heavy-duty 3-wire, 3-pronged extension cord rated for at least 10A. Plug the extension cord into a Ground Fault Interrupt (GFI) protected, grounded 110-VAC outlet. Failure to use the proper extension cord or a grounded outlet can result in a fire or electrical shock and cause serious personal injury.




# **6 In case of emergency**

| Hazard warning flasher switch                      | 6-2 |
|--|-----|
| Emergency engine shut off (models with Intelligent |     |
| Key system)  | 6-2 |
| Flat tire  | 6-3 |
| Tire Pressure Monitoring System (TPMS)             | 6-3 |
| Changing a flat tire                               | 6-3 |

| Jump starting                              | 6-  |
|--|-----|
| Push starting                              | 6-1 |
| If your vehicle overheats                  | 6-1 |
| Towing your vehicle                        | 6-1 |
| Towing recommended by NISSAN               | 6-1 |
| Vehicle recovery (freeing a stuck vehicle) | 6-1 |
|  |     |



## HAZARD WARNING FLASHER SWITCH



Push the switch on to warn other drivers when you must stop or park under emergency conditions. All turn signal lights will flash.

### **A** WARNING

- If stopping for an emergency, be sure to move the vehicle well off the road.
- Do not use the hazard warning flashers while moving on the highway unless unusual circumstances force you to drive so slowly that your vehicle might become a hazard

#### to other traffic.

 Turn signals do not work when the hazard warning flasher lights are on.

The flasher can be actuated with the ignition switch in any position.

Some state laws may prohibit the use of the hazard warning flasher switch while driving.

## **EMERGENCY ENGINE SHUT OFF** (models with Intelligent Key system)

To shut off the engine in an emergency situation while driving, perform the following procedure:

- Rapidly push the push-button ignition switch 3 consecutive times in less than 1.5 seconds, or
- Push and hold the push-button ignition switch for more than 2 seconds.



### **FLAT TIRE**

### TIRE PRESSURE MONITORING SYS-TEM (TPMS)

This vehicle is equipped with the Tire Pressure Monitoring System (TPMS). It monitors tire pressure of all tires except the spare. When the low tire pressure warning light is lit, and the CHECK TIRE PRES (pressure) warning message is displayed in the vehicle information display, one or more of your tires is significantly under-inflated. If the vehicle is being driven with low tire pressure, the TPMS will activate and warn you of it by the low tire pressure warning light. This system will activate only when the vehicle is driven at speeds above 16 MPH (25 km/h). For more details, see "Warning/indicator lights and audible reminders" (P.2-12) and "Tire Pressure Monitoring System (TPMS)" (P.5-4).



### **WARNING**

If the low tire pressure warning light illuminates while driving, avoid sudden steering maneuvers or abrupt braking, reduce vehicle speed, pull off the road to a safe location and stop the vehicle as soon as possible. Driving with under-inflated tires may permanently damage the tires and increase the likelihood of tire failure. Serious vehicle damage could occur and may lead to an accident and could result in serious personal injury. Check the tire pressure for all four tires. Adjust the tire pressure to the recommended COLD tire pressure shown on the Tire and Loading Information label to turn the low tire pressure warning light OFF. If you have a flat tire, replace it with a spare tire as soon as possible.

- When a spare tire is mounted or a wheel is replaced, the TPMS will not function and the low tire pressure warning light will flash for approximately 1 minute. The light will remain on after 1 minute. Contact vour NISSAN dealer as soon as possible for tire replacement and/ or system resetting.
- Replacing tires with those not originally specified by NISSAN could affect the proper operation of the TPMS.
- Do not inject any tire liquid or aerosol tire sealant into the tires. as this may cause a malfunction of

### the tire pressure sensors.

### CHANGING A FLAT TIRE

If you have a flat tire, follow the instructions below.

### Stopping the vehicle

- 1. Safely move the vehicle off the road and away from traffic.
- 2. Turn on the hazard warning flashers.
- 3. Park on a level surface and apply the parking brake.
- 4. Continuously Variable Transmission (CVT) models:

Move the shift lever to the P (Park) position.

### Manual Transmission (MT) models:


Move the shift lever to the R (Reverse) position.

- 5. Turn off the engine.
- 6. Raise the hood to warn other traffic, and to signal professional road assistance personnel that you need assistance.
- 7. Have all passengers get out of the vehicle and stand in a safe place, away from traffic and clear of the vehicle



## **A** WARNING

- Make sure the parking brake is securely applied and the Manual Transmission is shifted into R (Reverse), or the Continuously Variable Transmission into P (Park).
- Never change tires when the vehicle is on a slope, ice or slippery areas. This is hazardous.
- Never change tires if oncoming traffic is close to your vehicle. Wait for professional road assistance.




### Blocking wheels

Place suitable blocks ① at both the front and back of the wheel diagonally opposite the flat tire to prevent the vehicle from moving when it is jacked up.



Be sure to block the wheel as the vehicle may move and result in personal injury.




Jacking tools

Getting the spare tire and tools

Open the lift gate. Raise the cargo floor board

① . Remove jacking tools.





The spare tire is located under the cargo floor board.

Loosen the clamp (2) and remove the spacer and take out the spare tire.


Jacking up the vehicle and removing the damaged tire

### WARNING

- Never get under the vehicle while it is supported only by the jack. If it is necessary to work under the vehicle, support it with safety stands.
- Use only the jack provided with your vehicle to lift the vehicle. Do not use the jack provided with your vehicle on other vehicles. The jack is designed for lifting only your vehicle during a tire change.
- Use the correct jack-up points. Never use any other part of the vehicle for jack support.
- Never jack up the vehicle more than necessary.
- Never use blocks on or under the iack.
- Do not start or run the engine while vehicle is on the jack, as it may cause the vehicle to move.
- Do not allow passengers to stay in the vehicle while it is on the jack.

Carefully read the caution label attached to the jack body and the following instructions.






Jack-up point


 Place the jack directly under the jack-up point as illustrated so the top of the jack contacts the vehicle at the jack-up point. Align the jack head between the two notches in the front or the rear as shown. Also fit the groove of the jack head between the notches as shown.

The jack should be used on level firm ground.



- Loosen each wheel nut one or two turns by turning it counterclockwise with the wheel nut wrench. Do not remove the wheel nuts until the tire is off the ground.
- To lift the vehicle, securely hold the jack lever and rod with both hands as shown above. Carefully raise the vehicle until the tire clears the ground. Remove the wheel nuts, and then remove the tire.





Installing the spare tire

The spare tire is designed for emergency use. (See specific instructions under the heading "Wheels and tires" (P.8-30).)

- 1. Clean any mud or dirt from the surface between the wheel and hub.
- 2. Carefully put the spare tire on and tighten the wheel nuts finger tight. Check that all the wheel nuts contact the wheel surface horizontally.
- 3. With the wheel nut wrench, tighten wheel nuts alternately and evenly in the sequence as illustrated (1), 2, 3, 4, 5), more than 2 times, until they are tight.

4. Lower the vehicle slowly until the tire touches the ground. Then, with the wheel nut wrench, tighten the wheel nuts securely in the sequence as illustrated. Lower the vehicle completely.



### WARNING

- Incorrect wheel nuts or improperly tightened wheel nuts can cause the wheel to become loose or come off. This could cause an accident.
- Do not use oil or grease on the wheel studs or nuts. This could cause the nuts to become loose.
- Retighten the wheel nuts when the vehicle has been driven for 600 miles (1,000 km) (also in cases of a flat tire, etc.).
  - · As soon as possible, tighten the wheel nuts to the specified torque with a torque wrench.

Wheel nut tightening torque: 80 ft-lb (108 N-m)

The wheel nuts must be kept tightened to specifications at all times. It is recommended that the wheel nuts be tightened to specifications at each lubrication interval.

 Adjust tire pressure to the COLD pressure.

### **COLD** pressure:

After the vehicle has been parked for 3 hours or more or driven less than 1 mile (1.6 km).

COLD tire pressures are shown on the Tire and Loading Information label affixed to the driver side center pillar.

Stowing the damaged tire and the tools

- 1. Securely store the jack, tools and the damaged tire in the storage area.
- 2. Replace the cargo floor box and board.
- Close the lift gate.



### **WARNING**

- Always make sure that the spare tire and jacking equipment are properly secured after use. Such items can become dangerous projectiles in an accident or sudden stop.
- The spare tire and small size spare tire are designed for emergency use. See specific instructions under the



### JUMP STARTING

heading "Wheels and tires" (P.8-30).

To start your engine with a booster battery, the instructions and precautions below must be followed.




### WARNING

- If done incorrectly, jump starting can lead to a battery explosion, resulting in severe injury or death. It could also damage your vehicle.
- Explosive hydrogen gas is always present in the vicinity of the battery.
   Keep all sparks and flames away from the battery.
- Do not allow battery fluid to come into contact with eyes, skin, clothing or painted surfaces. Battery fluid is a corrosive sulfuric acid solution which can cause severe burns. If the fluid should come into contact with anything, immediately flush the contacted area with water.
- Keep the battery out of the reach of children.
- The booster battery must be rated at 12 volts. Use of an improperly rated battery can damage your vehicle.

- Whenever working on or near a battery, always wear suitable eye protectors (for example, goggles or industrial safety spectacles) and remove rings, metal bands, or any other jewelry. Do not lean over the battery when jump starting.
- Do not attempt to jump start a frozen battery. It could explode and cause serious injury.
- Your vehicle has an automatic engine cooling fan. It could come on at any time. Keep hands and other objects away from it.





## **A** WARNING

Always follow the instructions below. Failure to do so could result in damage to the charging system and cause personal injury.

If the booster battery is in another vehicle

 (a) and
 (b) to bring their batteries into close proximity to each other.

Do not allow the two vehicles to touch.

- 2. Apply the parking brake.
- 3. Continuously Variable Transmission (CVT) models:

Move the shift lever to the P (Park) position.

Manual Transmission (MT) models:

Move the shift lever to the N (Neutral) position.

- Switch off all unnecessary electrical systems (headlights, heater, air conditioner, etc.).
- Remove the vent caps on the battery (if so equipped). Cover the battery with a firmly wrung out moist cloth to reduce explosion hazard.



6. Connect jumper cables in the sequence as illustrated  $(\widehat{1}) \rightarrow (\widehat{2}) \rightarrow (\widehat{3}) \rightarrow (\widehat{4})$ .

For the vehicle equipped with Intelligent Key system:

If the battery is discharged, the ignition switch cannot be moved from the OFF position. Connect the jumper cables to the booster vehicle (B) before turning the ignition switch.



- Always connect positive (+) to positive (+) and negative (-) to body ground (for example, as illustrated), not to the battery.
- Make sure the jumper cables do not touch moving parts in the engine compartment and that the cable clamps do not contact any other metal.
- Start the engine of the booster vehicle (B) and let it run for a few minutes.
- Keep the engine speed of the booster vehicle (B) at about 2,000 rpm, and start the engine of the vehicle (A) being jump started.

### **PUSH STARTING**

Do not attempt to start the engine by pushing.

## A CAUTION

Do not keep the starter motor engaged for more than 10 seconds. If the engine does not start right away, place the ignition switch in the OFF position and wait 10 seconds before trying again.

- 9. After starting your engine, carefully disconnect the negative cable and then the positive cable  $(\widehat{\mathbf{4}}) \to (\widehat{\mathbf{3}}) \to (\widehat{\mathbf{2}}) \to (\widehat{\mathbf{1}})$ .
- 10. Replace the vent caps (if so equipped). Be sure to dispose of the cloth used to cover the vent holes as it may be contaminated with corrosive acid.



### **CAUTION**

- **Continuously Variable Transmission** (CVT) models cannot be pushstarted or tow-started. Attempting to do so may cause transmission damage.
- Three-way catalyst equipped models should not be started by pushing since the three way catalyst may be damaged.
- Never try to start the vehicle by towing it; when the engine starts, the forward surge could cause the vehicle to collide with the tow vehicle.

### **A** CAUTION

IF YOUR VEHICLE OVERHEATS

- Do not continue to drive if your vehicle overheats. Doing so could cause engine damage or a vehicle fire.
- To avoid the danger of being scalded, never remove the radiator cap while the engine is still hot. When the radiator cap is removed, pressurized hot water will spurt out, possibly causing serious injury.
- Do not open the hood if steam is coming out.

If your vehicle is overheating (indicated by an extremely high temperature gauge reading), or if you feel a lack of engine power, detect abnormal noise, etc., take the following steps:

- 1. Move the vehicle safely off the road and apply the parking brake.
- 2. Continuously Variable Transmission (CVT) models:

Move the shift lever to the P (Park) position.

### Manual Transmission (MT) models:

Move the shift lever to the N (Neutral) position.



### Do not stop the engine.

- Turn off the air conditioner (if so equipped).
   Open all the windows, move the heater or air conditioner temperature control to maximum hot and fan control to high speed.
- 4. Get out of the vehicle. Look and listen for steam or coolant escaping from the radiator before opening the hood. (If steam or coolant is escaping, turn off the engine.) Do not open the hood further until no steam or coolant can be seen.
- 5. Open the engine hood.



If steam or water is coming from the engine, stand clear to prevent getting burned.

 Visually check the drive belt for damage or looseness. Also check if the cooling fan is running. The radiator hoses and radiator should not leak water. If coolant is leaking or the cooling fan does not run, stop the engine.



Be careful not to allow your hands, hair, jewelry or clothing to come into contact with, or get caught in, engine belts or the engine cooling fan. The engine cooling fan can start at any time.

 After the engine cools down, check the coolant level in the reservoir with the engine running. Add coolant to the reservoir if necessary. Have your vehicle repaired at a NISSAN dealer.



### **TOWING YOUR VEHICLE**

When towing your vehicle, all State (Provincial in Canada) and local regulations for towing must be followed. Incorrect towing equipment could damage your vehicle. Towing instructions are available from a NISSAN dealer. Local service operators are familiar with the applicable laws and procedures for towing. To assure proper towing and to prevent accidental damage to your vehicle, NISSAN recommends that you have a service operator tow your vehicle. It is advisable to have the service operator carefully read the following precautions.



### WARNING

- Never ride in a vehicle that is being towed.
- Never get under your vehicle after it has been lifted by a tow truck.




### A CAUTION

. When towing, make sure that the transmission, axles, steering system and powertrain are in working condition. If any unit is damaged, dollies must be used.

### · Always attach safety chains before towing.

For information about towing your vehicle behind a recreational vehicle (RV), see "Flat towing" (P.9-17) of this manual.





Two-wheel drive models

## TOWING RECOMMENDED BY NISSAN

### Two-Wheel Drive (2WD) models

NISSAN recommends that your vehicle be towed with the driving (front) wheels off the ground or place the vehicle on a flat bed truck as illustrated.


## **A** CAUTION

 Never tow CVT models with the front wheels on the ground or four wheels on the ground (forward or backward), as this may cause serious and expensive damage to the transmission. If it is necessary to tow the vehicle with the rear wheels raised, always use towing dollies under the front wheels.

 When towing CVT models with the front wheels on towing dollies: Push the ignition switch to the ACC or ON position, and secure the steering wheel in a straightahead position with a rope or similar device. Move the shift lever to the N (Neutral) position.

DEALER E-PROCESS

 When towing a CVT model with the rear wheels on the ground (if you do not use towing dollies): Always release the parking brake.



All-wheel drive models

### All-Wheel Drive (AWD) models

NISSAN recommends that towing dollies be used when towing your vehicle or the vehicle be placed on a flat bed truck as illustrated.



Never tow AWD models with any of the wheels on the ground as this may cause serious and expensive damage to the powertrain.

VEHICLE RECOVERY (freeing a stuck vehicle)




- . Stand clear of a stuck vehicle.
- Do not spin your tires at high speed.
   This could cause them to explode and result in serious injury. Parts of your vehicle could also overheat and be damaged.


Pulling a stuck vehicle

Do not use the tie down hook for towing or vehicle recovery.






Front (except for NISMO models)




Front (NISMO models)



#### Front:

- 1. Remove the hook cover (1) from the bumper with a suitable tool.
- 2. Securely install the recovery hook (2) as illustrated.

Make sure that the hook is properly secured in its original position after use.



Rear:

Do not use the tie down hook to pull the vehicle.

## **A** CAUTION

- Tow chains or cables must be attached only to the vehicle recovery hook or main structural members of the vehicle. Otherwise, the vehicle body will be damaged.
- Do not use the vehicle tie down hook to free a vehicle stuck in sand, snow, mud, etc.



- Never tow a vehicle using the vehicle tie down hook or recovery hook.
- Always pull the cable straight out from the front of the vehicle. Never pull on the vehicle at an angle.
- Pulling devices should be routed so they do not touch any part of the suspension, steering, brake or cooling systems.
- Pulling devices such as ropes or canvas straps are not recommended for use in vehicle towing or recovery.

### Rocking a stuck vehicle

If your vehicle is stuck in sand, snow, mud, etc., use the following procedure:

- Turn off the Vehicle Dynamic Control (VDC) system.
- Make sure the area in front and behind the vehicle is clear of obstructions.
- Turn the steering wheel right and left to clear an area around the front tires.
- Slowly rock the vehicle forward and backward.
  - Shift back and forth between R (Reverse) and D (Drive) (Continuously Variable

- Transmission models) or 1st and R (Reverse) (Manual Transmission models).
- Apply the accelerator as little as possible to maintain the rocking motion.
- Release the accelerator pedal before shifting between R and D (Continuously Variable Transmission models) or 1st and R (Manual Transmission models).
- Do not spin the tires above 35 MPH (55 km/h).
- If the vehicle cannot be freed after a few tries, contact a professional towing service to remove the vehicle.



# 7 Appearance and care

| Cleaning exterior     | . 7- |
|-----------------------|------|
| Washing               | . 7- |
| Waxing                | . 7- |
| Removing spots        | . 7- |
| Underbody             | . 7- |
| Glass                 | . 7- |
| Wheels                | . 7- |
| Aluminum alloy wheels | . 7- |
| Chrome parts          | . 7- |
| Tire dressing         | . 7- |
|                       |      |

| Cleaning interior                                     | 7- |
|---|----|
| Air fresheners  | 7- |
| Floor mats  | 7- |
| Seat belts  | 7- |
| Corrosion protection                                  | 7- |
| Most common factors contributing to vehicle corrosion | 7- |
| Environmental factors influence the rate of corrosion | 7- |
| To protect your vehicle from corrosion                | 7- |
|   |    |



### **CLEANING EXTERIOR**

In order to maintain the appearance of your vehicle, it is important to take proper care of it.

To protect the paint surfaces, wash your vehicle as soon as you can:

- after a rainfall to prevent possible damage from acid rain
- · after driving on coastal roads
- when contaminants such as soot, bird droppings, tree sap, metal particles or bugs get on the paint surface
- when dust or mud builds up on the surface Whenever possible, store or park your vehicle inside a garage or in a covered area.

When it is necessary to park outside, park in a shady area or protect the vehicle with a body cover.

Be careful not to scratch the paint surface when putting on or removing the body cover.

#### WASHING

Wash dirt off the vehicle with a wet sponge and plenty of water. Clean the vehicle thoroughly using a mild soap, a special vehicle soap or general purpose dishwashing liquid mixed with clean, lukewarm (never hot) water.



### CAUTION

- Do not use car washes that use acid in the detergent. Some car washes, especially brushless ones, use some acid for cleaning. The acid may react with some plastic vehicle components, causing them to crack. This could affect their appearance, and also could cause them not to function properly. Always check with your car wash to confirm that acid is not used.
- Do not wash the vehicle with strong household soap, strong chemical detergents, gasoline or solvents.
- Do not wash the vehicle in direct sunlight or while the vehicle body is hot, as the surface may become water-spotted.


 Avoid using tight-napped or rough cloths, such as washing mitts. Care must be taken when removing caked-on dirt or other foreign substances so the paint surface is not scratched or damaged.

Rinse the vehicle thoroughly with plenty of clean water.

Inside flanges, seams and folds on the doors, hatches and hood are particularly vulnerable to the effects of road salt. Therefore, these areas must be regularly cleaned. Make sure that the drain holes in the lower edge of the door are open. Spray water under the body and in the wheel wells to loosen the dirt and wash away road salt.

Avoid leaving water spots on the paint surface by using a damp chamois to dry the vehicle.





Model with rear spoiler



Do not use an automatic car wash for model with rear spoiler. The rear spoiler may be damaged.

### WAXING

Regular waxing protects the paint surface and helps retain new vehicle appearance. Polishing is recommended to remove built-up wax residue and to avoid a weathered appearance before reapplying wax.

A NISSAN dealer can assist you in choosing the proper product.

- Wax your vehicle only after a thorough washing. Follow the instructions supplied with the wax.
- Do not use a wax containing any abrasives, cutting compounds or cleaners that may damage the vehicle finish.

Machine compound or aggressive polishing on a base coat/clear coat paint finish may dull the finish or leave swirl marks.

### REMOVING SPOTS

Remove tar and oil spots, industrial dust, insects, and tree sap as quickly as possible from the paint surface to avoid lasting damage or staining. Special cleaning products are available at a NISSAN dealer or any automotive accessory stores.

### UNDERBODY

In areas where road salt is used in winter, the underbody must be cleaned regularly. This will prevent dirt and salt from building up and causing the acceleration of corrosion on the underbody and suspension. Before the winter period and again in the spring, the underseal must be checked and, if necessary, re-treated.

#### GLASS

Use glass cleaner to remove smoke and dust film from the glass surfaces. It is normal for glass to become coated with a film after the vehicle is parked in the hot sun. Glass cleaner and a soft cloth will easily remove this film.



When cleaning the inside of the windows, do not use sharp-edged tools, abrasive cleaners or chlorine-based disinfectant cleaners. They could damage the electrical conductors, radio antenna elements or rear window defroster elements.



#### WHEELS

Wash the wheels when washing the vehicle to maintain their appearance.

- Clean the inner side of the wheels when the wheel is changed or the underside of the vehicle is washed.
- Inspect wheel rims regularly for dents or corrosion. Such damage may cause loss of pressure or poor seal at the tire bead.
- NISSAN recommends that the road wheels be waxed to protect against road salt in areas where it is used during winter.



Do not use abrasive cleaners when washing the wheels.

#### **ALUMINUM ALLOY WHEELS**

Wash regularly with a sponge dampened in a mild soap solution, especially during winter months in areas where road salt is used. Salt could discolor the wheels if not removed.



Follow the directions below to avoid staining or discoloring the wheels:

- Do not use a cleaner that uses strong acid or alkali contents to clean the wheels.
- Do not apply wheel cleaners to the wheels when they are hot. The wheel temperature should be the same as ambient temperature.
- Rinse the wheel to completely remove the cleaner within 15 minutes after the cleaner is applied.

#### CHROME PARTS

Clean chrome parts regularly with a non-abrasive chrome polish to maintain the finish.

#### TIRE DRESSING

NISSAN does not recommend the use of tire dressings. Tire manufacturers apply a coating to the tires to help reduce discoloration of the rubber. If a tire dressing is applied to the tires, it may react with the coating and form a compound. This compound may come off the tire while driving and stain the vehicle paint.

If you choose to use a tire dressing, take the

### following precautions:

- Use a water-based tire dressing. The coating on the tire dissolves more easily with an oil-based tire dressing.
- Apply a light coat of tire dressing to help prevent it from entering the tire tread/ grooves (where it would be difficult to remove).
- Wipe off excess tire dressing using a dry towel. Make sure the tire dressing is completely removed from the tire tread/ grooves.
- Allow the tire dressing to dry as recommended by tire dressing manufacturer.



### **CLEANING INTERIOR**

Occasionally remove loose dust from the interior trim, plastic parts and seats using a vacuum cleaner or soft bristled brush. Wipe the vinyl and leather surfaces with a clean, soft cloth dampened in mild soap solution, then wipe clean with a dry soft cloth.

Regular care and cleaning is required in order to maintain the appearance of the leather.

Before using any fabric protector, read the manufacturer's recommendations. Some fabric protectors contain chemicals that may stain or bleach the seat material.

Use a cloth dampened only with water, to clean the meter and gauge lens.



### **WARNING**

Do not use water or acidic cleaners (hot steam cleaners) on the seat. This can damage the seat or occupant classification sensors. This can also affect the operation of the air bag system and result in serious personal injury.



### **A** CAUTION

- Never use benzine, thinner, or any similar material.
- For cleaning, use a soft cloth, dampened with water. Never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or cause discoloration to the lens.
- Do not spray any liquid such as water on the meter lens. Spraving liquid may cause the system to malfunction.
- Small dirt particles can be abrasive and damaging to the leather surfaces and should be removed promptly. Do not use saddle soap. car waxes, polishes, oils, cleaning fluids, solvents, detergents or ammonia-based cleaners as they may damage the leather's natural finish.
- Never use fabric protectors unless recommended by the manufacturer.
- Do not use glass or plastic cleaner on meter or gauge lens covers. It

### may damage the lens cover.

### AIR FRESHENERS

Most air fresheners use a solvent that could affect the vehicle interior. If you use an air freshener, take the following precautions:

- Hanging-type air fresheners can cause permanent discoloration when they contact vehicle interior surfaces. Place the air freshener in a location that allows it to hang free and not contact an interior surface.
- Liquid-type air fresheners typically clip on the vents. These products can cause immediate damage and discoloration when spilled on interior surfaces.

Carefully read and follow the manufacturer's instructions before using air fresheners.




### FLOOR MATS



To avoid potential pedal interference that may result in a collision or injury:

- NEVER place a floor mat on top of another floor mat in the driver front position.
- Use only genuine NISSAN floor mats specifically designed for use in your vehicle model. See your NISSAN dealer for more information.
- Properly position the mats in the floorwell using the floor mat positioning aid. See "Floor mat positioning aid" (P.7-6).

The use of genuine NISSAN floor mats can extend the life of your vehicle carpet and make it easier to clean the interior. Mats should be maintained with regular cleaning and replaced if they become excessively worn.




Front (example)

### Floor mat positioning aid

This model includes front floor mat brackets to act as floor mat positioning aid. NISSAN floor mats have been specially designed for your vehicle model. The front floor mats have grommet holes in them. To install, simply position the mat by placing the floor mat bracket through the floor mat grommet hole while centering the mat in the floorwell.

Periodically check to make certain that the mats are properly positioned.



Bracket positions

The illustration shows the location of the floor mat brackets.

#### SEAT BELTS

The seat belts can be cleaned by wiping them with a sponge dampened in a mild soap solution. Allow the belts to dry completely in the shade before using them.

See "Seat belts" (P.1-10).



Do not allow wet seat belts to roll up in the retractor. NEVER use bleach, dye, or chemical solvents to clean the seat



### **CORROSION PROTECTION**

belts, since these materials may severely weaken the seat belt webbing.

### MOST COMMON FACTORS CONTRI-BUTING TO VEHICLE CORROSION

- The accumulation of moisture-retaining dirt and debris in body panel sections, cavities, and other areas.
- Damage to paint and other protective coatings caused by gravel and stone chips or minor traffic accidents.

### ENVIRONMENTAL FACTORS INFLU-ENCE THE RATE OF CORROSION

### Moisture

Accumulation of sand, dirt and water on the vehicle body underside can accelerate corrosion. Wet floor coverings will not dry completely inside the vehicle, and should be removed for drying to avoid floor panel corrosion.

### Relative humidity

Corrosion will be accelerated in areas of high relative humidity, especially those areas where the temperatures stay above freezing where atmospheric pollution exists, or where road salt is used.

### **Temperature**

A temperature increase will accelerate the rate of corrosion to those parts which are not well ventilated.

### Air pollution

Industrial pollution, the presence of salt in the air in coastal areas, or heavy road salt use will accelerate the corrosion process. Road salt will also accelerate the disintegration of paint surfaces.

## TO PROTECT YOUR VEHICLE FROM CORROSION

- Wash and wax your vehicle often to keep the vehicle clean.
- Always check for minor damage to the paint and repair it as soon as possible.
- Keep drain holes at the bottom of the doors open to avoid water accumulation.
- Check the underbody for accumulation of sand, dirt or salt. If present, wash with water as soon as possible.



 NEVER remove dirt, sand or other debris from the passenger compartment by washing it out with a hose.



### Remove dirt with a vacuum cleaner.

Never allow water or other liquids to come in contact with electronic components inside the vehicle as this may damage them.

Chemicals used for road surface deicing are extremely corrosive. They accelerate corrosion and deterioration of underbody components such as the exhaust system, fuel and brake lines, brake cables, floor pan and fenders.

### In winter, the underbody must be cleaned periodically.

For additional protection against rust and corrosion, which may be required in some areas, consult a NISSAN dealer.



# 8 Maintenance and do-it-yourself

| Maintenance requirement                        | 8-2  |
|--|------|
| Scheduled maintenance                          | 8-2  |
| General maintenance                            | 8-2  |
| Where to go for service                        | 8-2  |
| General maintenance                            | 8-2  |
| Explanation of maintenance items               | 8-2  |
| Maintenance precautions                        | 8-5  |
| Engine compartment check locations             | 8-6  |
| MR16DDT engine                                 | 8-6  |
| Engine cooling system                          | 8-7  |
| Checking engine coolant level                  | 8-8  |
| Changing engine coolant                        | 8-8  |
| Engine oil                                     | 8-8  |
| Checking engine oil level                      | 8-8  |
| Changing engine oil and filter                 | 8-9  |
| Continuously Variable Transmission (CVT) fluid | 8-11 |
| Brake and clutch (if so equipped) fluid        | 3-11 |
| Window washer fluid                            | 3-12 |
| Battery  | 8-13 |
| Jump starting                                  | 8-14 |
| Variable voltage control system                | 8-14 |
| Drive belt                                     | B-15 |
| Spark plugs                                    | 8-15 |
| Replacing spark plugs                          | 8-16 |

| 8-1  |
|------|
| 8-1  |
| 8-1  |
| 8-1  |
| 8-18 |
| 8-18 |
| 8-18 |
| 8-18 |
| 8-19 |
| 8-19 |
| 8-2  |
| 8-2  |
| 8-2  |
| 8-2  |
| 8-2  |
| 8-2  |
| 8-2  |
| 8-3  |
| 8-30 |
| 8-3  |
| 8-3  |
| 8-38 |
| 8-39 |
|      |



### MAINTENANCE REQUIREMENT

Some day-to-day and regular maintenance is essential to maintain your vehicle good mechanical condition, as well as its emission and engine performance.

It is the owner's responsibility to make sure that the scheduled maintenance, as well as general maintenance, is performed.

As the vehicle owner, you are the only one who can ensure that your vehicle receives the proper maintenance care. You are a vital link in the maintenance chain.

#### SCHEDULED MAINTENANCE

For your convenience, both required and optional scheduled maintenance items are described and listed in your "NISSAN Service and Maintenance Guide". You must refer to that guide to ensure that necessary maintenance is performed on your vehicle at regular intervals.

### **GENERAL MAINTENANCE**

General maintenance includes those items which should be checked during normal day-to-day operation. They are essential for proper vehicle operation. It is your responsibility to perform these procedures regularly as prescribed.

Performing general maintenance checks requires minimal mechanical skill and only a few general automotive tools. These checks or inspections can be done by yourself, a qualified technician or, if you prefer, a NISSAN dealer.

### WHERE TO GO FOR SERVICE

If maintenance service is required or your vehicle appears to malfunction, have the systems checked and serviced by a NISSAN dealer.

NISSAN technicians are well-trained specialists and are kept up-to-date with the latest service information through technical bulletins, service tips, and in-dealership information systems. They are completely qualified to work on NISSAN vehicles **before** work begins.

You can be confident that a NISSAN dealer's service department performs the best job to meet the maintenance requirements on your vehicle.

#### **GENERAL MAINTENANCE**

During the normal day-to-day operation of the vehicle, general maintenance should be performed regularly as prescribed in this section. If you detect any unusual sounds, vibrations or smell, be sure to check for the cause or have a NISSAN dealer do it promptly. In addition, you should notify a NISSAN dealer if you think that repairs are required.

When performing any checks or maintenance work, see "Maintenance precautions" (P.8-5).

## EXPLANATION OF MAINTENANCE ITEMS

Additional information on the following items with "\*" is found later in this section.

### Outside the vehicle

The maintenance items listed here should be performed from time to time, unless otherwise specified.

**Doors and engine hood:** Check that all doors and the engine hood operate properly. Also ensure that all latches lock securely. Lubricate hinges, latches, latch pins, rollers and links if necessary. Make sure that the secondary latch keeps the hood from opening when the primary latch is released.

When driving in areas using road salt or other corrosive materials, check lubrication frequently.

Lights\*: Clean the headlights on a regular basis.

Make sure that the headlights, stop lights, tail lights, turn signal lights, and other lights are all operating properly and installed securely. Also check headlight aim.

Road wheel nuts (lug nuts)\*: When checking the tires, make sure no wheel nuts are missing, and check for any loose wheel nuts. Tighten if necessary.

**Tire rotation\*:** Tires should be rotated every 5,000 miles (8,000 km).

**Tires\*:** Check the pressure with a gauge often and always prior to long distance trips. If necessary, adjust the pressure in all tires, including the spare, to the pressure specified. Check carefully for damage, cuts or excessive wear.

**Tire Pressure Monitoring System (TPMS) transmitter components:** Replace the TPMS transmitter grommet seal, valve core and cap when the tires are replaced due to wear or age.

Wheel alignment and balance: If the vehicle should pull to either side while driving on a straight and level road, or if you detect uneven or abnormal tire wear, there may be a need for wheel alignment.

If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed. For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

**Windshield:** Clean the windshield on a regular basis. Check the windshield at least every six months for cracks or other damage. Have a damaged windshield repaired by a qualified repair facility.

**Windshield wiper blades\*:** Check for cracks or wear if they do not wipe properly.

Inside the vehicle

The maintenance items listed here should be checked on a regular basis, such as when performing scheduled maintenance, cleaning the vehicle, etc.

**Accelerator pedal:** Check the pedal for smooth operation and make sure the pedal does not catch or require uneven effort. Keep the floor mat away from the pedal.

**Brake pedal:** Check the pedal for smooth operation. If the brake pedal suddenly goes down further than normal, the pedal feels spongy or the vehicle seems to take longer to stop, see a NISSAN dealer immediately. Keep the floor mat away from the pedal.

**Brakes:** Check that the brakes do not pull the vehicle to one side when applied.

Continuously Variable Transmission (CVT) P (Park) position mechanism: On a fairly steep hill, check that the vehicle is held securely with the shift lever in the P (Park) position without applying any brakes.

**Parking brake:** Check the parking brake operation regularly. The vehicle should be securely held on a fairly steep hill with only the parking brake applied. If the parking brake needs adjusted, see a NISSAN dealer.

**Seat belts:** Check that all parts of the seat belt system (for example, buckles, anchors, adjusters and retractors) operate properly and smoothly, and are installed securely. Check the belt webbing for cuts, fraying, wear or damage.

**Seats:** Check seat position controls such as seat adjusters, seatback recliners, etc. to ensure they operate smoothly and that all latches lock securely in every position. Check that the head restraints move up and down smoothly and that the locks (if so equipped) hold securely in all latched positions.

**Steering wheel:** Check for changes in the steering conditions, such as excessive free play, hard steering or strange noises.

Warning lights and chimes: Make sure that all warning lights and chimes are operating properly.

Windshield defroster: Check that the air Maintenance and do-it-yourself 8-3 comes out of the defroster outlets properly and in sufficient quantity when operating the heater or air conditioner.

**Windshield wiper and washer\*:** Check that the wipers and washers operate properly and that the wipers do not streak.

#### Under the hood and vehicle

The maintenance items listed here should be checked periodically (for example, each time you check the engine oil or refuel).

Battery\*: Check the fluid level in each cell.

It should be between the MAX and MIN lines. Vehicles operated in high temperatures or under severe condition require frequent checks of the battery fluid level.

#### NOTE:

Care should be taken to avoid situations that can lead to potential battery discharge and potential no-start conditions such as:

- Installation or extended use of electronic accessories that consume battery power when the engine is not running (Phone chargers, GPS, DVD players, etc.)
- Vehicle is not driven regularly and/or only driven short distances.

In these cases, the battery may need to be

charged to maintain battery health.

Brake and clutch fluid level\*: Make sure that the brake and clutch fluid level is between the MAX and MIN lines on the reservoir.

**Engine coolant level\*:** Check the coolant level when the engine is cold.

**Engine drive belt\*:** Make sure that the drive belt is not frayed, worn, cracked or oily.

Engine oil level\*: Check the level after parking the vehicle on a level surface and turning off the engine. Wait more than 10 minutes for the oil to drain back into the oil pan.

**Exhaust system:** Make sure there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes, immediately have the exhaust system inspected by a NISSAN dealer. (See "Precautions when starting and driving" (P.5-3) for exhaust gas (carbon monoxide).)

Fluid leaks: Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If you should notice any leaks or if gasoline fumes are evident, check for the cause and have it corrected immediately.

Radiator and hoses: Check the front of the radiator and clean off any dirt, insects, leaves,

etc., that may have accumulated. Make sure the hoses have no cracks, deformation, rot or loose connections.

**Underbody:** The underbody is frequently exposed to corrosive substances such as those used on icy roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter, the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt may accumulate. For additional information, see "Cleaning exterior" (P.7-2).

**Windshield washer fluid\*:** Check that there is adequate fluid in the reservoir.

#### MAINTENANCE PRECAUTIONS

When performing any inspection or maintenance work on your vehicle, always take care to prevent serious accidental injury to yourself or damage to the vehicle. The following are general precautions which should be closely observed.



### WARNING

- Park the vehicle on a level surface. apply the parking brake securely and block the wheels to prevent the vehicle from moving. Move the shift lever to the P (Park) position (CVT model) or the shift lever to the N (Neutral) position (MT model).
- Be sure the ignition switch is in the OFF or LOCK position when performing any parts replacement or repairs.
- If you must work with the engine running, keep your hands, clothing, hair and tools away from moving fans, belts and any other moving parts.
- It is advisable to secure or remove any loose clothing and remove any jewelry, such as rings, watches, etc. before working on your vehicle.

- Always wear eve protection whenever you work on your vehicle.
- If you must run the engine in an enclosed space such as a garage, be sure there is proper ventilation for exhaust gases to escape.
- Never get under the vehicle while it is supported only by a jack. If it is necessary to work under the vehicle. support it with safety stands.
- Keep smoking materials, flame and sparks away from fuel tank and the batterv.
- The fuel filter or fuel lines should be serviced by a NISSAN dealer because the fuel lines are under high pressure even when the engine is off.



### CAUTION

- Do not work under the hood while the engine is hot. Turn the engine off and wait until it cools down.
- Avoid direct contact with used engine oil and coolant. Improperly disposed engine oil, and engine

- coolant and/or other vehicle fluids can damage the environment. Always conform to local regulations for disposal of vehicle fluid.
- Never leave the engine or the CVT related component harnesses disconnected while the ignition switch is in the ON position.
- Never connect or disconnect the battery or any transistorized component while the ignition switch is in the ON position.
- Your vehicle is equipped with an automatic engine cooling fan. It may come on at any time without warning, even if the ignition key is in the OFF position and the engine is not running. To avoid injury, always disconnect the negative battery cable before working near the fan.

This "8. Maintenance and do-it-yourself" section gives instructions regarding only those items which are relatively easy for an owner to perform.


A genuine NISSAN Service Manual is also available. (See "Owner's manual/service manual order information" (P.9-21).)

You should be aware that incomplete or



## ENGINE COMPARTMENT CHECK LOCATIONS

improper servicing may result in operating difficulties or excessive emissions, and could affect your warranty coverage. If in doubt about any servicing, we recommend that it be done by a NISSAN dealer.



#### MR16DDT ENGINE

- Engine oil filler cap
- 2. Radiator filler cap
- Brake and clutch\* fluid reservoir
- 4. Air cleaner
- 5. Window washer fluid reservoir
- 6. Engine drive belt location

- 7. Engine oil dipstick
- 8. Engine coolant reservoir
- 9. Fuse/fusible link holder
- 10. Battery
- \*: for Manual Transmission (MT) models



#### **ENGINE COOLING SYSTEM**

The engine cooling system is filled at the factory with a pre-diluted mixture of 50% Genuine NISSAN Long Life Antifreeze/Coolant (blue) and 50% water to provide year-round anti-freeze and coolant protection. The anti-freeze solution contains rust and corrosion inhibitors. Additional engine cooling system additives are not necessary.



### **WARNING**

- Never remove the radiator or coolant reservoir cap when the engine is hot. Wait until the engine and radiator cool down. Serious burns could be caused by high pressure fluid escaping from the radiator. See precautions in "If your vehicle overheats" (P.6-10) of this manual.
- The radiator is equipped with a pressure type radiator cap. To prevent engine damage, use only a genuine NISSAN radiator cap.
- If the engine was stopped soon when the engine is hot, the cooling fan may operate for approximately 10 minutes after the engine was stopped to cool the components in the engine compartment. When the

cooling fan is operating, be sure that hands or other items do not get caught in it.




### A CAUTION

- Never use any cooling system additives such as radiator sealer. Additives may clog the cooling system and cause damage to the engine, transmission and/or cooling system.
- When adding or replacing coolant. be sure to use only Genuine NISSAN Long Life Antifreeze/Coolant (blue) or equivalent. Genuine NISSAN Long Life Antifreeze/Coolant (blue) is pre-diluted to provide antifreeze protection to -34°F (-37°C). If additional freeze protection is needed due to weather where you operate your vehicle, add Genuine NISSAN Long Life Antifreeze/ Coolant (blue) concentrate following the directions on the container. If an equivalent coolant other than Genuine NISSAN Long Life Antifreeze/Coolant (blue) is used, fol-

- low the coolant manufacture's instructions to maintain minimum antifreeze protection to -34°F (-37°C). The use of other types of coolant solutions other than Genuine NISSAN Long Life Antifreeze/ Coolant (blue) or equivalent may damage the engine cooling system.
- The life expectancy of the factory-fill coolant is 105,000 miles (168,000 km) or 7 years. Mixing any other type of coolant other than Genuine NISSAN Long Life Antifreeze/Coolant (blue), including Genuine NISSAN Long Life Antifreeze/Coolant (green), or the use of nondistilled water will reduce the life expectancy of the factory-fill coolant. Refer to the NISSAN Service and Maintenance Guide for more details.





#### CHECKING ENGINE COOLANT LEVEL

Check the coolant level in the reservoir when the engine is cold. If the coolant level is below the MIN level ②, open the reservoir cap and add coolant up to the MAX level ①. If the reservoir is empty, check the coolant level in the radiator when the engine is cold. If there is insufficient coolant in the radiator, fill the radiator with coolant up to the filler opening and also add it to the reservoir up to the MAX level ①.

Tighten the cap securely after adding engine coolant.

If the cooling system frequently requires coolant, have it checked by a NISSAN dealer.

#### 8-8 Maintenance and do-it-yourself

#### CHANGING ENGINE COOLANT

Major cooling system repairs should be performed by a NISSAN dealer. The service procedures can be found in the appropriate NISSAN Service Manual.

Improper servicing can result in reduced heater performance and engine overheating.


## **A** WARNING

- To avoid the danger of being scalded, never change the coolant when the engine is hot.
- Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.
- Avoid direct skin contact with used coolant. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.
- Keep coolant out of reach of children and pets.

Engine coolant must be disposed of properly. Check your local regulations.



#### **ENGINE OIL**



#### CHECKING ENGINE OIL LEVEL

- Park the vehicle on a level surface and apply the parking brake.
- 2. Run the engine until it reaches operating temperature.
- 3. Turn off the engine. Wait more than 10 minutes for the oil to drain back into the oil pan.
- 4. Remove the dipstick and wipe it clean. Reinsert it all the way.
- Remove the dipstick again and check the oil level. It should be within the range ©. If the oil level is below (A), remove the oil filler cap and pour recommended oil through the

- opening. Do not overfill (B).
- 6. Recheck oil level with the dipstick.

It is normal to add some oil between oil maintenance intervals or during the breakin period, depending on the severity of operating conditions.



Oil level should be checked regularly. Operating the engine with an insufficient amount of oil can damage the engine, and such damage is not covered by the warranty.

#### CHANGING ENGINE OIL AND FILTER

Change the engine oil and filter according to the maintenance log shown in the NISSAN Service and Maintenance Guide.


#### Vehicle set-up


- 1. Park the vehicle on a level surface and apply the parking brake.
- 2. Run the engine until it reaches the operating temperature.
- 3. Turn the engine off and wait more than 10 minutes.

- 4. Raise and support the vehicle using a suitable floor jack and safety jack stands.
  - · Place the safety jack stands under the vehicle jack-up points.
  - · A suitable adapter should be attached to the jack stand saddle.



Make sure the correct lifting and support points are used to avoid vehicle damage.







#### Engine oil and filter

- 1. Oil filler cap
- 2. Oil drain plug
- 3. Oil filter
- 1. Place a large drain pan under the drain plug.
- 2. Remove the oil filler cap.
- Remove the drain plug with a wrench and completely drain the oil.



Be careful not to burn yourself, as the engine oil is hot.

- Waste oil must be disposed of properly.
- · Check your local regulations.

(Perform steps 4 to 7 only when the engine oil filter change is needed.)

- Loosen the oil filter with an oil filter wrench.
   Remove the oil filter by turning it by hand.
- Wipe the engine oil filter mounting surface with a clean rag.



Be sure to remove any old gasket material remaining on the mounting surface of the engine. Failure to do so could lead to engine damage.

- Coat the gasket on the new filter with clean engine oil.
- Screw in the oil filter clockwise until a slight resistance is felt, then tighten additionally more than 2/3 turn.

Oil filter tightening torque: 11 to 15 ft-lb (14.7 to 20.5 N·m)

Clean and re-install the drain plug with a new washer. Securely tighten the drain plug with a wrench.

Drain plug tightening torque: 22 to 29 ft-lb (29 to 39 N-m)

Do not use excessive force.

Refill the engine with the recommended oil through the oil filler opening, and install the oil filler cap securely.

See "Capacities and recommended fuel/

lubricants" (P.9-2) for drain and refill capacity. The drain and refill capacity depends on the oil temperature and drain time. Use these specifications for reference only. Always use the dipstick to determine the proper amount of oil in the engine.

- Start the engine and check for leakage around the drain plug and the oil filter. Correct as required.
- 11. Turn the engine off and wait more than 10 minutes. Check the oil level with the dipstick. Add engine oil if necessary.

#### After the operation

- 1. Lower the vehicle carefully to the ground.
- 2. Dispose of waste oil and filter properly.



- Prolonged and repeated contact with used engine oil may cause skin cancer.
- Try to avoid direct skin contact with used oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.
- Keep used engine oil out of reach of children.



#### **CONTINUOUSLY VARIABLE** TRANSMISSION (CVT) FLUID

When checking or replacement is required, we recommend a NISSAN dealer for servicing.



### A CAUTION

- **Use only Genuine NISSAN CVT Fluid** NS-2. Do not mix with other fluids.
- Using transmission fluid other than Genuine NISSAN CVT Fluid NS-2 will damage the CVT, which is not covered by the NISSAN new vehicle limited warranty.

#### **BRAKE AND CLUTCH (if so** equipped) FLUID

For additional brake and clutch fluid information. see "Capacities and recommended fuel/lubricants" (P.9-2) of this manual.




### WARNING

- Use only new fluid from a sealed container. Old, inferior or contaminated fluid may damage the brake and clutch systems. The use of improper fluids can damage the brake and clutch systems, and affect the vehicle's stopping ability.
- Clean the filler cap before removing.
- Brake and clutch fluid is poisonous and should be stored carefully in marked containers out of the reach of children.



### **A** CAUTION


Do not spill the fluid on any painted surfaces. This will damage the paint. If fluid is spilled, immediately wash the surface with water.



Check the fluid level in the reservoir. If the fluid is below the MIN line (2) or the brake warning light comes on, add Genuine NISSAN Super Heavy Duty Brake Fluid or equivalent DOT 3 fluid up to the MAX line (1). If fluid must be added frequently, the system should be checked by a NISSAN dealer.



#### WINDOW WASHER FLUID



To fill the window washer fluid reservoir, lift the cap and pour the window washer fluid into the reservoir opening.

Add a washer solvent to the washer for better cleaning. In the winter season, add a windshield washer antifreeze. Follow the manufacturer's instructions for the mixture ratio.

Fill the window washer fluid reservoir periodically.

Add fluid when the low washer fluid warning light illuminates (if so equipped).

To check the fluid level, use your finger to plug the center hole ① of the cap/tube assembly, then remove it from the reservoir. If there is no fluid in the tube, add fluid.

Refill the reservoir more frequently when driving conditions require an increased amount of window washer fluid.

Recommended fluid:

Genuine NISSAN Windshield Washer Concentrate Cleaner & Antifreeze or equivalent

## **A** CAUTION

- Do not substitute engine anti-freeze coolant for window washer solution.
   This may result in damage to the paint.
- Do not fill the window washer reservoir tank with washer fluid concentrates at full strength. Some methyl alcohol based washer fluid concentrates may permanently stain the grille if spilled while filling the window washer reservoir tank.
- Pre-mix washer fluid concentrates with water to the manufacturer's recommended levels before pouring the fluid into the window washer reservoir tank. Do not use the window washer reservoir tank to mix the washer fluid concentrate

#### and water.

#### **BATTERY**

- Keep the battery surface clean and dry. Clean the battery with a solution of baking soda and water.
- Make certain the terminal connections are clean and securely tightened.
- If the vehicle is not to be used for 30 days or longer, disconnect the negative ⊖ battery terminal cable to prevent discharging it.

#### NOTE:

Care should be taken to avoid situations that can lead to potential battery discharge and potential no-start conditions such as:

- 1. Installation or extended use of electronic accessories that consume battery power when the engine is not running (Phone chargers, GPS, DVD players, etc.)
- 2. Vehicle is not driven regularly and/or only driven short distances.

In these cases, the battery may need to be charged to maintain battery health.




### **WARNING**

Do not expose the battery to flames or electrical sparks. Hydrogen gas generated by the battery is explosive. Do not allow battery fluid to

contact your skin, eyes, fabrics or painted surfaces. After touching a battery or battery cap, do not touch or rub your eyes. Thoroughly wash your hands. If the acid contacts your eyes, skin or clothing, immediately flush with water for at least 15 minutes and seek medical attention.


- Do not operate the vehicle if the fluid in the battery is low. Low battery fluid can cause a higher load on the battery which can generate heat, reduce battery life, and in some cases lead to an explosion.
- When working on or near a battery. always wear suitable eve protection and remove all iewelry.
- Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling.
- Keep the battery out of the reach of children.



Check the fluid level in each cell. It should be between the UPPER LEVEL (1) and LOWER LEVEL (2) lines.

If it is necessary to add fluid, add only distilled water to bring the level to the indicator in each filler opening. Do not overfill.





- 1. Remove the cell plugs (A) .
- Add distilled water up to the UPPER LEVEL
   line.

If the side of the battery is not clear, check the distilled water level by looking directly above the cell; the condition ① indicates OK and the condition ② needs more to be added.

3. Tighten cell plugs (A).

Vehicles operated in high temperatures or under severe conditions require frequent checks of the battery fluid level.

JUMP STARTING

If jump starting is necessary, see "Jump starting" (P.6-8). If the engine does not start by jump starting, the battery may have to be replaced. Contact a NISSAN dealer.

## VARIABLE VOLTAGE CONTROL SYSTEM




- Do not ground accessories directly to the battery terminal. Doing so will bypass the variable voltage control system and the vehicle battery may not charge completely.
- Use electrical accessories with the engine running to avoid discharging the vehicle battery.

The variable voltage control system measures the amount of electrical discharge from the battery and controls voltage generated by the generator.



#### **DRIVE BELT**



- Alternator
- Drive belt auto-tensioner
- Crankshaft pulley
- Air conditioner compressor 4
- Water pump



### WARNING

Be sure the ignition switch is in the OFF or LOCK position before servicing drive belts. The engine could rotate unexpectedly.

1. Visually inspect the belt for signs of unusual wear, cuts, fraying or looseness. If the belt is

## in poor condition or loose, have it replaced

or adjusted by a NISSAN dealer. 2. Have the belt condition checked regularly.

#### **SPARK PLUGS**



### **WARNING**

Be sure the engine and ignition switch are off and that the parking brake is engaged securely.




### A CAUTION

Be sure to use the correct socket to remove the spark plugs. An incorrect socket can damage the spark plugs.



#### **AIR CLEANER**



#### REPLACING SPARK PLUGS

If replacement is required, see a NISSAN dealer for servicing.

#### Iridium platinum-tipped spark plugs

It is not necessary to replace the iridium platinum-tipped spark plugs as frequently as the conventional type spark plugs since they will last much longer. Follow the maintenance log shown in the "NISSAN Service and Maintenance Guide". Do not reuse the iridium platinum-tipped spark plugs by cleaning or regapping.

Always replace spark plugs with recommended or equivalent ones.

SDI2667

To remove the filter, pull the air duct ① upward to remove it. Pull the tabs ②, then pull the cover ③ upward.

The air cleaner filter should not be cleaned and reused. Replace it according to the maintenance shown in the "NISSAN Service and Maintenance Guide". When replacing the filter, wipe the inside of the air cleaner housing and the cover with a damp cloth.

## **A** WARNING

 Operating the engine with the air cleaner removed can cause you or others to be burned. The air cleaner not only cleans the air, it stops flame if the engine backfires. If it is not there, and the engine backfires, you could be burned. Do not drive with the air cleaner removed, and be careful when working on the engine with the air cleaner removed.

 Never pour fuel into the throttle body or attempt to start the engine with the air cleaner removed. Doing so could result in serious injury.

8-16 Maintenance and do-it-yourself

#### WINDSHIELD WIPER BLADES

#### **CLEANING**


If your windshield is not clear after using the windshield washer or if a wiper blade chatters when running, wax or other material may be on the blade or windshield.

Clean the outside of the windshield with a washer solution or a mild detergent. Your windshield is clean if beads do not form when rinsing with clear water.

Clean each blade by wiping it with a cloth soaked in a washer solution or a mild detergent. Then rinse the blade with clear water. If your windshield is still not clear after cleaning the blades and using the wiper, replace the blades.



Worn windshield wiper blades can damage the windshield and impair driver vision.




#### REPLACING.

Replace the wiper blades if they are worn.

Before replacing the wiper blades, the wiper should be in the fully up position to avoid scratching the engine hood or damaging the wiper arm. To pull up the wiper arm, see "Windshield wiper and washer switch" (P.2-32).

- 1. Lift the wiper arm away from the windshield.
- 2. Push and hold the release tab (A), and move the wiper blade down the wiper arm **(1)**.
- 3. Insert the new wiper blade onto the wiper arm until a click sounds.



4. Rotate the wiper blade so that the dimple is in the groove.

### A CAUTION

- After wiper blade replacement, return the wiper arm to its original position; otherwise it may be damaged when the hood is opened.
- the glass; otherwise the arm may be damaged from wind pressure.



#### **REAR WINDOW WIPER BLADE**

replacement is required.

Contact a NISSAN dealer if checking or

**BRAKES** 

If the brakes do not operate properly, have the brakes checked by a NISSAN dealer.

#### SELF-ADJUSTING BRAKES

Your vehicle is equipped with self-adjusting brakes.

The disc-type brakes self-adjust every time the brake pedal is applied.




See a NISSAN dealer for a brake system check if the brake pedal height does not return to normal.

#### BRAKE PAD WEAR WARNING

The disc brake pads have audible wear warnings. When a brake pad requires replacement, it will make a high pitched scraping sound when the vehicle is in motion. This scraping sound will first occur only when the brake pedal is depressed. After more wear of the brake pad. the sound will always be heard even if the brake pedal is not depressed. Have the brakes checked as soon as possible if the wear warning sound is heard.

Under some driving or climate conditions, occasional brake squeak, squeal or other noise may be heard. Occasional brake noise during




Be careful not to clog the washer nozzle (A) . This may cause improper windshield washer operation. If the nozzle is clogged, remove any objects with a needle or small pin (B). Be careful not to damage the nozzle.



#### **FUSES**

light to moderate stops is normal and does not affect the function or performance of the brake system.

Proper brake inspection intervals should be followed. For additional information, see the maintenance log section of your "NISSAN Service and Maintenance Guide".



**ENGINE COMPARTMENT** 



### A CAUTION


Never use a fuse of a higher or lower amperage rating than that specified on the fuse box cover. This could damage the electrical system or cause a fire.

If any electrical equipment does not operate, check for an open fuse.

1. Be sure the ignition switch and the headlight switch are turned off.




- 2. Open the engine hood.
- 3. Remove the fuse/fusible link holder cover by pushing the tab (1) and lifting the cover from the right side (2), then the left side **(3)**.
- 4. Locate the fuse that needs to be replaced.
- 5. Remove the fuse using the fuse puller located in the passenger compartment fuse box.



- 6. If the fuse is open (A) , replace it with a new fuse (B) .
- If a new fuse also opens, have the electrical system checked and repaired by a NISSAN dealer.

The holder (4) also contains the fuses. For checking and/or replacing, see a NISSAN dealer.




#### Fusible links


If any electrical equipment does not operate and the fuses are in good condition, check the fusible links in the holders ① and ②. If any of these fusible links are melted, replace only with genuine NISSAN parts.

For checking and replacing the fusible links in the holders (2), see a NISSAN dealer.





PASSENGER COMPARTMENT




Never use a fuse of a higher or lower amperage rating than that specified on the fuse box cover. This could damage the electrical system or cause a fire.

If any electrical equipment does not operate, check for an open fuse.


1. Be sure the ignition switch and the headlight switch are turned off.

- 2. Remove the fuse box cover (1).
- Remove the fuse with the fuse puller (2).



- 4. If the fuse is open (A), replace it with a new fuse (B).
- 5. If a new fuse also opens, have the electrical system checked and repaired by a NISSAN dealer.





# Extended storage fuse switch (if so equipped)

To reduce battery drain, the extended storage fuse switch comes from the factory switched off. Prior to delivery of your vehicle, the switch is pushed in (switched on) and should always remain on.

If the extended storage fuse switch is not pushed in (switched on), the meter may display a warning message. See "Extended storage fuse warning message" (P.2-7).

If any electrical equipment does not operate, remove the extended storage fuse switch and check for an open fuse.

#### **KEY BATTERY REPLACEMENT**



Be careful not to allow children to swallow the battery and removed parts.


#### NOTE:

If the extended storage fuse switch malfunctions or if the fuse is open, it is not necessary to replace the switch. In this case, remove the extended storage fuse switch and replace it with a new fuse of the same rating.

## How to remove the extended storage fuse switch:

- To remove the extended storage fuse switch, be sure the ignition switch is in the OFF or LOCK position.
- Be sure the headlight switch is in the OFF position.
- 3. Remove the fuse box cover.
- 4. Pinch the storage fuse switch and pull it in the direction illustrated.





#### **KEYFOB**

Replace the battery in the keyfob as follows:

- 1. Remove the screw.
- 2. Insert a small screwdriver into the slit of the corner and twist it to separate the upper part from the lower part. Use a cloth to protect

the casing.

3. Replace the battery with a new one.

Recommended battery:

CR1620 or equivalent

- · Do not touch the internal circuit and electric terminals as doing so could cause a malfunction.
- · Hold the battery by the edges. Holding the battery across the contact points will seriously deplete the storage capacity.
- Make sure that the 

  side faces the bottom of the case.
- 4. Close the lid securely and install the screw.
- Operate the buttons to check its operation.

See a NISSAN dealer if you need any assistance for replacement.

#### **FCC Notice:**


#### For USA:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### For Canada:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



#### INTELLIGENT KEY

Replace the battery in the Intelligent Key as follows:


1. Remove the mechanical key from the Intelligent Key.

- Insert a small screwdriver into the slit of the corner and twist it to separate the upper part from the lower part. Use a cloth to protect the casing.
- 3. Replace the battery with a new one.

Recommended battery:

CR2025 or equivalent

- Do not touch the internal circuit and electric terminals as doing so could cause a malfunction.
- Hold the battery by the edges. Holding the battery across the contact points will seriously deplete the storage capacity.
- Make sure that the 
   ⊕ side faces the bottom of the case.



- Align the tips of the upper and lower parts

   , and then push them together 2 until it is securely closed.
- 5. Operate the buttons to check its operation. See a NISSAN dealer if you need any assistance for replacement.

#### **FCC Notice:**

#### For USA:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that



may cause undesired operation.


Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### For Canada:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



#### LIGHTS



- Map light
- Front side marker light
- Front fog light (if so equipped)
- Headlight (high-beam/low-beam)
- Front turn signal light
- Front parking light
- Side turn signal light
- Daytime running light (NISMO models)
- High-mounted stop light
- Back-up light
- Stop light
- Rear turn signal/tail/rear side marker light
- License plate light
- 14. Cargo light



#### **HEADLIGHTS**

Fog may temporarily form inside the lens of the exterior lights in the rain or in a car wash. A temperature difference between the inside and the outside of the lens causes the fog. This is not a malfunction. If large drops of water collect inside the lens, contact a NISSAN dealer.

#### Replacing

#### Halogen headlight model:

The headlight is a semi-sealed beam type which uses a replaceable headlight (halogen) bulb.


## A CAUTION

- Do not leave the bulb out of the headlight reflector for a long period of time. Dust, moisture, smoke, etc. entering the headlight body may affect bulb performance.
- High pressure halogen gas is sealed inside the halogen bulb. The bulb may break if the glass envelope is scratched or the bulb is dropped.
- Only touch the base when handling the bulb. Never touch the glass envelope. Touching the glass envelope could significantly affect bulb

life and/or headlight performance.

Aiming is not necessary after replacing the bulb. When aiming adjustment is necessary, contact a NISSAN dealer.

Use the same number and wattage as originally installed as shown in the chart.



Disconnect the battery negative cable before replacing bulbs.

- 1. Remove the connector.
- 2. Turn the holder (A) and then pull out it. Remove the cap (B) and then remove the bulb (C).




#### **EXTERIOR AND INTERIOR LIGHTS**

| Item                                      | Wattage (W) | Bulb No. |
|---|-------------|----------|
| Headlight high/low beams (Halogen)        | 65/55       | HB5      |
| Front turn signal light*                  | 21          | PY21W    |
| Front fog light (if so equipped)*         | 35          | H8       |
| Front side marker light*                  | 3.8         | 194      |
| Front parking light*                      | 5           | WY5W     |
| Side turn signal light*                   | 5           | WY5W     |
| Daytime running light (for NISMO models)* | LED         | -        |
| Rear combination light*                   |             |          |
| stop light                                | 21          | W21W     |
| turn signal/tail/rear side marker light   | 21/5        | W21/5W   |
| back-up                                   | 16          | W16W     |
| License plate light*                      | 5           | W5W      |
| Map light                                 | 5           | _        |
| High-mounted stop light*                  | LED         | _        |
| Cargo light                               | 5           | _        |
| Glove box light*                          | 1.4         | _        |

<sup>\*:</sup> See a NISSAN dealer for replacement.

NOTE: Always check with the Parts Department at a NISSAN dealer for the latest information about parts.







### Replacement procedures

All other lights are either type A, B, C, D or E. When replacing a bulb, first remove the lens and/or cover.





Map light



Cargo light



#### WHEELS AND TIRES

## If you have a flat tire, see "Flat tire" (P.6-3). TIRE PRESSURE

#### Tire Pressure Monitoring System (TPMS)

This vehicle is equipped with the Tire Pressure Monitoring System (TPMS). It monitors tire pressure of all tires except the spare. When the low tire pressure warning light is lit, and the CHECK TIRE PRES (pressure) warning message is displayed in the vehicle information display, one or more of your tires is significantly under-inflated.

The TPMS will activate only when the vehicle is driven at speeds above 16 MPH (25 km/h). Also, this system may not detect a sudden drop in tire pressure (for example a flat tire while driving).

For more details, see "Low tire pressure warning light" (P.2-15), "Tire Pressure Monitoring System (TPMS)" (P.5-4) and "Tire Pressure Monitoring System (TPMS)" (P.6-3).

#### Tire inflation pressure

Check the pressure of the tires (including the spare) often and always prior to long distance trips. The recommended tire pressure specifications are shown on the Tire and Loading Information label under the "Cold Tire Pressure" heading. The Tire and Loading Information label is affixed to the driver side center pillar. Tire pressures should be checked regularly because:

- Most tires naturally lose air over time.
- Tires can lose air suddenly when driven over potholes or other objects or if the vehicle strikes a curb while parking.

The tire pressures should be checked when the tires are cold. The tires are considered COLD after the vehicle has been parked for 3 or more hours, or driven less than 1 mile (1.6 km) at moderate speeds.

Incorrect tire pressure, including under inflation, may adversely affect tire life and vehicle handling.


## **A** WARNING

- Improperly inflated tires can fail suddenly and cause an accident.
- The Gross Vehicle Weight rating (GVWR) is located on the F.M.V. S.S./C.M.V.S.S. certification label. The vehicle weight capacity is indicated on the Tire and

Loading Information label. Do not load your vehicle beyond this capacity. Overloading your vehicle may result in reduced tire life, unsafe operating conditions due to premature tire failure, or unfavorable handling characteristics and could also lead to a serious accident. Loading beyond the specified capacity may also result in failure of other vehicle components.

- Before taking a long trip, or whenever you heavily load your vehicle, use a tire pressure gauge to ensure that the tire pressures are at the specified level.
- For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

8-30 Maintenance and do-it-yourself




Tire and Loading Information label

- Seating capacity: The maximum number of occupants that can be seated in the vehicle.
- Vehicle load limit: See "Vehicle loading information" (P.9-14).
- Original size: The size of the tires originally installed on the vehicle at the factory.
- (4) Cold tire pressure: Inflate the tires to this pressure when the tires are cold. Tires are considered COLD after the vehicle has been parked for 3 or more

hours, or driven less than 1 mile (1.6 km) at moderate speeds. The recommended cold tire inflation is set by the manufacturer to provide the best balance of tire wear, vehicle handling, driveability, tire noise, etc., up to the vehicle's GVWR.

- (5) Tire size see "Tire labeling" (P.8-35).
- Spare tire size or compact spare tire size (if so equipped)



#### Checking the tire pressure

- 1. Remove the valve stem cap from the tire.
- Press the pressure gauge squarely onto the valve stem. Do not press too hard or force the valve stem sideways, or air will escape. If the hissing sound of air escaping from the tire is heard while checking the pressure, reposition the gauge to eliminate this leakage.
- 3. Remove the gauge.
- Read the tire pressure on the gauge stem and compare it to the specifica-

- tion shown on the Tire and Loading Information label.
- Add air to the tire as needed. If too much air is added, press the core of the valve stem briefly with the tip of the gauge stem to release pressure. Recheck the pressure and add or release air as needed.
- 6. Install the valve stem cap.
- 7. Check the pressure of all other tires, including the spare.



### **Except for NISMO and NISMO RS models:**

|                     | SIZE   | COLD TIRE INFLATION PRESSURE   |
|---------------------|--|--|
| FRONT ORIGINAL TIRE | P215/55R17 93V   | 230 kPa, 33 PSI (2WD MT<br>models)<br>250 kPa, 36 PSI (2WD CVT<br>models)<br>240 kPa, 34 PSI (AWD<br>models) |
| REAR ORIGINAL TIRE  | P215/55R17 93V   | 230 kPa, 33 PSI (2WD MT<br>models)<br>250 kPa, 36 PSI (2WD CVT<br>models)<br>240 kPa, 34 PSI (AWD<br>models) |
| SPARE TIRE          | T135/80D16 101M (2WD<br>models)<br>T135/90D16 102M (AWD<br>models) | 420 kPa, 60 PSI  |




#### For NISMO models:

|                     | SIZE   | COLD TIRE INFLATION PRESSURE  |
|---------------------|--|---|
| FRONT ORIGINAL TIRE | 225/45R18 95Y  | 230 kPa, 33 PSI (2WD MT<br>models)<br>240 kPa, 35 PSI (AWD<br>models) |
| REAR ORIGINAL TIRE  | 225/45R18 95Y  | 230 kPa, 33 PSI (2WD MT<br>models)<br>240 kPa, 35 PSI (AWD<br>models) |
| SPARE TIRE          | T135/80D16 101M (2WD<br>models)<br>T135/90D16 102M (AWD<br>models) | 420 kPa, 60 PSI   |



#### For NISMO RS models:

|                     | SIZE           | COLD TIRE INFLATION PRESSURE  |
|---------------------|----------------|---|
| FRONT ORIGINAL TIRE | 225/45R18 95Y  | 230 kPa, 33 PSI (2WD MT<br>models)<br>240 kPa, 35 PSI (AWD<br>models) |
| REAR ORIGINAL TIRE  | 225/45R18 95Y  | 230 kPa, 33 PSI (2WD MT<br>models)<br>240 kPa, 35 PSI (AWD<br>models) |
| SPARE TIRE          | T135/70D17 92M | 420 kPa, 60 PSI   |




Example

#### TIRE LABELING


Federal law requires tire manufacturers to place standardized information on the sidewall of all tires. This information identifies and describes the fundamental characteristics of the tire and also provides the tire identification number (TIN) for safety standard certification. The TIN can be used to identify the tire in case of a recall.





- Example Tire size (example: P215/60R16 94H)
- 1. P: The "P" indicates the tire is designed for passenger vehicles. (Not all tires have this information.)
- 2. Three-digit number (215): This number gives the width in millimeters of the tire from sidewall edge to sidewall edge.
- 3. Two-digit number (60): This number, known as the aspect ratio, gives the tire's ratio of height to width.
- 4. R: The "R" stands for radial.

- 5. Two-digit number (16): This number is the wheel or rim diameter in inches.
- 6. Two- or three-digit number (94): This number is the tire's load index. It is a measurement of how much weight each tire can support. You may not find this information on all tires because it is not required by law.
- 7. H: Tire speed rating. You should not drive the vehicle faster than the tire speed rating.



Example

- (2) TIN (Tire Identification Number) for a new tire (example: DOT XX XX XXX XXXX)
- 1. DOT: Abbreviation for the "Department of Transportation". The symbol can be placed above, below or to the left or right of the Tire Identification Number.
- 2. Two-digit code: Manufacturer's identification mark
- 3. Two-digit code: Tire size
- 4. Three-digit code: Tire type code (Optional)



- 5. Three-digit code: Date of Manufacture
- 6. Four numbers represent the week and year the tire was built. For example, the numbers 3103 means the 31st week of 2003. If these numbers are missing. then look on the other sidewall of the tire.
- 3 Tire ply composition and material

The number of layers or plies of rubbercoated fabric in the tire.

Tire manufacturers also must indicate the materials in the tire, which include steel, nylon, polyester, and others.

Maximum permissible inflation pressure

This number is the greatest amount of air pressure that should be put in the tire. Do not exceed the maximum permissible inflation pressure.

Maximum load rating

This number indicates the maximum load in kilograms and pounds that can be carried by the tire. When replacing the tires on the vehicle, always use a tire that has the same load rating as the factory installed tire.

- (6) Term of "tubeless" or "tube type" Indicates whether the tire requires an inner tube ("tube type") or not ("tubeless").
- 7 The word "radial"

The word "radial" is shown, if the tire has radial structure.

8 Manufacturer or brand name Manufacturer or brand name is shown.

#### Other tire-related terminology:

In addition to the many terms that are defined throughout this section. Intended Outboard Sidewall is (1) the sidewall that contains a whitewall, bears white lettering or bears manufacturer, brand and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or (2) the outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle.

#### TYPES OF TIRES



- When changing or replacing tires, be sure all four tires are of the same type (Example: Summer, All Season or Snow) and construction. A NISSAN dealer may be able to help you with information about tire type, size, speed rating and availability.
- Replacement tires may have a lower speed rating than the factory equipped tires, and may not match the potential maximum vehicle speed. Never exceed the maximum speed rating of the tire.
- Replacing tires with those not originally specified by NISSAN could affect the proper operation of the TPMS.
- For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.



#### All season tires

NISSAN specifies all season tires on some models to provide good performance all year, including snowy and icy road conditions. All Season tires are identified by ALL SEASON and/or M&S (Mud and Snow) on the tire sidewall. Snow tires have better snow traction than All Season tires and may be more appropriate in some areas.

#### Summer tires

NISSAN specifies summer tires on some models to provide superior performance on dry roads. Summer tire performance is substantially reduced in snow and ice. Summer tires do not have the tire traction rating M&S on the tire sidewall.

If you plan to operate your vehicle in snowy or icy conditions, NISSAN recommends the use of SNOW tires or ALL SEASON tires on all four wheels.

#### Snow tires

If snow tires are needed, it is necessary to select tires equivalent in size and load rating to the original equipment tires. If you do not, it can adversely affect the safety and handling of your vehicle.

Generally, snow tires will have lower speed ratings than factory equipped tires and may not

match the potential maximum vehicle speed. Never exceed the maximum speed rating of the tire.

If you install snow tires, they must be the same size, brand, construction and tread pattern on all four wheels.

For additional traction on icy roads, studded tires may be used. However, some U.S. states and Canadian provinces prohibit their use. Check local, state and provincial laws before installing studded tires. Skid and traction capabilities of studded snow tires, on wet or dry surfaces, may be poorer than that of non-studded snow tires.

#### TIRE CHAINS


Use of tire chains may be prohibited according to location. Check the local laws before installing tire chains. When installing tire chains, make sure they are the proper size for the tires on your vehicle and are installed according to the chain manufacturer's suggestions. Use only SAE Class S chains. Class "S" chains are used on vehicles with restricted tire to vehicle clearance. Vehicles that can use Class "S" chains are designed to meet the SAE standard minimum clearances between the tire and the closest vehicle suspension or body component required to accommodate the use of a winter traction device (tire chains or cables). The minimum

clearances are determined using the factory equipped tire size. Other types may damage your vehicle. Use chain tensioners when recommended by the tire chain manufacturer to ensure a tight fit. Loose end links of the tire chain must be secured or removed to prevent the possibility of whipping action damage to the fenders or underbody. If possible, avoid fully loading your vehicle when using tire chains. In addition, drive at a reduced speed. Otherwise, your vehicle may be damaged and/or vehicle handling and performance may be adversely affected.

## Tire chains must be installed only on the front wheels and not on the rear wheels.

Never install tire chains on a TEMPORARY USE ONLY spare tire.

Do not use tire chains on dry roads. Driving with tire chains in such conditions can cause damage to the various mechanisms of the vehicle due to some overstress.



#### CHANGING WHEELS AND TIRES

Tire rotation

NISSAN recommends rotating the tires every 5,000 miles (8,000 km). (See "Flat tire" (P.6-3) for tire replacing procedures.)

As soon as possible, tighten the wheel nuts to the specified torque with a torque wrench.

Wheel nut tightening torque: 80 ft-lb (108 N·m)


The wheel nuts must be kept tigh-

tened to the specification at all times. It is recommended that wheel nuts be tightened to the specification at each tire rotation interval.



### **WARNING**

- After rotating the tires, check and adjust the tire pressure.
- Retighten the wheel nuts when the vehicle has been driven for 600 miles (1,000 km) (also in cases of a flat tire, etc.).
- Do not include the spare tire or any other small size spare tire in the tire rotation.
- For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.



- Wear indicator location mark

Tire wear and damage



### **WARNING**

- Tires should be periodically inspected for wear, cracking, bulging or objects caught in the tread. If excessive wear, cracks, bulging or deep cuts are found. the tire(s) should be replaced.
- The original tires have built-in tread wear indicators. When

Maintenance and do-it-yourself 8-39



- wear indicators are visible, the tire(s) should be replaced.
- Tires degrade with age and use. Have tires, including the spare, over 6 years old checked by a qualified technician, because some tire damage may not be obvious. Replace the tires as necessary to prevent tire failure and possible personal injury.
- Improper service of the spare tire may result in serious personal injury. If it is necessary to repair the spare tire, contact a NISSAN dealer.
- For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

### Replacing wheels and tires

When replacing a tire, use the same size, tread design, speed rating and load carrying capacity as originally equipped. (See "Specifications" (P.9-8) for recommended types and sizes of tires and wheels.)



### **WARNING**

- The use of tires other than those. recommended or the mixed use of tires of different brands, construction (bias, bias-belted or radial), or tread patterns can adversely affect the ride, braking, handling, ground clearance, body-to-tire clearance, tire chain clearance, speedometer calibration, headlight aim and bumper height. Some of these effects may lead to accidents and could result in serious personal injury.
- For Two-Wheel Drive (2WD) models, if your vehicle was originally equipped with 4 tires that were the same size and you are only replacing 2 of the 4 tires, install the new tires on the rear axle. Placing new tires on the front axle may cause loss of vehicle control in some

- driving conditions and cause an accident and personal injury.
- If the wheels are changed for any reason, always replace with wheels which have the same off-set dimension. Wheels of a different off-set could cause premature tire wear, degrade vehicle handling characteristics and/or interference with the brake discs/drums. Such interference can lead to decreased braking efficiency and/or early brake pad/ shoe wear. See "Wheels and tires" (P.9-8) of this manual for wheel offset dimensions.
- When a spare tire is mounted or a wheel is replaced, the TPMS will not function and the low tire pressure warning light will flash for approximately 1 minute. The light will remain on after 1 minute. Contact vour NISSAN dealer as soon as possible for tire replacement and/ or system resetting.
- Replacing tires with those not originally specified by NISSAN could affect the proper operation of the TPMS.



- Do not install a damaged or deformed wheel or tire even if it has been repaired. Such wheels or tires could have structural damage and could fail without warning.
- The use of retread tire is not recommended.
- For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

All-Wheel Drive (AWD) models



 Always use tires of the same size, brand, construction (bias, biasbelted or radial), and tread pattern on all four wheels. Failure to do so may result in a circumference difference between tires on the front and rear axles which will cause excessive tire wear and may damage the transmission, transfer case and rear differential gears. Only use spare tires specified for each AWD model.

If excessive tire wear is found, it is recommended that all four tires be replaced with tires of the same size, brand, construction and tread pattern. The tire pressure and wheel alignment should also be checked and corrected as necessary. Contact a NISSAN dealer.

### Wheel balance

Unbalanced wheels may affect vehicle handling and tire life. Even with regular use, wheels can get out of balance. Therefore, they should be balanced as required.

Wheel balance service should be performed with the wheels off the vehicle. Spin balancing the wheels on the vehicle could lead to mechanical damage.

For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the Warranty Information Booklet.

#### Care of wheels

See "Cleaning exterior" (P.7-2) for details about care of the wheels.

### Spare tire

When a spare tire is mounted (TEMPORARY USE ONLY), the TPMS will not function.

Observe the following precautions if the TEM-PORARY USE ONLY spare tire must be used, otherwise your vehicle could be damaged or involved in an accident.



- The TEMPORARY USE ONLY spare tire should be used for emergency use. It should be replaced with the standard tire at the first opportunity to avoid possible tire or differential damage.
- Drive carefully while the TEMPOR-ARY USE ONLY spare tire is installed. Avoid sharp turns and abrupt braking while driving.
- Periodically check spare tire inflation pressure. Always keep the pressure of the TEMPORARY USE ONLY spare tire at 60 psi (420 kPa, 4.2 bar).



- With the TEMPORARY USE ONLY spare tire installed do not drive your vehicle at speeds faster than 50 MPH (80 km/h).
- When driving on roads covered with snow or ice, the TEMPORARY USE ONLY spare tire should be used on the rear wheels and original tire used on the front wheels (drive wheels). Use tire chains only on the front (original) tires.
- Tire tread of the TEMPORARY USE ONLY spare tire will wear at a faster rate than the standard tire. Replace the spare tire as soon as the tread wear indicators appear.
- Do not use the spare tire on other vehicles.
- Do not use more than one spare tire at the same time.

# **A** CAUTION

 Do not use tire chains on a TEM-PORARY USE ONLY spare tire. Tire chains will not fit properly and may cause damage to the vehicle. Because the TEMPORARY USE ONLY spare tire is smaller than the original tire, ground clearance is reduced. To avoid damage to the vehicle, do not drive over obstacles. Also do not drive the vehicle through an automatic car wash since it may get caught.







# 9 Technical and consumer information

| Capacities and recommended fuel/lubricants  Fuel information  Engine oil and oil filter recommendation | 9-4          |
|--|--------------|
| Air conditioning system refrigerant and lubricant recommendations                                      |              |
| Engine   | 9-8          |
| Dimensions and weights   |              |
| When traveling or registering your vehicle in another country  | 9-9<br>9-10  |
| Vehicle Identification Number (VIN) plate  | 9-10         |
| Engine serial number   | 9-10<br>9-10 |
|  | 9-11<br>9-11 |
| 3  | 9-11<br>9-12 |

| Installing front license plate                  | 9-1 |
|---|-----|
| Vehicle loading information                     | 9-1 |
| Terms   | 9-1 |
| Vehicle load capacity                           | 9-1 |
| Loading tips                                    | 9-1 |
| Measurement of weights                          | 9-1 |
| Towing a trailer                                | 9-1 |
| Flat towing                                     | 9-1 |
| Continuously Variable Transmission (CVT)        | 9-1 |
| Manual Transmission                             | 9-1 |
| Uniform tire quality grading                    | 9-1 |
| Treadwear                                       | 9-1 |
| Traction AA, A, B and C                         | 9-1 |
| Temperature A, B and C                          | 9-1 |
| Emission control system warranty                | 9-1 |
| Reporting safety defects                        | 9-1 |
| Readiness for Inspection/Maintenance (I/M) test | 9-2 |
| Event Data Recorders (EDR)                      | 9-2 |
| Owner's manual/service manual order information | 9-2 |
|   |     |



### **CAPACITIES AND RECOMMENDED FUEL/LUBRICANTS**

The following are approximate capacities. The actual refill capacities may be a little different. When refilling, follow the procedure instructed in the "8. Maintenance and do-it-yourself" section to determine the proper refill capacity.

|                                |                           |           | C          | apacity (Approxin | nate) | Recommended specifications  |
|--------------------------------|---------------------------|-----------|------------|-------------------|-------|---|
|                                |                           |           | US measure | Imp measure       | Liter |   |
| Fuel                           |                           | 2WD model | 13-1/4 gal | 11 gal            | 50    | See "Fuel information" (P.9-4).   |
| i dei                          |                           | AWD model | 11-7/8 gal | 9-7/8 gal         | 45    | , ,   |
|                                | With oil filter change    |           | 4-3/4 qt   | 4 qt              | 4.5   | For additional information, see "Engine oil" (P.8-8) for changing   |
| Engine oil<br>Drain and refill | Without oil filter change |           | 4-1/2 qt   | 3-3/4 qt          | 4.3   | engine oil.  NISSAN recommends Genuine NISSAN Ester Oil available at a NISSAN dealer.  Genuine NISSAN engine oil or equivalent Engine oil with API Certification Mark Viscosity SAE 5W-30 For additional information, see "Engine oil and oil filter recommendation" (P.9-6).   |
| Cooling system                 |                           |           |            |                   |       |   |
|                                | NACHL                     | CVT model | 8-5/8 qt   | 7-1/8 qt          | 8.1   | De district Commiss NICCANII and I to Additional Control (Children  |
|                                | With reservoir            | MT model  | 8-3/8 qt   | 7 qt              | 7.9   | Pre-diluted Genuine NISSAN Long Life Antifreeze/Coolant (blue) or equivalent  |
|                                | Reservoir                 |           | 5/8 qt     | 1/2 qt            | 0.6   | equivalent  |
| Continuously Variable T        | ransmission (CVT) fluid   |           | -          | -                 | -     | Use only Genuine NISSAN CVT Fluid NS-2. Using transmission fluid other than Genuine NISSAN CVT Fluid NS-2 will damage the CVT, which is not covered by the NISSAN new vehicle limited warranty.     Genuine NISSAN CVT Fluid NS-2   |
| Manual Transmission (N         | /IT) gear oil             |           | -          | -                 | -     | For NISMO RS models Genuine NISSAN Manual Transmission Fluid (MTF) HQ Multi 75W-85 or equivalent If Genuine NISSAN Manual Transmission Fluid (MTF) HQ Multi 75W-85 is hard to obtain, API GL-4, Viscosity SAE 75W-85 may be used as a temporary replacement. However, use Genuine NISSAN gear oil as soon as it is available.  Except for NISMO RS models Genuine NISSAN Manual Transmission Fluid (MTF) TL/JR Type 75W-80 or equivalent If Genuine NISSAN Manual Transmission Fluid (MTF) TL/JR Type is not available, API GL-4+, Viscosity SAE 75W-80 may be used as a temporary replacement. However, use Genuine NISSAN Manual Transmission Fluid (MTF) TL/JR Type is not svailable, API GL-4+, Viscosity SAE 75W-80 may be used as a |

|                                     | С          | apacity (Approxin                             | nate) | Recommended specifications   |
|-------------------------------------|------------|---|-------|--|
|                                     | US measure | Imp measure                                   | Liter |  |
| Differential gear oil               | -          | ı   | ı     | For hot climates, viscosity SAE 90 is suitable for ambient temperatures above 32°F (0°C). Genuine NISSAN Differential Oil Hypoid Super GL-5 80W-90 or API GL-5, Viscosity SAE 80W-90  For hot climates, viscosity SAE 90W-90 |
| Transfer fluid                      | -          | -   | -     | Genuine NISSAN Differential Oil Hypoid Super GL-5 80W-90 or API GL-5, Viscosity SAE 80W-90   |
| Brake and clutch fluid              |            | per oil level acco<br>he "8. Maintenand<br>n. |       | Genuine NISSAN Super Heavy Duty Brake Fluid* or equivalent DOT 3 *: Available in mainland U.S.A. through a NISSAN dealer.  |
| Multi-purpose grease                | _          | _   | -     | NLGI No. 2 (Lithium soap base)   |
| Air conditioning system refrigerant | _          | _   | -     | For additional information, see "Vehicle identification" (P.9-10) for air conditioner specification label.     HFC-134a (R-134a)   |
| Air conditioning system lubricants  | _          | _   | _     | NISSAN A/C System Oil Type R or exact equivalent   |
| Window washer fluid                 | 1-1/4 gal  | 1 gal   | 4.5   | Genuine NISSAN Windshield Washer Concentrate Cleaner & Antifreeze or equivalent  |



### **FUEL INFORMATION**

### **Except for NISMO RS models:**

NISSAN recommends the use of unleaded premium gasoline with an octane rating of at least 91 AKI (Anti-Knock Index) number (Research octane number 96).

If unleaded premium gasoline is not available, you may use unleaded regular gasoline with an octane rating of at least 87 AKI number (Research octane number 91), but you may notice a decrease in performance.

#### For NISMO RS models:

Use unleaded premium gasoline with an octane rating of at least 91 AKI (Anti-Knock Index) number (Research octane number 96).

If unleaded premium gasoline is not available, unleaded regular gasoline with an octane rating of at least 87 AKI number (Research octane number 91) may be temporarily used, but only under the following precautions:

- Have the fuel tank filled only partially with unleaded regular gasoline, and fill up with unleaded premium gasoline as soon as possible.
- Avoid full throttle driving and abrupt acceleration.

Use unleaded premium gasoline for maximum vehicle performance.

9-4 Technical and consumer information



- Using a fuel other than that specified could adversely affect the emission control system, and may also affect warranty coverage.
- Under no circumstances should a leaded gasoline be used, because this will damage the three-way catalyst.
- Do not use E-15 or E-85 fuel in your vehicle. Your vehicle is not designed to run on E-15 or E-85 fuel. Using E-15 or E-85 fuel in a vehicle not specifically designed for E-15 or E-85 fuel can adversely affect the emission control devices and systems of the vehicle. Damage caused by such fuel is not covered by the NISSAN new vehicle limited warranty.
- U.S. government regulations require ethanol dispensing pumps to be identified by a small, square, orange and black label with the common abbreviation or the appropriate percentage for that region.



### Gasoline specifications

NISSAN recommends using gasoline that meets the World-Wide Fuel Charter (WWFC) specifications where it is available. Many of the automobile manufacturers developed this specification to improve emission control system and vehicle performance. Ask your service station manager if the gasoline meets the WWFC specifications.

### Reformulated gasoline

Some fuel suppliers are now producing reformulated gasolines. These gasolines are specially designed to reduce vehicle emissions. NISSAN supports efforts towards cleaner air and suggests that you use reformulated gasoline when available.

### Gasoline containing oxygenates

Some fuel suppliers sell gasoline containing oxygenates such as ethanol, MTBE and methanol with or without advertising their presence. NISSAN does not recommend the use of fuels of which the oxygenate content and the fuel compatibility for your NISSAN cannot be readily determined. If in doubt, ask your service station manager.

If you use oxygenate-blend gasoline, please take the following precautions as the usage of such fuels may cause vehicle performance problems and/or fuel system damage.

- The fuel should be unleaded and have an octane rating no lower than that recommended for unleaded gasoline.
- If an oxygenate-blend, other than methanol blend is used, it should contain no more than 10% oxygenate. (MTBE may, however, be added up to 15%.)
- E-15 fuel contains more than 10% oxygenate. E-15 fuel will adversely affect the emission control devices and systems of the vehicle and should not be used. Damage caused by such fuel is not covered by the NISSAN new vehicle limited warranty.
- If a methanol blend is used, it should contain no more than 5% methanol (methyl alcohol, wood alcohol). It should also contain a suitable amount of appropriate cosolvents and corrosion inhibitors. If not properly formulated with appropriate cosolvents and corrosion inhibitors, such methanol blends may cause fuel system damage and/or vehicle performance problems. At this time, sufficient data is not available to ensure that all methanol blends are suitable for use in NISSAN

#### vehicles.

If any driveability problems such as engine stalling and difficult hot-starting are experienced after using oxygenate-blend fuels, immediately change to a non-oxygenate fuel or a fuel with a low blend of MTBE.

# Take care not to spill gasoline during refueling. Gasoline containing oxygenates can cause paint damage.

#### E-15 fuel

E-15 fuel is a mixture of approximately 15% fuel ethanol and 85% unleaded gasoline. E-15 can only be used in vehicles designed to run on E-15 fuel. Do not use E-15 in your vehicle. U.S. government regulations require fuel ethanol dispensing pumps to be identified with small, square, orange and black label with the common abbreviation or the appropriate percentage for that region.

### E-85 fuel

E-85 fuel is a mixture of approximately 85% fuel ethanol and 15% unleaded gasoline. E-85 can only be used in a Flexible Fuel Vehicle (FFV). Do not use E-85 fuel in your vehicle. U.S. government regulations require fuel ethanol dispensing pumps to be identified by a small, square, orange and black label with the common abbreviation or the appropriate percentage for

that region.

### Aftermarket fuel additives


NISSAN does not recommend the use of any aftermarket fuel additives (for example, fuel injector cleaner, octane booster, intake valve deposit removers, etc.) which are sold commercially. Many of these additives intended for gum, varnish or deposit removal may contain active solvent or similar ingredients that can be harmful to the fuel system and engine.

### Octane rating tips

Using unleaded gasoline with an octane rating lower than recommended can cause persistent, heavy "spark knock". (Spark knock is a metallic rapping noise.) If severe, this can lead to engine damage. If you detect a persistent heavy spark knock even when using gasoline of the stated octane rating, or if you hear steady spark knock while holding a steady speed on level roads, have a NISSAN dealer correct the condition is misuse of the vehicle, for which NISSAN is not responsible.

Incorrect ignition timing will result in spark knock, after-run and/or overheating, which may cause excessive fuel consumption or engine damage. If any of the above symptoms are encountered, have your vehicle checked at a NISSAN dealer.

However, now and then you may notice light spark knock for a short time while accelerating or driving up hills. This is not a cause for concern, because you get the greatest fuel benefit when there is light spark knock for a short time under heavy engine load.



- API certification mark
- 2. API service symbol

### ENGINE OIL AND OIL FILTER RE-COMMENDATION

### Selecting the correct oil

It is essential to choose the correct grade, quality, and viscosity engine oil to ensure satisfactory engine life and performance, see "Capacities and recommended fuel/lubricants" (P.9-2). NISSAN recommends the use of an energy conserving oil in order to improve fuel economy.

Select only engine oils that meet the American Petroleum Institute (API) certification or International Lubricant Standardization and Approval Committee (ILSAC) certification and SAE viscosity standard. These oils have the API certification mark on the front of the container. Oils which do not have the specified quality label should not be used as they could cause engine damage.

#### Oil additives

NISSAN does not recommend the use of oil additives. The use of an oil additive is not necessary when the proper oil type is used and maintenance intervals are followed.

Oil which may contain foreign matter or has been previously used should not be used.



### Oil viscosity

The engine oil viscosity or thickness changes with temperature. Because of this, it is important to select the engine oil viscosity based on the temperatures at which the vehicle will be operated before the next oil change. Choosing an oil viscosity other than that recommended could cause serious engine damage.

### Selecting the correct oil filter

Your new NISSAN vehicle is equipped with a high-quality genuine NISSAN oil filter. When replacing, use a genuine NISSAN oil filter or its equivalent for the reason described in "Change intervals".

### Change intervals

The oil and oil filter change intervals for your engine are based on the use of the specified quality oils and filters. Using an engine oil and filter other than the specified quality, or exceeding recommended oil and filter change intervals could reduce engine life. Damage to the engine caused by improper maintenance or use of incorrect oil and filter quality and/or viscosity is not covered by the NISSAN new vehicle limited warranty.

Your engine was filled with a high quality engine oil when it was built. You do not have to change the oil before the first recommended change interval. Oil and filter change intervals depend upon how you use your vehicle.

Operation under the following conditions may require more frequent oil and filter changes.

- · repeated short distance driving at cold outside temperatures
- driving in dusty conditions
- extensive idling
- stop and go commuting

Refer to the "NISSAN Service and Maintenance Guide" for the maintenance schedule.

AIR CONDITIONING SYSTEM RE-FRIGERANT AND LUBRICANT RE-COMMENDATIONS

The air conditioning system in your NISSAN vehicle must be charged with the refrigerant HFC-134a (R-134a) and the oil, NISSAN A/C system oil Type R or the exact equivalents.

# A CAUTION

The use of any other refrigerant or oil will cause severe damage to the air conditioning system and will require the replacement of all air conditioner system components.

The refrigerant HFC-134a (R-134a) in your NISSAN vehicle will not harm the earth's ozone laver. Although this refrigerant does not affect the earth's atmosphere, certain governmental regulations require the recovery and recycling of any refrigerant during automotive air conditioning system service. A NISSAN dealer has the trained technicians and equipment needed to recover and recycle your air conditioning system refrigerant.

Contact a NISSAN dealer when servicing your air conditioning system.



### **SPECIFICATIONS**

### **ENGINE**

| Model                      |                          | MR16DDT                      |  |
|----------------------------|--------------------------|------------------------------|--|
| Туре                       |                          | Gasoline, 4-cycle, DOHC      |  |
| Cylinder arrangement       |                          | 4-cylinder, in-line          |  |
| Bore × Stroke              | in (mm)                  | 3.138 × 3.193 (79.7 × 81.1)  |  |
| Displacement               | cu in (cm <sup>3</sup> ) | 98.78 (1,618)                |  |
| Firing order               |                          | 1-3-4-2                      |  |
| Idle speed                 | rpm                      | No adjustment is necessary.  |  |
| Ignition timing (B.T.D.C.) | degree/rpm               | ino adjustment is necessary. |  |
| Spark plug                 | Standard                 | DILKAR7C9H                   |  |
| Spark plug gap (Normal)    | in (mm)                  | 0.035 (0.9)                  |  |
| Camshaft operation         |                          | Timing chain                 |  |

This spark ignition system complies with the Canadian standard ICES-002.

### WHEELS AND TIRES

### Road wheel

|                   | ,01                |         |                |
|-------------------|--------------------|---------|----------------|
| Туре              |                    | Size    | Offset in (mm) |
| Conven-<br>tional |                    | 17 × 7J | 1.85 (47)      |
|                   | NISMO<br>models    | 18 × 7J | 1.85 (47)      |
| Spare             |                    | 16 × 4T | 1.18 (30)      |
|                   | NISMO RS<br>models | 17 × 4T | 1.18 (30)      |



#### Tire

| Туре              |                    | Size                        | Pressure<br>PSI (kPa)<br>[Cold]        |
|-------------------|--------------------|-----------------------------|--|
| Conven-<br>tional |                    | P215/55-<br>R17 93V         | 33 (230)*1<br>36 (250)*2<br>34 (240)*3 |
|                   | NISMO<br>models    | 225/45R18<br>95Y            | 33 (230)*1<br>35 (240)*3               |
|                   |                    | T135/80-<br>D16<br>101M*1*2 |  |
| Spare             |                    | T135/90-<br>D16<br>102M*3   | 60 (420)                               |
|                   | NISMO RS<br>models | T135/70-<br>D17 92M         | •                                      |

2WD MT model

2WD CVT model

AWD model

### DIMENSIONS AND WEIGHTS

| in (mm) | 162.8 (4,135)*1                         |
|---------|---|
|         | 162.4 (4,125)*2                         |
|         | 164.0 (4,165)*3                         |
|         | 163.8 (4,160)*4                         |
| in (mm) | 69.5 (1,765)                            |
|         | 69.7(1,770)*5                           |
| in (mm) | 61.8 (1,570)                            |
| in (mm) | 60.0 (1,525)                            |
| in (mm) | 60.0 (1,525)*6                          |
|         | 59.3 (1,505)*7                          |
| in (mm) | 99.6 (2,530)                            |
|         |   |
| lb (kg) |   |
| ٠ ٠,    | See the F.M.V.S.S. or                   |
|         | C.M.V.S.S. certification                |
|         | label on the driver's                   |
|         | side center pillar.                     |
| lb (kg) |   |
| lb (ka) |   |
|         | in (mm) in (mm) in (mm) in (mm) in (mm) |

\*1: With front license plate bracket

Without front license plate bracket

With front license plate bracket (NISMO models)

Without front license plate bracket (NISMO models)

\*5: NISMO models for 2WD model

for AWD model



### WHEN TRAVELING OR REGISTERING YOUR VEHICLE IN ANOTHER COUNTRY

When planning to travel in another country, you should first find out if the fuel available is suitable for your vehicle's engine.


Using fuel with an octane rating that is too low may cause engine damage. All gasoline vehicles must be operated with unleaded gasoline. Therefore, avoid taking your vehicle to areas where appropriate fuel is not available.

When transferring the registration of your vehicle to another country, state, province or district, it may be necessary to modify the vehicle to meet local laws and regulations.

The laws and regulations for motor vehicle emission control and safety standards vary according to the country, state, province or district: therefore, vehicle specifications may differ.


When any vehicle is to be taken into another country, state, province or district and registered, its modifications, transportation, and registration are the responsibility of the user. NISSAN is not responsible for any inconvenience that may result.

### **VEHICLE IDENTIFICATION**






The vehicle identification number plate is attached as shown. This number is the identification for your vehicle and is used in the vehicle registration.



VEHICLE IDENTIFICATION NUMBER (chassis number)

The vehicle identification number is located as shown.


Remove the cover to access the number.



**ENGINE SERIAL NUMBER** 


The number is stamped on the engine as shown.






F.M.V.S.S./C.M.V.S.S. CERTIFICATION LABEL

The Federal/Canadian Motor Vehicle Safety Standards (F.M.V.S.S./C.M.V.S.S.) certification label is affixed as shown. This label contains valuable vehicle information, such as: Gross Vehicle Weight Ratings (GVWR), Gross Axle Weight Rating (GAWR), month and year of manufacture, Vehicle Identification Number (VIN), etc. Review it carefully.



**EMISSION CONTROL INFORMATION LABEL** 


The emission control information label is attached to the underside of the hood as shown.



TIRE AND LOADING INFORMATION LABEL

The cold tire pressure is shown on the Tire and Loading Information label affixed to the pillar as shown.






AIR CONDITIONER SPECIFICATION **LABEL** 

The air conditioner specification label is attached to the engine compartment as shown.



#### **INSTALLING FRONT LICENSE PLATE**





Use the following steps to mount the license plate:

Before mounting the license plate, confirm that the following parts are enclosed in the plastic bag.

- License plate bracket
- J-nut  $\times$  2
- Screw × 2
- Screw grommet × 2
- 1. Park the vehicle on flat, level ground.
- Locate the center position (A) as illustrated.
   Make sure the side end surface of the license plate bracket is aligned with the bumper (B).
- 3. Mark the center of the holes © with a felt-tip pen.
- Carefully drill the two pilot holes using a 0.39 in (10 mm) drill bit at the marked locations. (Be sure that the drill only goes through the bumper fascia.)
- 5. Insert grommets into the hole on the fascia.
- Insert a flat-blade screwdriver into the grommet hole to add a 90° turn onto the part (D).
- Insert a J-nut into the license plate bracket before placing the license plate bracket on the fascia.

### VEHICLE LOADING INFORMATION

- Install the license plate bracket with the screws.
- 9. Install the license plate with bolts that are not longer than 0.55 in (14 mm).



- It is extremely dangerous to ride in a cargo area inside the vehicle. In a collision, people riding in these areas are more likely to be seriously injured or killed.
- Do not allow people to ride in any area of your vehicle that is not equipped with seats and seat belts.
- Be sure everyone in your vehicle is in a seat and using a seat belt properly.

### **TERMS**

It is important to familiarize yourself with the following terms before loading your vehicle:

 Curb Weight (actual weight of your vehicle) - vehicle weight including: standard and optional equipment, fluids, emergency tools, and spare tire assembly. This weight does not include passengers and cargo.



- GVW (Gross Vehicle Weight) curb weight plus the combined weight of passengers and cargo.
- GVWR (Gross Vehicle Weight Rating)

   maximum total combined weight of the unloaded vehicle, passengers, luggage, hitch, trailer tongue load and any other optional equipment. This information is located on the F.M.V.S.S./C.M.V.S.S. label.
- GAWR (Gross Axle Weight Rating) maximum weight (load) limit specified for the front or rear axle. This information is located on the F.M.V.S.S./C.M.V. S.S. label.
- GCWR (Gross Combined Weight Rating) The maximum total weight rating of the vehicle, passengers, cargo, and trailer.
- Vehicle Capacity Weight, Load limit,
   Total load capacity maximum total
   weight limit specified of the load
   (passengers and cargo) for the vehicle.
   This is the maximum combined weight
   of occupants and cargo that can be
   loaded into the vehicle. If the vehicle is
   used to tow a trailer, the trailer tongue


weight must be included as part of the cargo load. This information is located on the Tire and Loading Information label.

 Cargo capacity - permissible weight of cargo, the subtracted weight of occupants from the load limit.

### VEHICLE LOAD CAPACITY

Do not exceed the load limit of your vehicle shown as "The combined weight of occupants and cargo" on the Tire and Loading Information label. Do not exceed the number of occupants shown as "Seating Capacity" on the Tire and Loading Information label.

To get "the combined weight of occupants and cargo", add the weight of all occupants, then add the total luggage weight. Examples are shown in the following illustration.



Steps for determining correct load limit

- Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs" on your vehicle's placard.
- Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.



- 4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the XXX amount equals 1400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1400 750 (5 x 150) = 650 lbs) or (640 340 (5 x 70) = 300 kg.)
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.

Before driving a loaded vehicle, confirm that you do not exceed the Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR) for your vehicle. (See "Measurement of weights" (P.9-16).) Also check tires for proper inflation pressures. See the Tire and Loading Information label.

#### LOADING TIPS

- The GVW must not exceed GVWR or GAWR as specified on the F.M.V.S.S./ C.M.V.S.S. certification label.
- Do not load the front and rear axle to the GAWR. Doing so will exceed the GVWR.

# **A** WARNING

- Properly secure all cargo with ropes or straps to help prevent it from sliding or shifting. Do not place cargo higher than the seatbacks. In a sudden stop or collision, unsecured cargo could cause personal injury.
- Do not load your vehicle any heavier than the GVWR or the maximum front and rear GAWRs. If you do, parts of your vehicle can break, tire damage could occur, or it can change the way your vehicle handles. This could result in loss of control and cause personal injury.

Overloading not only can shorten the life of your vehicle and the tire, but can cause unsafe vehicle handling and longer braking distances. This may cause a premature tire failure, which could result in a serious accident and personal injury. Failures caused by overloading are not covered by the vehicle's warranty.

### MEASUREMENT OF WEIGHTS

Secure loose items to prevent weight shifts that could affect the balance of your vehicle. When the vehicle is loaded, drive to a scale and weigh the front and the rear wheels separately to determine axle loads. Individual axle loads should not exceed either of the Gross Axle Weight Ratings (GAWR). The total of the axle loads should not exceed the Gross Vehicle Weight Rating (GVWR). These ratings are given on the vehicle certification label. If weight ratings are exceeded, move or remove items to bring all weights below the ratings.



### **TOWING A TRAILER**

Do not tow a trailer with your vehicle.

#### **FLAT TOWING**

Towing your vehicle with all four wheels on the ground is sometimes called flat towing. This method is sometimes used when towing a vehicle behind a recreational vehicle, such as a motor home.



### A CAUTION

- Failure to follow these guidelines can result in severe transmission damage.
- Whenever flat towing your vehicle. always tow forward, never backward.
- DO NOT tow any Continuously Variable Transmission (CVT) vehicle with all four wheels on the ground (flat towing). Doing so WILL DA-MAGE internal transmission parts due to lack of transmission lubrication.
- DO NOT tow an All-Wheel Drive (AWD) vehicle with any of the wheels on the ground. Doing so may cause serious and expensive damage to the powertrain.
- For emergency towing procedures refer to "Towing your vehicle" (P.6-



### 12).

### CONTINUOUSLY VARIABLE TRANS-MISSION (CVT)

### All-Wheel Drive (AWD) models:

Do not tow an AWD vehicle with any of the wheels on the ground.

### Two-Wheel Drive (2WD) models:

To tow a vehicle equipped with a Continuously Variable Transmission (CVT), an appropriate vehicle dolly **MUST** be placed under the towed vehicle's driving wheels. Always follow the dolly manufacturer's recommendations when using their product.

#### MANUAL TRANSMISSION

- Always tow with the manual transmission in Neutral.
- Your vehicle speed should never exceed 70 MPH (112 km/h) when flat towing your vehicle.
- After towing 500 miles (805 km), start and idle the engine with the transmission in Neutral for two minutes. Failure to idle the engine after every 500 miles (805 km) of towing may cause damage to the transmission's internal parts.

### UNIFORM TIRE QUALITY GRADING

DOT (Department Of Transportation) Quality Grades: All passenger car tires must conform to federal safety requirements in addition to these grades.

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width. For example:

### Treadwear 200 Traction AA Temperature A **TREADWEAR**

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half

(1 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

### TRACTION AA, A, B AND C

The traction grades, from highest to lowest, are AA, A, B and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.



### **WARNING**

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

### TEMPERATURE A. B AND C

The temperature grades A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.



### **WARNING**

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, under-inflation, or excessive loading, either separately or in combination, can cause heat build-up and possible tire failure.



# EMISSION CONTROL SYSTEM WARRANTY

Your NISSAN is covered by the following emission warranties.

#### For USA:

- Emission Defects Warranty
- Emissions Performance Warranty

Details of these warranties may be found with other vehicle warranties in your Warranty Information Booklet which comes with your NISSAN. If you did not receive a Warranty Information Booklet, or it has become lost, you may obtain a replacement by writing to:

 Nissan North America, Inc. Consumer Affairs Department P.O. Box 685003
 Franklin, TN 37068-5003

#### For Canada:

Emission Control System Warranty

Details of this warranty may be found with other vehicle warranties in your Warranty Information Booklet which comes with your NISSAN. If you did not receive a Warranty Information Booklet, or it has become lost, you may obtain a replacement by writing to:

Nissan Canada Inc.
 5290 Orbitor Drive
 Mississauga, Ontario,
 L4W 4Z5

### REPORTING SAFETY DEFECTS

#### For USA

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying NISSAN.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or NISSAN.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, D.C. 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

You may notify NISSAN by contacting our Consumer Affairs Department, toll-free, at 1-800-NISSAN-1.

### For Canada

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform Transport Canada in addition to notifying NISSAN.

If Transport Canada receives complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may request that NISSAN conduct a recall campaign. However, Transport Canada cannot become involved in individual problems between you, your dealer, or NISSAN.

You may contact Transport Canada's Defect Investigations and Recalls Division toll free at 1-800-333-0510. You may also report safety defects online at: https://www.apps.tc.gc.ca/Saf-Sec-Sur/7/PCDB-BDPP/Index.aspx.

Additional information concerning motor vehicle safety may be obtained from Transport Canada's Road Safety Information Centre at 1-800-333-0371 or online at www.tc.gc.ca/roadsafety (English speakers) or www.tc.gc.ca/securiteroutiere

### READINESS FOR INSPECTION/ MAINTENANCE (I/M) TEST

(French speakers).

To notify NISSAN of any safety concerns please contact our Consumer Information Centre toll free at 1-800-387-0122



A vehicle equipped with All-Wheel Drive (AWD) should never be tested using a two wheel dynamometer (such as the dynamometers used by some states for emissions testing), or similar equipment. Make sure you inform test facility personnel that your vehicle is equipped with AWD before it is placed on a dynamometer. Using the wrong test equipment may result in transmission damage or unexpected vehicle movement which could result in serious vehicle damage or personal injury.

Due to legal requirements in some states/areas or provinces, your vehicle may be required to be in what is called the "ready condition" for an Inspection/Maintenance (I/M) test of the emission control system.

The vehicle is set to the "ready condition" when it is driven through certain driving patterns. Usually, the "ready condition" can be obtained by ordinary usage of the vehicle.

If a powertrain system component is repaired or the battery is disconnected, the vehicle may be reset to a "not ready condition". Before taking the I/M test, check the vehicle's inspection/ maintenance test readiness condition. Place the ignition switch in the ON position without starting the engine. If the Malfunction Indicator Light (MIL) comes on steady for 20 seconds and then blinks for 10 seconds, the I/M test condition is "not ready". If the MIL does not blink after 20 seconds, the I/M test condition is "ready".

Contact a NISSAN dealer to set "ready condition" or to prepare the vehicle for testing.



### **EVENT DATA RECORDERS (EDR)**

This vehicle is equipped with an Event Data Recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.
- Sounds are not recorded.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a nontrivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g. name, gender, age and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer and NISSAN dealer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR. EDR data will only be accessed with the consent of the vehicle owner or lessee or as otherwise required or permitted by law.

### OWNER'S MANUAL/SERVICE MANUAL ORDER INFORMATION

Genuine NISSAN Service Manuals for this model year and prior can be purchased. A genuine NISSAN Service Manual is the best source of service and repair information for your vehicle. This manual is the same one used by the factory trained technicians working at a NISSAN dealer, Genuine NISSAN Owner's Manuals can also be purchased.

#### In the USA:

For current pricing and availability of genuine NISSAN Service Manuals contact:

> 1-800-450-9491 www.nissan-techinfo.com

For current pricing and availability of genuine NISSAN Owner's Manuals contact:

1-800-247-5321

#### In Canada:

To purchase a copy of a genuine NISSAN Service Manual or Owner's Manual for this model year and prior please contact a NISSAN dealer. For the phone number and location of a NISSAN dealer in your area call the NISSAN Information Center at 1-800-387-0122 and a bilingual NISSAN representative will assist you.





# 10 Index

| A  |
|--|
| ABS (Anti-lock Braking System) 5-40  |
| Adjusting the screen 4-19  |
| Advanced air bag system 1-44<br>Air bag system                                   |
| Advanced air bag system 1-44   |
| Front passenger air bag and status light 1-46<br>Front-seat mounted side-impact  |
| supplemental air bag system  |
| supplemental air bag system 1-49   |
| Air bag warning labels 1-52  |
| Air bag warning light 1-52, 2-17   |
| Air cleaner housing filter   |
| Air conditioner operation 4-20   |
| Air conditioner service 4-27   |
| Air conditioner specification label 9-12 Air conditioning system refrigerant and |
| lubricant recommendations 4-27, 9-7  |
| In-cabin microfilter 4-27  |
| Air conditioner operation  |
| security system) 2-30  |
| Alcohol, drugs and driving 5-8   |
| All-wheel drive (AWD) 5-33   |
| Antenna  |
| Anti-lock Braking System (ABS) 5-40  |
| Anti-lock braking system (ABS) warning light 2-13 Appearance care                |
| Exterior appearance care   |
| Interior appearance care   |
| Application download 4-71  |
| Audible reminders 2-19   |
| Audio operation precautions 4-28   |

| Audio setup                                       | 4-6  |
|---|------|
| Audio system                                      | 4-28 |
| Steering wheel audio controls                     |      |
| Audio system voice commands                       |      |
| Autolight system                                  | 2-36 |
| Automatic   |      |
| Air conditioner                                   |      |
| Door locks  |      |
| AUX (Auxiliary) input 4-47,                       |      |
| Average fuel consumption                          |      |
| Avoiding collision and rollover                   | 5-7  |
| В   |      |
| Back door (See lift gate)                         | 3-20 |
| Battery   | 8-13 |
| Battery replacement, Intelligent Key              | 8-24 |
| Battery replacement, Keyfob                       | 8-23 |
| Battery saver system                              | 2-37 |
| Variable voltage control system                   | 8-14 |
| Before starting the engine                        | 5-15 |
| Bluetooth ® Hands-Free Phone System               |      |
| (Type B)  | 4-85 |
| Bluetooth® Hands-Free Phone System                |      |
| (Type A)  | 4-72 |
| Bluetooth® hands-free phone system                | 4-94 |
| voice commands                                    | 4-94 |
| Bluetooth® settings<br>Bluetooth® streaming audio | 4-90 |
| Booster seats                                     | 1-34 |
| Brake   | 1-34 |
| Anti-lock Braking System (ABS)                    | 5-40 |
| Brake and clutch fluid                            |      |
| Brake system                                      | 5-39 |
| Parking brake operation                           | 5-29 |
| Warning light                                     | 2-13 |

| Break-in schedule                          | 5-31   |
|--|--------|
| Display ON/OFF button                      | . 4-6  |
| Instrument panel                           |        |
| Bulb check/instrument panel                | 2-13   |
| Bulb replacement                           | 8-26   |
| -  |        |
| C  |        |
| Cabin air filter                           | 4-27   |
| Capacities and recommended fuel/lubricants |        |
| Car phone or CB radio                      |        |
| Cargo cover                                |        |
| Cargo floor box                            |        |
| Catalytic converter, Three way catalyst    | . 5-4  |
| CD/USB memory care and cleaning            | 4-68   |
| Check tire pressure warning                | . 2-7  |
| Child restraints                           | 1-18   |
| Booster seats                              | 1-34   |
| LATCH system                               |        |
| Precautions on child restraints            | 1-18   |
| Child safety                               | 1-16   |
| Child safety rear door lock                |        |
| Chimes, Audible reminders                  |        |
| Circuit breaker, Fusible link              |        |
| Cleaning exterior and interior 7-2         | 2, 7-5 |
| Clock                                      | 2-41   |
| Clock (models with navigation system)      |        |
| Clutch fluid                               |        |
| Coat hook                                  |        |
| Cockpit                                    |        |
| Cold weather driving(Co.)                  | 5-43   |
| Compact Disc (CD) player (See              | 4 60   |
| audio system)                              |        |
| Connect phone                              |        |
| Connecting procedure                       | 4-87   |

| Continuously Variable Transmission  |
|---|
| (CVT) fluid 8-11  |
| Control panel buttons — color screen (Type A) 4-3   |
| Control panel buttons — color screen  |
| (Type B) 4-10   |
| Controls, Steering wheel audio controls 4-69  |
| Coolant   |
| Capacities and  |
| recommended fuel/lubricants 9-2   |
| Changing engine coolant 8-8   |
| Checking engine coolant level 8-8   |
| Corrosion protection  |
| Cover, Cargo cover  |
| Cruise control  |
| Cup holders 2-42  |
| CVT, Driving with CVT (Continuously   |
| Variable Transmission) 5-11, 5-17   |
|   |
|   |
| D   |
| Daytime running light system 2-37   |
| Daytime running light system 2-37 Defroster switch, Rear window and outside   |
| Daytime running light system  |
| Daytime running light system       2-37         Defroster switch, Rear window and outside mirror defroster switch       2-35         Dimensions and weights       9-9         Displaying Climate control       4-26         Door open warning light       2-14         Drive belt       8-15         Driving       All-wheel drive (AWD)       5-33         Cold weather driving       5-43         Driving with CVT (Continuously       5-11, 5-17 |
| Daytime running light system  |
| Daytime running light system  |
| Daytime running light system  |

| E                           |  |
|-----------------------------|--|
| Economy, Fuel               | 5-38<br>2-14<br>9-11<br>9-19   |
| Before starting the engine  |  |
| recommended fuel/lubricants | 8-8<br>8-9<br>8-8<br>2-8<br>4, 6-2<br>5-44<br>8-7<br>8-8<br>9-7<br>9-10<br>9-8<br>9-8<br>9-8 |
| Event Data Recorders (EDR)  | . 5-3  |

| ing the engine               | 5-15  |
|------------------------------|-------|
| nedule                       | 5-31  |
| and                          |       |
| ed fuel/lubricants           | . 9-2 |
| ngine coolant                | . 8-8 |
| ngine oil and filter         | . 8-9 |
| ngine coolant level          |       |
| ngine oil level              |       |
| perature gauge               |       |
| engine shut off 5-14         |       |
| k heater                     |       |
| partment check locations     |       |
| ing system                   |       |
| 1 2 6                        |       |
| nd oil filter recommendation |       |
| scosity                      |       |
| l number                     |       |
| cifications                  |       |
| le overheats                 |       |
| engine<br>orders (EDR)       | 0-10  |
| arbon monoxide)              |       |
| ge fuse warning              |       |
| ge luse warning              | . 2-1 |
|                              |       |
|                              |       |
|                              |       |
|                              |       |

| •   |                         |
|---|-------------------------|
| F.M.V.S.S./C.M.V.S.S. certification label<br>FCC Regulatory information   |                         |
| Air cleaner housing filter Changing engine oil and filter   | . 8-<br>6-<br>6-<br>9-1 |
| Brake and clutch fluid<br>Capacities and<br>recommended fuel/lubricants   |                         |
| Continuously Variable Transmission (CVT) fluid  | . 8-                    |
| Window washer fluidFM/AM/SAT radio operationFM-AM-SAT radio with Compact Disc                                       | 8-1                     |
| CD) player  |                         |
| olayer (Type C)   | 2-39<br>1-4<br>1-4      |
| Fuel Capacities and recommended fuel/lubricants Distance to empty Fuel economy Fuel information Fuel octane rating. | 2-10<br>5-3<br>9-4      |



| Fuel-filler cap                      | 3-21 | How to say numbers                   | 4-94  |   |     |
|--------------------------------------|------|--------------------------------------|-------|---|-----|
| Fuel-filler door                     |      | How to use brightness control button | 4-15  |   |     |
| Gauge                                |      | How to use the APPS-i button         |       | •   |     |
| Fuel Efficient Driving Tips          | 5-32 | How to use the back button 4-6,      |       | Jump starting                                   | 6-8 |
| Fuses                                |      | How to use the CAMERA button         |       | Sump starting                                   |     |
| Fusible links                        | 8-20 | How to use the ON-OFF button/Volume  |       | K   |     |
|                                      |      | control knob                         | 4-15  | K   |     |
| G                                    |      | How to use the SETUP button          | . 4-6 | Keyless entry                                   |     |
|                                      |      |                                      |       | (See remote keyless entry system)               | 3-7 |
| Gas cap                              | 3-21 |                                      |       | With Intelligent Key system (See Intelligent    |     |
| Gauge                                | 2-5  |                                      |       | Key system) 3                                   | -16 |
| Engine coolant temperature gauge     | 2-8  | IC Regulatory information            | 4-86  | Keys  |     |
| Fuel gauge                           | 2-9  | Ignition switch                      |       | For Intelligent Key system                      |     |
| Odometer                             | 2-6  | (with Intelligent Key system)        | 5-12  |   |     |
| Speedometer                          | 2-6  | (without Intelligent Key system)     | 5-10  |   |     |
| Tachometer                           |      | Key positions                        |       | -   |     |
| Trip computer                        | 2-10 | Immobilizer system                   |       | Labels  |     |
| General maintenance                  |      | In-cabin microfilter                 |       | Air bag warning labels 1                        | -52 |
| Giving voice commands                | 4-93 | Indicator lights                     | 2-17  | Air conditioner specification label             |     |
| Glove box                            |      | Information voice commands           | 4-96  | Emission control information label              |     |
|                                      |      | Initialization                       | 4-93  | Engine serial number                            |     |
| н                                    |      | Inside mirror                        |       |   | -11 |
|                                      |      | Inspection/maintenance (I/M) test    | 9-20  | Tire and Loading information label 8-31, 9      |     |
| Hands-Free Phone System, Bluetooth®  |      | Instrument brightness control        |       | Vehicle identification number (VIN)             |     |
| (Type A)                             | 4-72 | Instrument panel                     | . 2-4 | LATCH system 1                                  |     |
| Hazard warning flasher switch        |      | Integrated control system 2-21,      |       | License plate, Installing front license plate 9 |     |
| Head restraints/headrests            |      | Intelligent Key system               |       | Lift gate                                       |     |
| Headlights                           |      | Intelligent Key system warning light | 2-14  | Light   | 20  |
| Bulb replacement                     | 8-27 | Key operating range                  |       | Air bag warning light 1                         | -52 |
| Headlight switch                     |      | Key operation                        |       | Bulb replacement 8                              |     |
| Heated seats                         | 2-40 | P position selecting warning light   |       | Fog light switch                                | -30 |
| Heater                               |      | Remote keyless operation             |       | Headlight switch                                | -35 |
| Engine block heater                  | 5-44 | Interior light replacement           |       | Headlights bulb replacement 8                   | -07 |
| Heater and air conditioner operation |      | Interior lights                      |       | Indicator lights                                |     |
| Help voice commands                  |      | iPod® connecting                     |       | Interior lights                                 |     |
| Hood release                         |      | iPod® player operation 4-54,         |       | Map lights                                      |     |
| Horn                                 |      | ISOFIX child restraint               |       | Replacement                                     |     |
|                                      |      |                                      |       | Періасепіень 0                                  | 20  |
|                                      |      |                                      |       | 10  | 0-3 |

DEALER E-PROCESS

| Warning/indicator lights and   |
|--|
| audible reminders 2-13   |
| Lights, Exterior and interior light replacement 8-28   |
| Landing information (Can cabin)  |
| loading information (See venicle loading information) 9-14   |
| Lock   |
| Automatic door locks 3-6   |
| Door locks 3-4   |
| Lift gate lock 3-20  |
| Power door lock 3-4  |
| Loose fuel cap warning 2-7, 3-23   |
| Low fuel warning light 2-15  |
| Low tire pressure warning light 2-15   |
| Low tire pressure warning system   |
| (See tire pressure monitoring system (TPMS)) 5-4   |
| M  |
| IVI  |
|  |
| Maintenance  |
| Maintenance Battery 8-13   |
|  |
| Battery 8-13   |
| Battery         8-13           General maintenance         8-2   |
| Battery  |
| Battery       8-13         General maintenance       8-2         Inside the vehicle       8-3         Maintenance precautions       8-5  |
| Battery         8-13           General maintenance         8-2           Inside the vehicle         8-3           Maintenance precautions         8-5           Maintenance requirements         8-2   |
| Battery  |
| Battery         8-13           General maintenance         8-2           Inside the vehicle         8-3           Maintenance precautions         8-5           Maintenance requirements         8-2           Outside the vehicle         8-2           Seat belt maintenance         1-15           Making a call         4-87           Malfunction indicator light (MIL)         2-18  |
| Battery         8-13           General maintenance         8-2           Inside the vehicle         8-3           Maintenance precautions         8-5           Maintenance requirements         8-2           Outside the vehicle         8-2           Seat belt maintenance         1-15           Making a call         4-87           Malfunction indicator light (MIL)         2-18           Manual air conditioner         4-21  |
| Battery         8-13           General maintenance         8-2           Inside the vehicle         8-3           Maintenance precautions         8-5           Maintenance requirements         8-2           Outside the vehicle         8-2           Seat belt maintenance         1-15           Making a call         4-87           Malfunction indicator light (MIL)         2-18           Manual air conditioner         4-21           Manual front seat adjustment         1-3   |
| Battery  |
| Battery         8-13           General maintenance         8-2           Inside the vehicle         8-3           Maintenance precautions         8-5           Maintenance requirements         8-2           Outside the vehicle         8-2           Seat belt maintenance         1-15           Making a call         4-87           Malfunction indicator light (MIL)         2-18           Manual air conditioner         4-21           Manual front seat adjustment         1-3           Map lights         2-50           Mechanical key (Intelligent Key system)         3-4 |
| Battery         8-13           General maintenance         8-2           Inside the vehicle         8-3           Maintenance precautions         8-5           Maintenance requirements         8-2           Outside the vehicle         8-2           Seat belt maintenance         1-15           Making a call         4-87           Malfunction indicator light (MIL)         2-18           Manual air conditioner         4-21           Manual front seat adjustment         1-3           Map lights         2-50           Mechanical key (Intelligent Key system)         3-4 |
| Battery  |
| Battery         8-13           General maintenance         8-2           Inside the vehicle         8-3           Maintenance precautions         8-5           Maintenance requirements         8-2           Outside the vehicle         8-2           Seat belt maintenance         1-15           Making a call         4-87           Malfunction indicator light (MIL)         2-18           Manual air conditioner         4-21           Manual front seat adjustment         1-3           Map lights         2-50           Mechanical key (Intelligent Key system)         3-4 |

| Mirror Inside mirror Outside mirrors Vanity mirror Monitor, RearView monitor Moonroof My APPS voice commands | 3-25<br>3-25<br>3-27<br>4-15<br>2-48<br>4-96 |
|--|--|
| N  |  |
| Navigation setup   | 4-95<br>5-31<br>2-31<br>4-92                 |
| 0  |  |
| OdometerOff-road recoveryOil   |  |
| Capacities and recommended fuel/lubricants   | . 8-9<br>. 8-8<br>. 8-8                      |
| One Shot Call  | 4-87<br>4-93<br>2-10<br>3-25                 |
| Overheat, If your vehicle overheats Owner's Manual/Service Manual order information                          |  |

| P                                  |              |
|------------------------------------|--------------|
| Pandora® audio                     | 4-66         |
| Panic alarm 3-8,                   | 3-17         |
| Parking                            |              |
| Brake break-in                     | 5-39         |
| Parking brake operation            |              |
| Parking on hills                   | 5-37         |
| Phone                              |              |
| Bluetooth® Hands-Free Phone System |              |
| (Type A)                           | 4-72         |
| Car phone or CB radio              | 4-71         |
| Phone settings                     | 4-92         |
| Power                              | - 00         |
| Electric power steering system     | 5-38         |
| Moonroof                           | 2-48         |
| Power door lock                    |              |
| Power outlet                       | 2-42<br>2-45 |
| Power windows                      | 2-45         |
| Audio operation                    | 4-28         |
| Braking precautions                | 5-39         |
| Child restraints                   | 1-18         |
| Cruise control                     |              |
| Driving safety                     |              |
| Maintenance                        |              |
| Seat belt usage                    |              |
| Supplemental restraint system      |              |
| When starting and driving          |              |
| Push starting                      |              |
| Push-button ignition switch 5-12,  | 5-13         |
| R                                  |              |
| Radio                              | 4-28         |
| Car phone or CB radio              |              |
| Radio operation                    | 4-42         |



| Steering wheel audio controls                         |
|---|
| Rear door lock, Child safety rear door lock           |
| defroster switch 2-35                                 |
| Rear window wiper and washer switch 2-34              |
| RearView monitor 4-15                                 |
| Receiving a call                                      |
| Recorders, Event data 9-21                            |
| Registering with NissanConnect <sup>TM</sup> App 4-71 |
| Registering your vehicle in another country 9-9       |
| Regulatory information 4-86                           |
| Remote keyless entry function, For Intelligent        |
| Key system 3-16                                       |
| Remote keyless entry system                           |
| Reporting safety defects                              |
| Rollover  |
| Roof, Moonroof 2-48                                   |
| S   |
| Safety  |
| Child seat belts                                      |
| Front manual seat adjustment                          |
| Child safety  |

| Pregnant women 1-12                           |
|---|
| Seat belt cleaning 7-6                        |
| Seat belt extenders 1-15                      |
| Seat belt hooks1-15                           |
| Seat belt maintenance 1-15                    |
| Seat belt warning light 2-16                  |
| Seat belts 1-10                               |
| Seat belts with pretensioners 1-50            |
| Shoulder belt height adjustment 1-14          |
| Small children 1-17                           |
| Three-point type 1-12                         |
| Seat(s)                                       |
| Heated seats 2-40                             |
| Seats 1-2                                     |
| Security system (NISSAN Vehicle Immobilizer   |
| System), Engine start 2-31                    |
| Security system, Vehicle security system 2-29 |
| Servicing air conditioner 4-27                |
| Setting climate eco 4-26                      |
| Shift lever                                   |
| Shift lock release 5-22                       |
| Shift lock release                            |
| Transmission 5-22                             |
| Shifting                                      |
| CVT (Continuously                             |
| Variable Transmission) 5-11, 5-17             |
| Manual transmission 5-11, 5-23                |
| Shoulder belt height adjustment, For          |
| front seats 1-14                              |
| SOURCE select switch 4-69                     |
| Spare tire 8-41, 9-8                          |
| Spark plugs 8-15                              |
| Speedometer                                   |
| Starting                                      |
| Before starting the engine 5-15               |
| Jump starting                                 |
| Precautions when starting and driving 5-3     |

| Push starting                              | 6-1          |
|--|--------------|
| Starting the engine                        | 5-1          |
| Status light, Front passenger air bag      | 1-4          |
| Steering                                   |              |
| Electric power steering system             | 5-3          |
| Steering wheel switch for audio controls   | 4-6          |
| Tilting steering column                    | 3-2          |
| Storage                                    | 2-4          |
| Sun visors                                 | 3-2          |
| Supplemental air bag warning labels        | 1-5          |
| Supplemental air bag warning light 1-52,   | 2-1          |
| Supplemental restraint system              | 1-3          |
| Precautions on supplemental                |              |
| restraint system                           | 1-3          |
| Switch                                     |              |
| Audio control steering wheel switch        | 4-6          |
| Autolight switch                           | 2-3          |
| Fog light switch                           | 2-3          |
| Hazard warning flasher switch              | . 6-         |
| Headlight switch                           |              |
| Power door lock switch                     | . 3-         |
| Rear window and outside mirror             |              |
| defroster switch                           | 2-3          |
| Turn signal switch                         |              |
| Vehicle dynamic control (VDC) off switch   | 2-3          |
| System features                            | 4-9          |
| System setup                               | . 4-         |
|  |              |
| Т  |              |
| Tachometer                                 | 0-           |
| Temperature display                        |              |
| Temperature gauge, Engine coolant          | 2-11         |
|  | 9_6          |
| temperature gauge Text messaging           | رے .<br>ام-2 |
| Theft (NISSAN Vehicle Immobilizer System), | + 0          |
| Engine start                               | 0-2          |
| LITUILE Start                              | 2-3          |

| Three-way catalyst 5-4                              |
|---|
| Tilt steering column                                |
| Tire pressure, Low tire pressure warning light 2-15 |
| Tires   |
| Flat tire 6-3                                       |
| Low tire pressure warning system 5-4                |
| Tire and Loading information label 8-31, 9-11       |
| Tire chains 8-38                                    |
| Tire dressing 7-4                                   |
| Tire pressure 8-30                                  |
| Tire pressure monitoring                            |
| system (TPMS) 5-4, 6-3                              |
| Tire rotation 8-39                                  |
| Types of tires 8-37                                 |
| Uniform tire quality grading 9-18                   |
| Wheel/tire size                                     |
| Wheels and tires 8-30                               |
| Tonneau cover (see cargo cover) 2-44                |
| Touch screen  |
| Towing  |
| Flat towing 9-17                                    |
| Tow truck towing 6-12                               |
| Towing a trailer 9-17                               |
| TPMS, Tire pressure monitoring system 5-4           |
| TPMS, Tire pressure warning system 6-3              |
| Traffic info setup                                  |
| Trailer towing                                      |
| Transmission  |
| Continuously Variable Transmission                  |
| (CVT) fluid 8-11                                    |
| Driving with CVT (Continuously                      |
| Variable Transmission) 5-11, 5-17                   |
| Driving with manual transmission 5-11, 5-23         |
| Transmission shift lever lock release 5-22          |
| Transmitter (See remote keyless entry system) 3-7   |
| Transmitter, With Intelligent Key system            |
| (See Intelligent Key system) 3-16                   |

| raveling or registering your vehicle in<br>nother countryrip computerroubleshooting guideurn signal switch | 2-10<br>4-97   |
|--|--|
| U  |  |
| Inderbody cleaning   | 9-18<br>4-62<br>4-52   |
| V  |  |
| anity mirror   | 8-14<br>. 9-9<br>9-10<br>. 2-9<br>9-14<br>6-14<br>2-29<br>2-39<br>5-41 |
| ehicle phonebook   |  |
|  |  |

| DEAL |  |  |
|------|--|--|

| W  |        |
|--|--------|
| Warning                                    |        |
| Hazard warning flasher switch              | . 6-2  |
| Lights                                     |        |
| Tire pressure monitoring                   |        |
| system (TPMS) 5-4                          | 4. 6-3 |
| Warning/indicator lights and               | ,      |
| audible reminders                          | 2-12   |
| Warning labels, Air bag warning labels     | 1-52   |
| Warning light                              |        |
| Air bag warning light 1-52,                | 2-17   |
| Anti-lock braking system (ABS)             |        |
| warning light                              | 2-13   |
| AWD warning light                          | 5-35   |
| Brake warning light                        | 2-13   |
| Door open warning light                    | 2-14   |
| Electric power steering warning light      | 2-14   |
| Intelligent Key system warning light       | 2-14   |
| Low fuel warning light                     | 2-15   |
| Low tire pressure warning light            | 2-15   |
| Seat belt warning light                    | 2-16   |
| Warranty, Emission control system warranty | 9-19   |
| Washer switch                              |        |
| Rear window wiper and washer switch        |        |
| Windshield wiper and washer switch         |        |
| Washing                                    |        |
| Waxing                                     |        |
| Weights (See dimensions and weights)       |        |
| Wheel/tire size                            |        |
| Wheels and tires                           |        |
| Care of wheels                             | . 7-4  |
| Cleaning aluminum alloy wheels             | . 7-4  |
| Window washer fluid                        | 8-12   |
| Window(s)                                  | п ^    |
| Cleaning                                   |        |
| Power windows                              | 2-45   |

| Windshield wiper and washer switch  |       |
|---|-------|
| Wiper Rear window wiper and washer switch Rear window wiper blade Windshield wiper and washer switch Wiper blades |       |
| X   |       |
| XM setup  | . 4-7 |















#### **GAS STATION INFORMATION**

#### **FUEL INFORMATION:**

### **Except for NISMO RS models:**

NISSAN recommends the use of unleaded premium gasoline with an octane rating of at least 91 AKI (Anti-Knock Index) number (Research octane number 96).

If unleaded premium gasoline is not available, you may use unleaded regular gasoline with an octane rating of at least 87 AKI number (Research octane number 91), but you may notice a decrease in performance.

#### For NISMO RS models:

Use unleaded premium gasoline with an octane rating of at least 91 AKI (Anti-Knock Index) number (Research octane number 96).

If unleaded premium gasoline is not available, unleaded regular gasoline with an octane rating of at least 87 AKI number (Research octane number 91) may be temporarily used, but only under the following precautions:

- Have the fuel tank filled only partially with unleaded regular gasoline, and fill up with unleaded premium gasoline as soon as possible.
- Avoid full throttle driving and abrupt acceleration.

Use unleaded premium gasoline for maximum vehicle performance.



- Using a fuel other than that specified could adversely affect the emission control system, and may also affect warranty coverage.
- Under no circumstances should a leaded gasoline be used, because this will damage the three-way catalyst.
- Do not use E-15 or E-85 fuel in your vehicle. Your vehicle is not designed to run on E-15 or E-85 fuel. Using E-15 or E-85 fuel in a vehicle not specifically designed for E-15 or E-85 fuel can adversely affect the emission control devices and systems of the vehicle. Damage caused by such fuel is not covered by the NISSAN new vehicle limited warranty.
- U.S. government regulations require ethanol dispensing pumps to be identified by a small, square, orange

and black label with the common abbreviation or the appropriate percentage for that region.

For additional information, see "Capacities and recommended fuel/lubricants" (P.9-2).

### ENGINE OIL RECOMMENDATION:

- Genuine NISSAN engine oil or equivalent
- Engine oil with API Certification Mark
- Viscosity SAE 5W-30

See "Capacities and recommended fuel/lubricants" (P.9-2) for engine oil and oil filter recommendation.

### **COLD TIRE PRESSURES:**

The label is typically located on the driver side center pillar or on the driver's door. For additional information, see "Wheels and tires" (P.8-30).

### NEW VEHICLE BREAK-IN PROCE-DURES RECOMMENDATION:

During the first 1,200 miles (2,000 km) of vehicle use, follow the recommendations outlined in the "Break-in schedule" (P.5-31) of this Owner's Manual. Follow these recommendations for the future reliability and economy of your new vehicle.





Printing: October 2014 (26A)

Publication No.: OM14E 0F15U2

Printed in U.S.A.

TOOUM-1KA7D

PEALER E-PROCESS

F15-D